

# Operating Instructions

Diesel engine

12 V 4000 G23, G43, G63, G83

16 V 4000 G23, G43, G63, G83, G83L

M015710/04E



*Power. Passion. Partnership.*

# Table of Contents

|       |  |     |  |  |
|-------|--|-----|--|--|
| 1     | Safety   |     |  |  |
| 1.1   | General conditions   | 5   |  |  |
| 1.2   | Personnel and organizational requirements  | 6   |  |  |
| 1.3   | Transport  | 7   |  |  |
| 1.4   | Crankshaft transport locking device  | 8   |  |  |
| 1.5   | Safety regulations for startup and operation   | 11  |  |  |
| 1.6   | Explosion hazard when removing inspection port cover on engine   | 12  |  |  |
| 1.7   | Safety regulations for maintenance and repair work   | 13  |  |  |
| 1.8   | Auxiliary materials, fluids and lubricants, fire prevention and environmental protection                   | 16  |  |  |
| 1.9   | Conventions for safety instructions in the text  | 18  |  |  |
| 2     | General Information  |     |  |  |
| 2.1   | Engine side and cylinder designations  | 19  |  |  |
| 2.2   | Engine layout  | 20  |  |  |
| 2.3   | Sensors, actuators and injectors – Overview  | 21  |  |  |
| 3     | Technical Data   |     |  |  |
| 3.1   | 16 V 4000 Gx3 engine data: Continuous operation 3A, optimized fuel consumption                             | 25  |  |  |
| 3.2   | 12 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized fuel consumption                   | 28  |  |  |
| 3.3   | 12 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized exhaust emissions (TA-Luft)        | 32  |  |  |
| 3.4   | 16 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized fuel consumption                   | 36  |  |  |
| 3.5   | 12/16 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized exhaust emissions (EPA stage 2) | 40  |  |  |
| 3.6   | 12V 4000 Gx3 engine data: Standby operation 3D, optimized fuel consumption                                 | 44  |  |  |
| 3.7   | 16 V 4000 Gx3 engine data: Standby operation 3D, optimized fuel consumption                                | 48  |  |  |
| 3.8   | 12/16 V 4000 Gx3 engine data: Standby operation 3D, optimized exhaust emissions (EPA stage 2)              | 52  |  |  |
| 3.9   | 16 V 4000 G83L engine data: Standby operation 3D, optimized fuel consumption                               | 56  |  |  |
| 3.10  | 16 V 4000 G83L engine data: Standby operation 3D, optimized exhaust emissions (EPA stage 2)                | 60  |  |  |
| 3.11  | Final compression pressure   | 64  |  |  |
| 3.12  | Firing order   | 65  |  |  |
| 3.13  | Engine – Main dimensions   | 66  |  |  |
| 4     | Operation  |     |  |  |
| 4.1   | Putting the engine into operation after extended out-of-service periods (>3 months)                        | 67  |  |  |
| 4.2   | Putting the engine into operation after scheduled out-of-service-period                                    | 68  |  |  |
| 4.3   | Start engine in manual mode (testing mode)   | 69  |  |  |
| 4.4   | Safety system – Override   | 70  |  |  |
| 4.5   | Starting the engine in emergency situations (override mode)  | 71  |  |  |
| 4.6   | Operational checks   | 72  |  |  |
| 4.7   | Stop engine in manual mode (testing mode)  | 73  |  |  |
| 4.8   | Emergency stop   | 74  |  |  |
| 4.9   | After stopping the engine – Engine remains ready for operation   | 75  |  |  |
| 4.10  | After stopping the engine – putting the engine out of service  | 76  |  |  |
| 4.11  | Plant cleaning   | 77  |  |  |
| 5     | Maintenance  |     |  |  |
| 5.1   | Maintenance task reference table [QL 1]  | 78  |  |  |
| 6     | Troubleshooting  |     |  |  |
| 6.1   | Troubleshooting  | 79  |  |  |
| 6.2   | Engine governor ADEC (ECU 7) for Series 4000 genset engines – Fault messages                               | 82  |  |  |
| 7     | Task Description   |     |  |  |
| 7.1   | Engine   | 131 |  |  |
| 7.1.1 | Engine – Barring manually  | 131 |  |  |
| 7.1.2 | Engine – Barring with starting system  | 132 |  |  |
| 7.1.3 | Engine – Test run  | 133 |  |  |

|        |   |     |        |  |     |
|--------|---|-----|--------|--|-----|
| 7.2    | Cylinder Liner  | 134 | 7.14.3 | Centrifugal oil filter – Cleaning and filter sleeve replacement  | 174 |
| 7.2.1  | Cylinder liner – Endoscopic examination   | 134 | 7.15   | Coolant Circuit, General, High-Temperature Circuit               | 176 |
| 7.2.2  | Instructions and comments on endoscopic and visual examination of cylinder liners       | 136 | 7.15.1 | Engine coolant – Level check                                     | 176 |
| 7.3    | Crankcase Breather  | 138 | 7.15.2 | Engine coolant – Change  | 177 |
| 7.3.1  | Crankcase breather – Oil separator element replacement, diaphragm check and replacement | 138 | 7.15.3 | Engine coolant – Draining  | 178 |
| 7.4    | Valve Drive   | 140 | 7.15.4 | Engine coolant – Filling   | 179 |
| 7.4.1  | Valve gear – Lubrication  | 140 | 7.15.5 | Engine coolant pump – Relief bore check                          | 182 |
| 7.4.2  | Valve clearance – Check and adjustment  | 141 | 7.15.6 | Engine coolant – Sample extraction and analysis                  | 183 |
| 7.4.3  | Cylinder head cover – Removal and installation  | 144 | 7.16   | Low-Temperature Circuit  | 184 |
| 7.5    | Injection Pump / HP Pump  | 145 | 7.16.1 | Charge-air coolant – Level check                                 | 184 |
| 7.5.1  | HP pump – Filling with engine oil   | 145 | 7.16.2 | Charge-air coolant – Change                                      | 185 |
| 7.6    | Injection Valve / Injector  | 146 | 7.16.3 | Charge-air coolant – Draining                                    | 186 |
| 7.6.1  | Injector – Replacement  | 146 | 7.16.4 | Charge-air coolant – Filling                                     | 187 |
| 7.6.2  | Injector – Removal and installation   | 147 | 7.16.5 | Charge-air coolant pump – Relief bore check                      | 190 |
| 7.7    | Fuel System   | 152 | 7.17   | Belt Drive   | 191 |
| 7.7.1  | Fuel system – Venting   | 152 | 7.17.1 | Drive belt – Condition check                                     | 191 |
| 7.8    | Fuel Filter   | 153 | 7.18   | Battery-Charging Generator                                       | 192 |
| 7.8.1  | Fuel filter – Replacement   | 153 | 7.18.1 | Battery-charging generator drive – Drive belt tension adjustment | 192 |
| 7.8.2  | Fuel prefilter cleaning   | 154 | 7.18.2 | Battery-charging generator drive – Drive belt replacement        | 193 |
| 7.8.3  | Fuel prefilter – Differential pressure gauge check and adjustment                       | 155 | 7.19   | Engine Mounting / Support  | 194 |
| 7.8.4  | Fuel prefilter – Draining   | 156 | 7.19.1 | Engine mounting – Check  | 194 |
| 7.8.5  | Fuel prefilter – Flushing   | 157 | 7.20   | Wiring (General) for Engine/Gearbox/Unit                         | 195 |
| 7.8.6  | Fuel prefilter – Filter element replacement   | 159 | 7.20.1 | Engine wiring – Check  | 195 |
| 7.9    | Charge-Air Cooling  | 161 | 7.21   | Accessories for (Electronic) Engine Governor / Control System    | 196 |
| 7.9.1  | Intercooler – Checking condensate drain for coolant discharge and obstructions          | 161 | 7.21.1 | Engine governor and connectors – Cleaning                        | 196 |
| 7.10   | Air Filter  | 162 | 7.21.2 | Engine governor – Checking plug-in connections                   | 197 |
| 7.10.1 | Air filter – Replacement  | 162 | 7.21.3 | ECU 7 engine governor – Removal and installation                 | 198 |
| 7.10.2 | Air filter – Check  | 163 | 8      | Appendix A   |     |
| 7.10.3 | Air filter – Removal and installation   | 164 | 8.1    | Abbreviations  | 199 |
| 7.11   | Air Intake  | 165 | 8.2    | MTU contact persons/service partners                             | 202 |
| 7.11.1 | Service indicator – Signal ring position check (optional)                               | 165 | 9      | Appendix B   |     |
| 7.12   | Starting Equipment  | 166 | 9.1    | Special Tools  | 203 |
| 7.12.1 | Air starter – Manual operation  | 166 | 9.2    | Index  | 209 |
| 7.13   | Lube Oil System, Lube Oil Circuit   | 167 |        |  |     |
| 7.13.1 | Engine oil – Change   | 167 |        |  |     |
| 7.13.2 | Engine oil – Level check  | 169 |        |  |     |
| 7.13.3 | Engine oil – Sample extraction and analysis   | 170 |        |  |     |
| 7.14   | Oil Filtration / Cooling  | 171 |        |  |     |
| 7.14.1 | Engine oil filter – Replacement   | 171 |        |  |     |
| 7.14.2 | Oil indicator filter – Check  | 172 |        |  |     |


## 2 General Information

### 2.1 Engine side and cylinder designations

Engine sides are always designated as viewed from the driving end (KS).

The cylinders of the left engine side are designated "A" and those of the right side "B" (as per DIN ISO 1204). The cylinders of each bank are numbered consecutively, starting with No. 1 at the driving end.

Other components are numbered in the same way, i.e. starting with No. 1 on driving end.




1 Left engine side  
2 KGS = Free end

3 Right engine side  
4 KS = Driving end

## 2.2 Engine layout

Illustration applies in the same way to 12 V 4000 Gx3.



- |                                 |                      |                               |
|---------------------------------|----------------------|-------------------------------|
| 1 Exhaust gas outlet connection | 8 Charge-air pipe    | 15 HP fuel pump               |
| 2 Air filter                    | 9 Starter            | 16 Battery-charging generator |
| 3 Exhaust turbocharger          | 10 Engine mounting   | 17 Centrifugal oil filter     |
| 4 Intercooler                   | 11 Oil pan           | 18 Oil heat exchanger         |
| 5 Cylinder head                 | 12 Crankcase         | 19 Crankcase breather         |
| 6 Flywheel                      | 13 Engine oil filter |                               |
| 7 Lifting eye                   | 14 Fuel filter       |                               |


### Engine model designation

| Key to the engine model designations 12/16V 4000 Gx3(L) |                                  |
|---|----------------------------------|
| 12/16   | Number of cylinders              |
| V   | Cylinder arrangement: V engine   |
| 4000  | Series                           |
| G   | Application                      |
| x   | Application segment (2, 4, 6, 8) |
| 3   | Design index                     |
| L   | L (enhanced power / speed)       |

TIM-ID: 0000022697 - 002

## 2.3 Sensors, actuators and injectors – Overview

Illustrations are also valid for 12 V 4000 Gx3 engines.




1 Temperature sensors  
for cylinder exhaust gas  
B4.1 to B4.8 (engine  
side A)

2 Sensor B34 (fuel pres-  
sure after filter)


3 M8 (HP fuel pump ac-  
tuator)

The injectors (Y39.1 to Y39.8, engine side A) are underneath the cylinder head covers of the cylinder. Injector replacement and necessary activities (→ Page 146).



50703461


- |   |                                      |  |
|---|--------------------------------------|--|
| 1 B50 (crankcase pressure)                | 5 B07 (lube oil temperature)         | 9 B26 (charge-air coolant temperature) |
| 2 B05.3 (lube oil pressure before filter) | 6 B01 (camshaft speed)               | 10 B06 (engine coolant temperature)    |
| 3 B05 (lube oil pressure after filter)    | 7 B48 (fuel pressure in common rail) |  |
| 4 B33 (fuel temperature in common rail)   | 8 B43 (charge-air coolant pressure)  |  |



50703462

- |  |  |
|--|--|
| <p>1 Temperature sensors for cylinder exhaust gas B4.11 to B4.18 (engine side B)</p> <p>2 B16 (coolant pressure)</p> | <p>3 B10 (charge-air pressure)</p> <p>4 B09 (charge-air temperature)</p> |
|--|--|

The injectors (Y39.11 to Y39.18, engine side B) are underneath the cylinder head covers of the cylinder. Injector replacement and required procedure (→ Page 146)



50703463

1 B13 (crankshaft speed)

## 3 Technical Data

### 3.1 16 V 4000 Gx3 engine data: Continuous operation 3A, optimized fuel consumption

#### Explanation

| Abbreviation | Meaning   |
|--------------|---|
| DL           | Ref. value: Continuous power  |
| BL           | Ref. value: Fuel stop power   |
| A            | Design value  |
| G            | Guaranteed value  |
| R            | Guideline value   |
| L            | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N            | Not yet defined value   |

#### Reference conditions

| Engine model                   |      | 16V<br>4000G43 | 16V<br>4000G63 | 16V<br>4000G83 |
|--------------------------------|------|----------------|----------------|----------------|
| Application group              |      | 3A             | 3A             | 3A             |
| Intake air temperature         | °C   | 25             | 25             | 25             |
| Charge-air coolant temperature | °C   | 55             | 55             | 55             |
| Barometric pressure            | mbar | 1000           | 1000           | 1000           |
| Site altitude above sea level  | m    | 100            | 100            | 100            |

#### Power-related data (power ratings are net brake power to ISO 3046)

| Number of cylinders              |       | 16   | 16   | 16   |
|----------------------------------|-------|------|------|------|
| Rated engine speed               | A rpm | 1800 | 1500 | 1800 |
| Continuous power as per ISO 3046 | A kW  | 1560 | 1635 | 1710 |

#### General conditions (for maximum power)

| Number of cylinders            |        | 16 | 16 | 16 |
|--------------------------------|--------|----|----|----|
| Intake depression (new filter) | A mbar | 15 | 15 | 15 |
| Intake depression, max.        | L mbar | 50 | 50 | 50 |
| Exhaust overpressure           | A mbar | 30 | 30 | 30 |
| Exhaust overpressure, max.     | L mbar | 85 | 85 | 85 |

## Model related data (basic design)

|                               |  |             |      |      |      |
|-------------------------------|--|-------------|------|------|------|
| Number of cylinders           |  |             | 16   | 16   | 16   |
| Number of cylinders           |  |             | 16   | 16   | 16   |
| Cylinder arrangement: V-angle |  | Degrees (°) | 90   | 90   | 90   |
| Bore                          |  | mm          | 170  | 170  | 170  |
| Stroke                        |  | mm          | 210  | 210  | 210  |
| Cylinder displacement         |  | Liters      | 4.77 | 4.77 | 4.77 |
| Total displacement            |  | Liters      | 76.3 | 76.3 | 76.3 |
| Compression ratio             |  |             | 16.5 | 16.5 | 16.5 |
| Inlet valves per cylinder     |  |             | 2    | 2    | 2    |
| Exhaust valves per cylinder   |  |             | 2    | 2    | 2    |

## Combustion air / Exhaust gas

|  |   |         |     |     |     |
|--|---|---------|-----|-----|-----|
| Number of cylinders                      |   |         | 16  | 16  | 16  |
| Charge-air pressure before cylinder - BL | R | bar abs | 2.7 | 2.6 | 2.9 |

## Coolant system (HT circuit)

|   |   |     |     |     |     |
|---|---|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 | 100 | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 | 102 | 102 |
| Coolant temperature after engine, shutdown                              | L | °C  | 104 | 104 | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 | 0.7 | 0.7 |

## Coolant system (LT circuit)

|   |   |     |     |     |     |
|---|---|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  |
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 55  | 55  | 55  |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 | 0.7 | 0.7 |

## Lube oil system

|  |   |     |     |     |     |
|--|---|-----|-----|-----|-----|
| Number of cylinders                                |   |     | 16  | 16  | 16  |
| Lube-oil operating temperature before engine, from | R | °C  | 90  | 89  | 88  |
| Lube-oil operating temperature before engine, to   | R | °C  | 96  | 95  | 95  |
| Lube-oil temperature before engine, warning        | R | °C  | 97  | 97  | 97  |
| Lube-oil temperature before engine, shutdown       | L | °C  | 99  | 99  | 99  |
| Lube-oil operating pressure before engine, from    | R | bar | 4.7 | 4.2 | 4.7 |
| Lube-oil operating pressure before engine, to      | R | bar | 6.5 | 5.5 | 6.5 |

## Fuel system

|  |   |     |      |      |      |
|--|---|-----|------|------|------|
| Number of cylinders  |   |     | 16   | 16   | 16   |
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 | -0.1 | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  | 1.5  | 1.5  |

## General operating data

|   |   |     |     |     |     |
|---|---|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  |
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  | 10  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  | 32  | 32  |
| Firing speed, from  | R | rpm | 80  | 80  | 80  |
| Firing speed, to  | R | rpm | 120 | 120 | 120 |

## Capacities

|  |   |        |     |     |     |
|--|---|--------|-----|-----|-----|
| Number of cylinders  |   |        | 16  | 16  | 16  |
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 175 | 175 | 175 |
| Charge-air coolant, engine side  | R | Liters | 50  | 50  | 50  |
| Engine oil, total, for initial filling (standard oil system) (option: max. operating inclinations)   | R | Liters | 300 | 300 | 300 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations)                | R | Liters | 240 | 240 | 240 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 210 | 210 | 210 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 240 | 240 | 240 |

## Weights / main dimensions

|  |   |    |      |      |      |
|--|---|----|------|------|------|
| Number of cylinders  |   |    | 16   | 16   | 16   |
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 7700 | 7700 | 7700 |

## Acoustics

|  |   |       |     |     |     |
|--|---|-------|-----|-----|-----|
| Number of cylinders  |   |       | 16  | 16  | 16  |
| Exhaust noise, unsilenced - BL (sound power level LW, ISO 6798)                                  | R | dB(A) | 126 | 124 | 127 |
| Engine surface noise with attenuated intake noise (filter) - BL (sound power level LW, ISO 6798) | R | dB(A) | 124 | 124 | 124 |

## 3.2 12 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized fuel consumption

### Explanation

| Abbreviation | Meaning   |
|--------------|---|
| DL           | Ref. value: Continuous power  |
| BL           | Ref. value: Fuel stop power   |
| A            | Design value  |
| G            | Guaranteed value  |
| R            | Guideline value   |
| L            | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N            | Not yet defined value   |
| -            | Not applicable  |
| X            | Applicable  |

### Reference conditions

| Engine model                   |      |  | 12V4000 | 12V4000 | 12V4000 | 12V4000 | 12V4000 |
|--------------------------------|------|--|---------|---------|---------|---------|---------|
|                                |      |  | G23     | G23R    | G43     | G63     | G83     |
| Application group              |      |  | 3B      | 3B      | 3B      | 3B      | 3B      |
| Intake air temperature         | °C   |  | 25      | 25      | 25      | 25      | 25      |
| Charge-air coolant temperature | °C   |  | 55      | 55      | 55      | 55      | 55      |
| Raw water inlet temperature    | °C   |  | -       | -       | -       | -       | -       |
| Barometric pressure            | mbar |  | 1000    | 1000    | 1000    | 1000    | 1000    |
| Site altitude above sea level  | m    |  | 100     | 100     | 100     | 100     | 100     |

### Power-related data (power ratings are net brake power to ISO 3046)

| Number of cylinders  |   |     | 12   | 12   | 12   | 12   | 12   |
|--|---|-----|------|------|------|------|------|
| Rated engine speed   | A | rpm | 1500 | 1500 | 1800 | 1500 | 1800 |
| Continuous power ISO 3046 (10% overload capability, design power DIN 6280, ISO 8528) | A | kW  | 1420 | 1205 | 1520 | 1575 | 1736 |

### General conditions (for maximum power)

| Number of cylinders            |   |      | 12 | 12 | 12 | 12 | 12 |
|--------------------------------|---|------|----|----|----|----|----|
| Intake depression (new filter) | A | mbar | 15 | 15 | 15 | 15 | 15 |
| Intake depression, max.        | L | mbar | 50 | 50 | 50 | 50 | 50 |
| Exhaust overpressure           | A | mbar | 30 | 30 | 30 | 30 | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 | 85 | 85 | 85 | 85 |

## Model related data (basic design)

|  |             |  |      |      |      |      |      |
|--|-------------|--|------|------|------|------|------|
| Number of cylinders  |             |  | 12   | 12   | 12   | 12   | 12   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |             |  | X    | X    | X    | X    | X    |
| Uncooled exhaust lines   |             |  | X    | X    | X    | X    | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |             |  | X    | X    | X    | X    | X    |
| Combustion method: direct fuel injection                             |             |  | X    | X    | X    | X    | X    |
| Cooling method: Treated water  |             |  | X    | X    | X    | X    | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |             |  | X    | X    | X    | X    | X    |
| Number of cylinders  |             |  | 12   | 12   | 12   | 12   | 12   |
| Cylinder arrangement: V-angle  | Degrees (°) |  | 90   | 90   | 90   | 90   | 90   |
| Bore   | mm          |  | 170  | 170  | 170  | 170  | 170  |
| Stroke   | mm          |  | 210  | 210  | 210  | 210  | 210  |
| Cylinder displacement  | Liters      |  | 4.77 | 4.77 | 4.77 | 4.77 | 4.77 |
| Total displacement   | Liters      |  | 57.2 | 57.2 | 57.2 | 57.2 | 57.2 |
| Compression ratio  |             |  | 16.5 | 16.5 | 16.5 | 16.5 | 16.5 |
| Cylinder heads: individual cylinder heads                            |             |  | X    | X    | X    | X    | X    |
| Cylinder liners: wet, replaceable                                    |             |  | X    | X    | X    | X    | X    |
| Inlet valves per cylinder  |             |  | 2    | 2    | 2    | 2    | 2    |
| Exhaust valves per cylinder  |             |  | 2    | 2    | 2    | 2    | 2    |
| Standard housing connecting flange (engine main PTO)                 | SAE         |  | 00   | 00   | 00   | 00   | 00   |
| Flywheel interface   | DISC        |  | 21   | 21   | 21   | 21   | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |     |     |     |     |
|--|---|---------|-----|-----|-----|-----|-----|
| Number of cylinders                      |   |         | 12  | 12  | 12  | 12  | 12  |
| Charge air pressure before cylinder - DL | R | bar abs | 2.6 | 2.4 | 2.9 | 2.9 | 3.2 |

## Coolant system (HT circuit)

|   |   |    |     |     |     |     |     |
|---|---|----|-----|-----|-----|-----|-----|
| Number of cylinders   |   |    | 12  | 12  | 12  | 12  | 12  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C | 100 | 100 | 100 | 100 | 100 |
| Coolant temperature after engine, warning                               | R | °C | 102 | 102 | 102 | 102 | 102 |

|  |   |     |     |     |     |     |     |
|--|---|-----|-----|-----|-----|-----|-----|
| Number of cylinders                              |   |     | 12  | 12  | 12  | 12  | 12  |
| Coolant temperature after engine, shutdown       | L | °C  | 104 | 104 | 104 | 104 | 104 |
| Coolant antifreeze content, max.                 | L | %   | 50  | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max. | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

### Coolant system (LT circuit)

|   |   |     |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 12  | 12  | 12  |
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 55  | 55  | 55  | 55  | 55  |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |

### Lube oil system

|   |   |     |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|-----|
| Number of cylinders                                 |   |     | 12  | 12  | 12  | 12  | 12  |
| Lube-oil operating temperature before engine, from  | R | °C  | 88  | 88  | 88  | 88  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 98  | 98  | 98  | 98  | 98  |
| Lube-oil temperature before engine, warning         | R | °C  | 99  | 99  | 99  | 99  | 99  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 101 | 101 | 101 | 101 | 101 |
| Lube-oil operating pressure before engine, from     | R | bar | 5.0 | 5.0 | 5.0 | 5.0 | 5.0 |
| Lube-oil operating pressure before engine, to       | R | bar | 6.0 | 7.0 | 7.0 | 7.0 | 7.0 |
| Lube-oil operating pressure before engine, warning  | R | bar | --  | --  | --  | --  | --  |
| Lube-oil operating pressure before engine, shutdown | L | bar | --  | --  | --  | --  | --  |

### Fuel system

|  |   |     |      |      |      |      |      |
|--|---|-----|------|------|------|------|------|
| Number of cylinders  |   |     | 12   | 12   | 12   | 12   | 12   |
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 | -0.1 | -0.1 | -0.1 | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  | 1.5  | 1.5  | 1.5  | 1.5  |

## General operating data

|   |   |     |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 12  | 12  | 12  |
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  | 10  | 10  | 10  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  | 32  | 32  | 32  | 32  |
| Firing speed, from  | R | rpm | 80  | 80  | 80  | 80  | 80  |
| Firing speed, to  | R | rpm | 120 | 120 | 120 | 120 | 120 |

## Capacities

|  |   |        |     |     |     |     |     |
|--|---|--------|-----|-----|-----|-----|-----|
| Number of cylinders  |   |        | 12  | 12  | 12  | 12  | 12  |
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 160 | 160 | 160 | 160 | 160 |
| Charge-air coolant, engine side  | R | Liters | 40  | 40  | 40  | 40  | 40  |
| Engine oil, total, for initial filling (standard oil system) (option: max. operating inclinations)   | R | Liters | 260 | 260 | 260 | 260 | 260 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations)                | R | Liters | 260 | 260 | 260 | 260 | 260 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 | 160 | 160 | 160 | 160 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 | 200 | 200 | 200 | 200 |

## Weights / main dimensions

|  |   |    |       |       |       |       |       |
|--|---|----|-------|-------|-------|-------|-------|
| Number of cylinders  |   |    | 12    | 12    | 12    | 12    | 12    |
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 6200* | 6200* | 6200* | 6200* | 6200* |

## Acoustics

|   |   |       |     |     |     |     |     |
|---|---|-------|-----|-----|-----|-----|-----|
| Number of cylinders   |   |       | 12  | 12  | 12  | 12  | 12  |
| Exhaust noise, unsilenced - DL (sound power level LW, ISO 6798)                                 | R | dB(A) | 124 | 124 | 125 | 125 | 127 |
| Engine surface noise with attenuated intake noise filter) - DL (sound power level LW, ISO 6798) | R | dB(A) | 120 | 120 | 122 | 121 | 123 |

### 3.3 12 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized exhaust emissions (TA-Luft)

#### Explanation

| Abbreviation | Meaning   |
|--------------|---|
| DL           | Ref. value: Continuous power  |
| BL           | Ref. value: Fuel stop power   |
| A            | Design value  |
| G            | Guaranteed value  |
| R            | Guideline value   |
| L            | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N            | Not yet defined value   |
| -            | Not applicable  |
| X            | Applicable  |

#### Reference conditions

| Engine model                   |  |      | 12V4000<br>G23 | 12V4000<br>G23R | 12V4000<br>G63 |
|--------------------------------|--|------|----------------|-----------------|----------------|
| Application group              |  |      | 3B             | 3B              | 3B             |
| Intake air temperature         |  | °C   | 25             | 25              | 25             |
| Charge-air coolant temperature |  | °C   | 55             | 55              | 55             |
| Raw water inlet temperature    |  | °C   | -              | -               | -              |
| Barometric pressure            |  | mbar | 1000           | 1000            | 1000           |
| Site altitude above sea level  |  | m    | 100            | 100             | 100            |

#### Power-related data (power ratings are net brake power to ISO 3046)

| Number of cylinders  |   |     | 12   | 12   | 12   |
|--|---|-----|------|------|------|
| Rated engine speed   | A | rpm | 1500 | 1500 | 1500 |
| Continuous power ISO 3046 (10% overload capability, design power DIN 6280, ISO 8528) | A | kW  | 1420 | 1205 | 1575 |

#### General conditions (for maximum power)

| Number of cylinders            |   |      | 12 | 12 | 12 |
|--------------------------------|---|------|----|----|----|
| Intake depression (new filter) | A | mbar | 15 | 15 | 15 |
| Intake depression, max.        | L | mbar | 50 | 50 | 50 |
| Exhaust overpressure           | A | mbar | 30 | 30 | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 | 85 | 85 |

TIN-ID: 0000003032 - 002

## Model related data (basic design)

|  |  |             |      |      |      |
|--|--|-------------|------|------|------|
| Number of cylinders  |  |             | 12   | 12   | 12   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |  |             | X    | X    | X    |
| Uncooled exhaust lines   |  |             | X    | X    | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |  |             | X    | X    | X    |
| Combustion method: direct fuel injection                             |  |             | X    | X    | X    |
| Cooling method: Treated water  |  |             | X    | X    | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |  |             | X    | X    | X    |
| Number of cylinders  |  |             | 12   | 12   | 12   |
| Cylinder arrangement: V-angle  |  | Degrees (°) | 90   | 90   | 90   |
| Bore   |  | mm          | 170  | 170  | 170  |
| Stroke   |  | mm          | 210  | 210  | 210  |
| Cylinder displacement  |  | Liters      | 4.77 | 4.77 | 4.77 |
| Total displacement   |  | Liters      | 57.2 | 57.2 | 57.2 |
| Compression ratio  |  |             | 16.5 | 16.5 | 16.5 |
| Cylinder heads: individual cylinder heads                            |  |             | X    | X    | X    |
| Cylinder liners: wet, replaceable                                    |  |             | X    | X    | X    |
| Inlet valves per cylinder  |  |             | 2    | 2    | 2    |
| Exhaust valves per cylinder  |  |             | 2    | 2    | 2    |
| Standard housing connecting flange (engine main PTO)                 |  | SAE         | 00   | 00   | 00   |
| Flywheel interface   |  | DISC        | 21   | 21   | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |     |     |
|--|---|---------|-----|-----|-----|
| Number of cylinders                      |   |         | 12  | 12  | 12  |
| Charge air pressure before cylinder - DL | R | bar abs | 3.2 | 2.9 | 3.5 |

## Coolant system (HT circuit)

|   |   |     |     |     |     |
|---|---|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 12  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 | 100 | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 | 102 | 102 |
| Coolant temperature after engine, shutdown                              | L | °C  | 104 | 104 | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 | 0.7 | 0.7 |

## Coolant system (LT circuit)

|   |   |     |     |     |     |
|---|---|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 12  |
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 55  | 55  | 55  |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 | 0.7 | 0.7 |

## Lube oil system

|   |   |     |     |     |     |
|---|---|-----|-----|-----|-----|
| Number of cylinders                                 |   |     | 12  | 12  | 12  |
| Lube-oil operating temperature before engine, from  | R | °C  | 88  | 88  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 98  | 98  | 98  |
| Lube-oil temperature before engine, warning         | R | °C  | 99  | 99  | 99  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 101 | 101 | 101 |
| Lube-oil operating pressure before engine, from     | R | bar | 5.0 | 5.0 | 5.0 |
| Lube-oil operating pressure before engine, to       | R | bar | 7.0 | 7.0 | 7.0 |
| Lube-oil operating pressure before engine, warning  | R | bar | --  | --  | --  |
| Lube-oil operating pressure before engine, shutdown | L | bar | --  | --  | --  |

## Fuel system

|  |   |     |      |      |      |
|--|---|-----|------|------|------|
| Number of cylinders  |   |     | 12   | 12   | 12   |
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 | -0.1 | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  | 1.5  | 1.5  |

## General operating data

|   |   |     |     |     |     |
|---|---|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 12  |
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  | 10  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  | 32  | 32  |
| Firing speed, from  | R | rpm | 80  | 80  | 80  |
| Firing speed, to  | R | rpm | 120 | 120 | 120 |

## Capacities

|  |   |        |     |     |     |
|--|---|--------|-----|-----|-----|
| Number of cylinders  |   |        | 12  | 12  | 12  |
| Engine coolant capacity, engine side (without cooling equipment)                                   | R | Liters | 160 | 160 | 160 |
| Charge-air coolant, engine side  | R | Liters | 40  | 40  | 40  |
| Engine oil, total, for initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 260 | 260 | 260 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations)              | R | Liters | 260 | 260 | 260 |

|  |   |        |     |     |     |
|--|---|--------|-----|-----|-----|
| Number of cylinders  |   |        | 12  | 12  | 12  |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 | 160 | 160 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 | 200 | 200 |

### Weights / main dimensions

|  |   |    |       |       |       |
|--|---|----|-------|-------|-------|
| Number of cylinders  |   |    | 12    | 12    | 12    |
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 6200* | 6200* | 6200* |

### Acoustics

|   |   |       |     |     |     |
|---|---|-------|-----|-----|-----|
| Number of cylinders   |   |       | 12  | 12  | 12  |
| Exhaust noise, unsilenced - DL (sound power level LW, ISO 6798)                                 | R | dB(A) | 126 | 126 | 127 |
| Engine surface noise with attenuated intake noise filter) - DL (sound power level LW, ISO 6798) | R | dB(A) | 122 | 122 | 122 |

### 3.4 16 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized fuel consumption

#### Explanation

| Abbreviation | Meaning   |
|--------------|---|
| DL           | Ref. value: Continuous power  |
| BL           | Ref. value: Fuel stop power   |
| A            | Design value  |
| G            | Guaranteed value  |
| R            | Guideline value   |
| L            | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N            | Not yet defined value   |
| -            | Not applicable  |
| X            | Applicable  |

#### Reference conditions

| Engine model                   |      |  | 16V<br>4000G23 | 16V<br>4000G43 | 16V<br>4000G63 | 16V<br>4000G83 |
|--------------------------------|------|--|----------------|----------------|----------------|----------------|
| Application group              |      |  | 3B             | 3B             | 3B             | 3B             |
| Intake air temperature         | °C   |  | 25             | 25             | 25             | 25             |
| Charge-air coolant temperature | °C   |  | 55             | 55             | 55             | 55             |
| Raw-water inlet temperature    | °C   |  | -              | -              | -              | -              |
| Barometric pressure            | mbar |  | 1000           | 1000           | 1000           | 1000           |
| Site altitude above sea level  | m    |  | 100            | 100            | 100            | 100            |

#### Power-related data (power ratings are net brake power to ISO 3046)

| Number of cylinders  |   |     | 16   | 16   | 16   | 16   |
|--|---|-----|------|------|------|------|
| Rated engine speed   | A | rpm | 1500 | 1800 | 1500 | 1800 |
| Continuous power ISO 3046 (10% overload capability, design power DIN 6280, ISO 8528) | A | kW  | 1798 | 2020 | 1965 | 2280 |

#### General conditions (for maximum power)

| Number of cylinders            |   |      | 16 | 16 | 16 | 16 |
|--------------------------------|---|------|----|----|----|----|
| Intake depression (new filter) | A | mbar | 15 | 15 | 15 | 15 |
| Intake depression, max.        | L | mbar | 50 | 50 | 50 | 50 |
| Exhaust overpressure           | A | mbar | 30 | 30 | 30 | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 | 85 | 85 | 85 |

TIN-ID: 0000003003 - 002

## Model related data (basic design)

|  |  |         |      |      |      |      |
|--|--|---------|------|------|------|------|
| Number of cylinders  |  |         | 16   | 16   | 16   | 16   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |  |         | X    | X    | X    | X    |
| Uncooled exhaust lines   |  |         | X    | X    | X    | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |  |         | X    | X    | X    | X    |
| Combustion method: direct fuel injection                             |  |         | X    | X    | X    | X    |
| Cooling method: Treated water  |  |         | X    | X    | X    | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |  |         | X    | X    | X    | X    |
| Number of cylinders  |  |         | 16   | 16   | 16   | 16   |
| Cylinder arrangement: V-angle  |  | Degrees | 90   | 90   | 90   | 90   |
| Bore   |  | mm      | 170  | 170  | 170  | 170  |
| Stroke   |  | mm      | 210  | 210  | 210  | 210  |
| Cylinder displacement  |  | Liters  | 4.77 | 4.77 | 4.77 | 4.77 |
| Total displacement   |  | Liters  | 76.3 | 76.3 | 76.3 | 76.3 |
| Compression ratio  |  |         | 16.5 | 16.5 | 16.5 | 16.5 |
| Cylinder heads: individual cylinder heads                            |  |         | X    | X    | X    | X    |
| Cylinder liners: wet, replaceable                                    |  |         | X    | X    | X    | X    |
| Inlet valves per cylinder  |  |         | 2    | 2    | 2    | 2    |
| Exhaust valves per cylinder  |  |         | 2    | 2    | 2    | 2    |
| Standard housing connecting flange (engine main PTO)                 |  | SAE     | 00   | 00   | 00   | 00   |
| Flywheel interface   |  | DISC    | 21   | 21   | 21   | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |     |     |     |
|--|---|---------|-----|-----|-----|-----|
| Number of cylinders                      |   |         | 16  | 16  | 16  | 16  |
| Charge air pressure before cylinder - DL | R | bar abs | 2.6 | 2.9 | 2.8 | 3.1 |

## Coolant system (HT circuit)

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  | 16  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 | 100 | 100 | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 | 102 | 102 | 102 |
| Coolant temperature after engine, shut-down                             | L | °C  | 104 | 104 | 104 | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

## Coolant system (LT circuit)

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  | 16  |
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 55  | 55  | 55  | 55  |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

## Lube oil system

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders                                 |   |     | 16  | 16  | 16  | 16  |
| Lube-oil operating temperature before engine, from  | R | °C  | 89  | 90  | 89  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 95  | 96  | 95  | 95  |
| Lube-oil temperature before engine, warning         | R | °C  | 97  | 97  | 97  | 97  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 99  | 99  | 99  | 99  |
| Lube-oil operating pressure before engine, from     | R | bar | 4.2 | 4.7 | 4.2 | 4.7 |
| Lube-oil operating pressure before engine, to       | R | bar | 5.5 | 6.5 | 5.5 | 6.5 |
| Lube-oil operating pressure before engine, warning  | R | bar | --  | --  | --  | --  |
| Lube-oil operating pressure before engine, shutdown | L | bar | --  | --  | --  | --  |

## Fuel system

|  |   |     |      |      |      |      |
|--|---|-----|------|------|------|------|
| Number of cylinders  |   |     | 16   | 16   | 16   | 16   |
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 | -0.1 | -0.1 | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  | 1.5  | 1.5  | 1.5  |

## General operating data

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  | 16  |
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  | 10  | 10  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  | 32  | 32  | 32  |
| Firing speed, from  | R | rpm | 80  | 80  | 80  | 80  |
| Firing speed, to  | R | rpm | 120 | 120 | 120 | 120 |

## Capacities

| Number of cylinders  |   |        | 16  | 16  | 16  | 16  |
|--|---|--------|-----|-----|-----|-----|
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 260 | 260 | 260 | 260 |
| Charge-air coolant, engine side  | R | Liters | 50  | 50  | 50  | 50  |
| Engine oil, total, for initial filling (standard oil system) (option: max. operating inclinations)   | R | Liters | 300 | 300 | 300 | 300 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations)                | R | Liters | 240 | 240 | 240 | 240 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 210 | 210 | 210 | 210 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 240 | 240 | 240 | 240 |

## Weights / main dimensions

| Number of cylinders  |   |    | 16   | 16   | 16   | 16   |
|--|---|----|------|------|------|------|
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 7700 | 7700 | 7700 | 7700 |

## Acoustics

| Number of cylinders   |   |       | 16  | 16  | 16  | 16  |
|---|---|-------|-----|-----|-----|-----|
| Exhaust noise, unsilenced - DL (sound power level LW, ISO 6798)                                 | R | dB(A) | 125 | 127 | 126 | 129 |
| Engine surface noise with attenuated intake noise filter) - DL (sound power level LW, ISO 6798) | R | dB(A) | 126 | 125 | 128 | 125 |

### 3.5 12/16 V 4000 Gx3 engine data: Continuous operation, variable 3B, optimized exhaust emissions (EPA stage 2)

#### Explanation

| Abbreviation | Meaning   |
|--------------|---|
| DL           | Ref. value: Continuous power  |
| BL           | Ref. value: Fuel stop power   |
| A            | Design value  |
| G            | Guaranteed value  |
| R            | Guideline value   |
| L            | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N            | Not yet defined value   |
| -            | Not applicable  |
| X            | Applicable  |

#### Reference conditions

| Engine model                   |      |  | 12V     | 12V     | 16V     | 16V     |
|--------------------------------|------|--|---------|---------|---------|---------|
|                                |      |  | 4000G43 | 4000G83 | 4000G43 | 4000G83 |
| Application group              |      |  | 3B      | 3B      | 3B      | 3B      |
| Intake air temperature         | °C   |  | 25      | 25      | 25      | 25      |
| Charge-air coolant temperature | °C   |  | 45      | 45      | 45      | 45      |
| Raw-water inlet temperature    | °C   |  | -       | -       | -       | -       |
| Barometric pressure            | mbar |  | 1000    | 1000    | 1000    | 1000    |
| Site altitude above sea level  | m    |  | 100     | 100     | 100     | 100     |

#### Power-related data (power ratings are net brake power to ISO 3046)

| Number of cylinders  |   |     | 12   | 12   | 16   | 16   |
|--|---|-----|------|------|------|------|
| Rated engine speed   | A | rpm | 1800 | 1800 | 1800 | 1800 |
| Continuous power ISO 3046 (10% overload capability, design power DIN 6280, ISO 8528) | A | kW  | 1520 | 1736 | 2020 | 2280 |

#### General conditions (for maximum power)

| Number of cylinders            |   |      | 12 | 12 | 16 | 16 |
|--------------------------------|---|------|----|----|----|----|
| Intake depression (new filter) | A | mbar | 15 | 15 | 15 | 15 |
| Intake depression, max.        | L | mbar | 50 | 50 | 50 | 50 |
| Exhaust overpressure           | A | mbar | 30 | 30 | 30 | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 | 85 | 85 | 85 |

TIN-ID: 0000003018 - 002

## Model related data (basic design)

|  |         |  |      |      |      |      |
|--|---------|--|------|------|------|------|
| Number of cylinders  |         |  | 12   | 12   | 16   | 16   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |         |  | X    | X    | X    | X    |
| Uncooled exhaust lines   |         |  | X    | X    | X    | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |         |  | X    | X    | X    | X    |
| Combustion method: direct fuel injection                             |         |  | X    | X    | X    | X    |
| Cooling method: Treated water  |         |  | X    | X    | X    | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |         |  | X    | X    | X    | X    |
| Number of cylinders  |         |  | 12   | 12   | 16   | 16   |
| Cylinder arrangement: V-angle  | Degrees |  | 90   | 90   | 90   | 90   |
| Bore   | mm      |  | 170  | 170  | 170  | 170  |
| Stroke   | mm      |  | 210  | 210  | 210  | 210  |
| Cylinder displacement  | Liters  |  | 4.77 | 4.77 | 4.77 | 4.77 |
| Total displacement   | Liters  |  | 57.2 | 57.2 | 76.3 | 76.3 |
| Compression ratio  |         |  | 16.5 | 16.5 | 16.5 | 16.5 |
| Cylinder heads: individual cylinder heads                            |         |  | X    | X    | X    | X    |
| Cylinder liners: wet, replaceable                                    |         |  | X    | X    | X    | X    |
| Inlet valves per cylinder  |         |  | 2    | 2    | 2    | 2    |
| Exhaust valves per cylinder  |         |  | 2    | 2    | 2    | 2    |
| Standard housing connecting flange (engine main PTO)                 | SAE     |  | 00   | 00   | 00   | 00   |
| Flywheel interface   | DISC    |  | 21   | 21   | 21   | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |     |     |     |
|--|---|---------|-----|-----|-----|-----|
| Number of cylinders                      |   |         | 12  | 12  | 16  | 16  |
| Charge air pressure before cylinder - DL | R | bar abs | 3.0 | 3.1 | 3.0 | 3.2 |

## Coolant system (HT circuit)

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 16  | 16  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 | 100 | 100 | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 | 102 | 102 | 102 |
| Coolant temperature after engine, shut-down                             | L | °C  | 104 | 104 | 104 | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

## Coolant system (LT circuit)

| Number of cylinders   |   |     | 12  | 12  | 16  | 16  |
|---|---|-----|-----|-----|-----|-----|
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 45  | 45  | 45  | 45  |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

## Lube oil system

| Number of cylinders                                 |   |     | 12  | 12  | 16  | 16  |
|---|---|-----|-----|-----|-----|-----|
| Lube-oil operating temperature before engine, from  | R | °C  | 88  | 88  | 90  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 98  | 98  | 96  | 94  |
| Lube-oil temperature before engine, warning         | R | °C  | 99  | 99  | 97  | 97  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 101 | 101 | 99  | 99  |
| Lube-oil operating pressure before engine, from     | R | bar | 5.0 | 5.0 | 4.7 | 4.7 |
| Lube-oil operating pressure before engine, to       | R | bar | 7.0 | 7.0 | 6.5 | 6.5 |
| Lube-oil operating pressure before engine, warning  | R | bar | --  | --  | --  | --  |
| Lube-oil operating pressure before engine, shutdown | L | bar | --  | --  | --  | --  |

## Fuel system

| Number of cylinders  |   |     | 12   | 12   | 16   | 16   |
|--|---|-----|------|------|------|------|
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 | -0.1 | -0.1 | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  | 1.5  | 1.5  | 1.5  |

## General operating data

| Number of cylinders   |   |     | 12  | 12  | 16  | 16  |
|---|---|-----|-----|-----|-----|-----|
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  | 10  | 10  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  | 32  | 32  | 32  |
| Firing speed, from  | R | rpm | 80  | 80  | 80  | 80  |
| Firing speed, to  | R | rpm | 120 | 120 | 120 | 120 |

## Capacities

| Number of cylinders  |   |        | 12  | 12  | 16  | 16  |
|--|---|--------|-----|-----|-----|-----|
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 160 | 160 | 260 | 260 |
| Charge-air coolant, engine side  | R | Liters | 40  | 40  | 50  | 50  |
| Engine oil, total, for initial filling (standard oil system) (option: max. operating inclinations)   | R | Liters | 260 | 260 | 300 | 300 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations)                | R | Liters |     |     | 240 | 240 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 | 160 | 210 | 210 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 | 200 | 240 | 240 |

## Weights / main dimensions

| Number of cylinders  |   |    | 12    | 12    | 16   | 16   |
|--|---|----|-------|-------|------|------|
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 6200* | 6200* | 7700 | 7700 |

## Acoustics

| Number of cylinders   |   |       | 12  | 12  | 16  | 16  |
|---|---|-------|-----|-----|-----|-----|
| Exhaust noise, unsilenced - DL (sound power level LW, ISO 6798)                                 | R | dB(A) | 125 | 127 | 127 | 129 |
| Engine surface noise with attenuated intake noise filter) - DL (sound power level LW, ISO 6798) | R | dB(A) | 122 | 123 | 125 | 125 |

### 3.6 12V 4000 Gx3 engine data: Standby operation 3D, optimized fuel consumption

#### Explanation

| Abbreviation | Meaning   |
|--------------|---|
| DL           | Ref. value: Continuous power  |
| BL           | Ref. value: Fuel stop power   |
| A            | Design value  |
| G            | Guaranteed value  |
| R            | Guideline value   |
| L            | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N            | Not yet defined value   |
| -            | Not applicable  |
| X            | Applicable  |

#### Reference conditions

| Engine model                   |  |      | 12V     | 12V     | 12V     | 12V     |
|--------------------------------|--|------|---------|---------|---------|---------|
|                                |  |      | 4000G23 | 4000G43 | 4000G63 | 4000G83 |
| Application group              |  |      | 3D      | 3D      | 3D      | 3D      |
| Intake air temperature         |  | °C   | 25      | 25      | 25      | 25      |
| Charge-air coolant temperature |  | °C   | 55      | 55      | 55      | 55      |
| Raw-water inlet temperature    |  | °C   | -       | -       | -       | -       |
| Barometric pressure            |  | mbar | 1000    | 1000    | 1000    | 1000    |
| Site altitude above sea level  |  | m    | 100     | 100     | 100     | 100     |

#### Power-related data (power ratings are net brake power to ISO 3046)

| Number of cylinders      |   |     | 12   | 12   | 12   | 12   |
|--------------------------|---|-----|------|------|------|------|
| Rated engine speed       | A | rpm | 1500 | 1800 | 1500 | 1800 |
| Fuel stop power ISO 3046 | A | kW  | 1575 | 1736 | 1750 | 1910 |

#### General conditions (for maximum power)

| Number of cylinders            |   |      | 12 | 12 | 12 | 12 |
|--------------------------------|---|------|----|----|----|----|
| Intake depression (new filter) | A | mbar | 15 | 15 | 15 | 15 |
| Intake depression, max.        | L | mbar | 50 | 50 | 50 | 50 |
| Exhaust overpressure           | A | mbar | 30 | 30 | 30 | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 | 85 | 85 | 85 |

TIN-ID: 0000002873 - 002

## Model related data (basic design)

|  |         |  |      |      |      |      |
|--|---------|--|------|------|------|------|
| Number of cylinders  |         |  | 12   | 12   | 12   | 12   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |         |  | X    | X    | X    | X    |
| Uncooled exhaust lines   |         |  | X    | X    | X    | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |         |  | X    | X    | X    | X    |
| Combustion method: direct fuel injection                             |         |  | X    | X    | X    | X    |
| Cooling method: Treated water  |         |  | X    | X    | X    | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |         |  | X    | X    | X    | X    |
| Number of cylinders  |         |  | 12   | 12   | 12   | 12   |
| Cylinder arrangement: V-angle  | Degrees |  | 90   | 90   | 90   | 90   |
| Bore   | mm      |  | 170  | 170  | 170  | 170  |
| Stroke   | mm      |  | 210  | 210  | 210  | 210  |
| Cylinder displacement  | Liters  |  | 4.77 | 4.77 | 4.77 | 4.77 |
| Total displacement   | Liters  |  | 57.2 | 57.2 | 57.2 | 57.2 |
| Compression ratio  |         |  | 16.5 | 16.5 | 16.5 | 16.5 |
| Cylinder heads: individual cylinder heads                            |         |  | X    | X    | X    | X    |
| Cylinder liners: wet, replaceable                                    |         |  | X    | X    | X    | X    |
| Inlet valves per cylinder  |         |  | 2    | 2    | 2    | 2    |
| Exhaust valves per cylinder  |         |  | 2    | 2    | 2    | 2    |
| Standard housing connecting flange (engine main PTO)                 | SAE     |  | 00   | 00   | 00   | 00   |
| Flywheel interface   | DISC    |  | 21   | 21   | 21   | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |     |     |     |
|--|---|---------|-----|-----|-----|-----|
| Number of cylinders                      |   |         | 12  | 12  | 12  | 12  |
| Charge-air pressure before cylinder - BL | R | bar abs | 2.9 | 3.2 | 3.2 | 3.4 |

## Coolant system (HT circuit)

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 12  | 12  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 | 100 | 100 | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 | 102 | 102 | 102 |
| Coolant temperature after engine, shut-down                             | L | °C  | 104 | 104 | 104 | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

## Coolant system (LT circuit)

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 12  | 12  |
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 55  | 55  | 55  | 55  |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

## Lube oil system

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders                                 |   |     | 12  | 12  | 12  | 12  |
| Lube-oil operating temperature before engine, from  | R | °C  | 88  | 88  | 88  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 98  | 98  | 98  | 98  |
| Lube-oil temperature before engine, warning         | R | °C  | 99  | 99  | 99  | 99  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 101 | 101 | 101 | 101 |
| Lube-oil operating pressure before engine, from     | R | bar | 5.0 | 5.0 | 5.0 | 5.0 |
| Lube-oil operating pressure before engine, to       | R | bar | 7.0 | 7.0 | 7.0 | 7.0 |
| Lube-oil operating pressure before engine, warning  | R | bar | --  | --  | --  | --  |
| Lube-oil operating pressure before engine, shutdown | L | bar | --  | --  | --  | --  |

## Fuel system

|  |   |     |      |      |      |      |
|--|---|-----|------|------|------|------|
| Number of cylinders  |   |     | 12   | 12   | 12   | 12   |
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 | -0.1 | -0.1 | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  | 1.5  | 1.5  | 1.5  |

## General operating data

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 12  | 12  |
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  | 10  | 10  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  | 32  | 32  | 32  |
| Firing speed, from  | R | rpm | 80  | 80  | 80  | 80  |
| Firing speed, to  | R | rpm | 120 | 120 | 120 | 120 |

## Capacities

| Number of cylinders  |   |        | 12  | 12  | 12  | 12  |
|--|---|--------|-----|-----|-----|-----|
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 160 | 160 | 160 | 160 |
| Charge-air coolant, engine side  | R | Liters | 40  | 40  | 40  | 40  |
| Engine oil, total, for initial filling (standard oil system) (option: max. operating inclinations)   | R | Liters | 260 | 260 | 260 | 260 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations)                | R | Liters |     |     |     |     |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 | 160 | 160 | 160 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 | 200 | 200 | 200 |

## Weights / main dimensions

| Number of cylinders  |   |    | 12    | 12    | 12    | 12    |
|--|---|----|-------|-------|-------|-------|
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 6200* | 6200* | 6200* | 6200* |

## Acoustics

| Number of cylinders  |   |       | 12  | 12  | 12  | 12  |
|--|---|-------|-----|-----|-----|-----|
| Exhaust noise, unsilenced - BL (sound power level LW, ISO 6798)                                  | R | dB(A) | 125 | 127 | 126 | 129 |
| Engine surface noise with attenuated intake noise (filter) - BL (sound power level LW, ISO 6798) | R | dB(A) | 121 | 123 | 122 | 124 |

### 3.7 16 V 4000 Gx3 engine data: Standby operation 3D, optimized fuel consumption

#### Explanation

| Abbreviation | Meaning   |
|--------------|---|
| DL           | Ref. value: Continuous power  |
| BL           | Ref. value: Fuel stop power   |
| A            | Design value  |
| G            | Guaranteed value  |
| R            | Guideline value   |
| L            | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N            | Not yet defined value   |
| -            | Not applicable  |
| X            | Applicable  |

#### Reference conditions

| Engine model                   |      |  | 16V<br>4000G23 | 16V<br>4000G43 | 16V<br>4000G63 | 16V<br>4000G83 |
|--------------------------------|------|--|----------------|----------------|----------------|----------------|
| Application group              |      |  | 3D             | 3D             | 3D             | 3D             |
| Intake air temperature         | °C   |  | 25             | 25             | 25             | 25             |
| Charge-air coolant temperature | °C   |  | 55             | 55             | 55             | 55             |
| Raw-water inlet temperature    | °C   |  | -              | -              | -              | -              |
| Barometric pressure            | mbar |  | 1000           | 1000           | 1000           | 1000           |
| Site altitude above sea level  | m    |  | 100            | 100            | 100            | 100            |

#### Power-related data (power ratings are net brake power to ISO 3046)

| Number of cylinders      |   |     | 16   | 16   | 16   | 16   |
|--------------------------|---|-----|------|------|------|------|
| Rated engine speed       | A | rpm | 1500 | 1800 | 1500 | 1800 |
| Fuel stop power ISO 3046 | A | kW  | 1965 | 2280 | 2185 | 2500 |

#### General conditions (for maximum power)

| Number of cylinders            |   |      | 16 | 16 | 16 | 16 |
|--------------------------------|---|------|----|----|----|----|
| Intake depression (new filter) | A | mbar | 15 | 15 | 15 | 15 |
| Intake depression, max.        | L | mbar | 50 | 50 | 50 | 50 |
| Exhaust overpressure           | A | mbar | 30 | 30 | 30 | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 | 85 | 85 | 85 |

T1M-ID: 0000002922 - 002

## Model related data (basic design)

|  |         |  |      |      |      |      |
|--|---------|--|------|------|------|------|
| Number of cylinders  |         |  | 16   | 16   | 16   | 16   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |         |  | X    | X    | X    | X    |
| Uncooled exhaust lines   |         |  | X    | X    | X    | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |         |  | X    | X    | X    | X    |
| Combustion method: direct fuel injection                             |         |  | X    | X    | X    | X    |
| Cooling method: Treated water  |         |  | X    | X    | X    | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |         |  | X    | X    | X    | X    |
| Number of cylinders  |         |  | 16   | 16   | 16   | 16   |
| Cylinder arrangement: V-angle  | Degrees |  | 90   | 90   | 90   | 90   |
| Bore   | mm      |  | 170  | 170  | 170  | 170  |
| Stroke   | mm      |  | 210  | 210  | 210  | 210  |
| Cylinder displacement  | Liters  |  | 4.77 | 4.77 | 4.77 | 4.77 |
| Total displacement   | Liters  |  | 76.3 | 76.3 | 76.3 | 76.3 |
| Compression ratio  |         |  | 16.5 | 16.5 | 16.5 | 16.5 |
| Cylinder heads: individual cylinder heads                            |         |  | X    | X    | X    | X    |
| Cylinder liners: wet, replaceable                                    |         |  | X    | X    | X    | X    |
| Inlet valves per cylinder  |         |  | 2    | 2    | 2    | 2    |
| Exhaust valves per cylinder  |         |  | 2    | 2    | 2    | 2    |
| Standard housing connecting flange (engine main PTO)                 | SAE     |  | 00   | 00   | 00   | 00   |
| Flywheel interface   | DISC    |  | 21   | 21   | 21   | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |     |     |     |
|--|---|---------|-----|-----|-----|-----|
| Number of cylinders                      |   |         | 16  | 16  | 16  | 16  |
| Charge-air pressure before cylinder - BL | R | bar abs | 2.8 | 3.1 | 3.1 | 3.3 |

## Coolant system (HT circuit)

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  | 16  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 | 100 | 100 | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 | 102 | 102 | 102 |
| Coolant temperature after engine, shut-down                             | L | °C  | 104 | 104 | 104 | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

## Coolant system (LT circuit)

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  | 16  |
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 55  | 55  | 55  | 55  |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

## Lube oil system

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders                                 |   |     | 16  | 16  | 16  | 16  |
| Lube-oil operating temperature before engine, from  | R | °C  | 89  | 88  | 88  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 95  | 95  | 94  | 94  |
| Lube-oil temperature before engine, warning         | R | °C  | 97  | 97  | 97  | 97  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 99  | 99  | 99  | 99  |
| Lube-oil operating pressure before engine, from     | R | bar | 4.2 | 4.7 | 4.2 | 4.7 |
| Lube-oil operating pressure before engine, to       | R | bar | 5.5 | 6.5 | 5.5 | 6.5 |
| Lube-oil operating pressure before engine, warning  | R | bar | --  | --  | --  | --  |
| Lube-oil operating pressure before engine, shutdown | L | bar | --  | --  | --  | --  |

## Fuel system

|  |   |     |      |      |      |      |
|--|---|-----|------|------|------|------|
| Number of cylinders  |   |     | 16   | 16   | 16   | 16   |
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 | -0.1 | -0.1 | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  | 1.5  | 1.5  | 1.5  |

## General operating data

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 16  | 16  | 16  | 16  |
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  | 10  | 10  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  | 32  | 32  | 32  |
| Firing speed, from  | R | rpm | 80  | 80  | 80  | 80  |
| Firing speed, to  | R | rpm | 120 | 120 | 120 | 120 |

## Capacities

| Number of cylinders  |   |        | 16  | 16  | 16  | 16  |
|--|---|--------|-----|-----|-----|-----|
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 260 | 260 | 260 | 260 |
| Charge-air coolant, engine side  | R | Liters | 50  | 50  | 50  | 50  |
| Engine oil, total, for initial filling (standard oil system) (option: max. operating inclinations)   | R | Liters | 300 | 300 | 300 | 300 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations)                | R | Liters | 240 | 240 | 240 | 240 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 210 | 210 | 210 | 210 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 240 | 240 | 240 | 240 |

## Weights / main dimensions

| Number of cylinders  |   |    | 16   | 16   | 16   | 16   |
|--|---|----|------|------|------|------|
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 7700 | 7700 | 7700 | 7700 |

## Acoustics

| Number of cylinders  |   |       | 16  | 16  | 16  | 16  |
|--|---|-------|-----|-----|-----|-----|
| Exhaust noise, unsilenced - BL (sound power level LW, ISO 6798)                                  | R | dB(A) | 126 | 129 | 128 | 130 |
| Engine surface noise with attenuated intake noise (filter) - BL (sound power level LW, ISO 6798) | R | dB(A) | 128 | 125 | 125 | 126 |

### 3.8 12/16 V 4000 Gx3 engine data: Standby operation 3D, optimized exhaust emissions (EPA stage 2)

#### Explanation

| Abbreviation | Meaning   |
|--------------|---|
| DL           | Ref. value: Continuous power  |
| BL           | Ref. value: Fuel stop power   |
| A            | Design value  |
| G            | Guaranteed value  |
| R            | Guideline value   |
| L            | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N            | Not yet defined value   |
| -            | Not applicable  |
| X            | Applicable  |

#### Reference conditions

| Engine model                   |  |      | 12V     | 12V     | 16V     | 16V     |
|--------------------------------|--|------|---------|---------|---------|---------|
|                                |  |      | 4000G43 | 4000G83 | 4000G43 | 4000G83 |
| Application group              |  |      | 3D      | 3D      | 3D      | 3D      |
| Intake air temperature         |  | °C   | 25      | 25      | 25      | 25      |
| Charge-air coolant temperature |  | °C   | 45      | 45      | 45      | 45      |
| Raw-water inlet temperature    |  | °C   | -       | -       | -       | -       |
| Barometric pressure            |  | mbar | 1000    | 1000    | 1000    | 1000    |
| Site altitude above sea level  |  | m    | 100     | 100     | 100     | 100     |

#### Power-related data (power ratings are net brake power to ISO 3046)

| Number of cylinders      |   |     | 12   | 12   | 16   | 16   |
|--------------------------|---|-----|------|------|------|------|
| Rated engine speed       | A | rpm | 1800 | 1800 | 1800 | 1800 |
| Fuel stop power ISO 3046 | A | kW  | 1736 | 1910 | 2280 | 2500 |

#### General conditions (for maximum power)

| Number of cylinders            |   |      | 12 | 12 | 16 | 16 |
|--------------------------------|---|------|----|----|----|----|
| Intake depression (new filter) | A | mbar | 15 | 15 | 15 | 15 |
| Intake depression, max.        | L | mbar | 50 | 50 | 50 | 50 |
| Exhaust overpressure           | A | mbar | 30 | 30 | 30 | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 | 85 | 85 | 85 |

TIM-ID: 0000002955 - 002

## Model related data (basic design)

|  |  |         |      |      |      |      |
|--|--|---------|------|------|------|------|
| Number of cylinders  |  |         | 12   | 12   | 16   | 16   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |  |         | X    | X    | X    | X    |
| Uncooled exhaust lines   |  |         | X    | X    | X    | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |  |         | X    | X    | X    | X    |
| Combustion method: direct fuel injection                             |  |         | X    | X    | X    | X    |
| Cooling method: Treated water  |  |         | X    | X    | X    | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |  |         | X    | X    | X    | X    |
| Number of cylinders  |  |         | 12   | 12   | 16   | 16   |
| Cylinder arrangement: V-angle  |  | Degrees | 90   | 90   | 90   | 90   |
| Bore   |  | mm      | 170  | 170  | 170  | 170  |
| Stroke   |  | mm      | 210  | 210  | 210  | 210  |
| Cylinder displacement  |  | Liters  | 4.77 | 4.77 | 4.77 | 4,77 |
| Total displacement   |  | Liters  | 57.2 | 57.2 | 76,3 | 76.3 |
| Compression ratio  |  |         | 16.5 | 16.5 | 16.5 | 16.5 |
| Cylinder heads: individual cylinder heads                            |  |         | X    | X    | X    | X    |
| Cylinder liners: wet, replaceable                                    |  |         | X    | X    | X    | X    |
| Inlet valves per cylinder  |  |         | 2    | 2    | 2    | 2    |
| Exhaust valves per cylinder  |  |         | 2    | 2    | 2    | 2    |
| Standard housing connecting flange (engine main PTO)                 |  | SAE     | 00   | 00   | 00   | 00   |
| Flywheel interface   |  | DISC    | 21   | 21   | 21   | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |     |     |     |
|--|---|---------|-----|-----|-----|-----|
| Number of cylinders                      |   |         | 12  | 12  | 16  | 16  |
| Charge-air pressure before cylinder - BL | R | bar abs | 3.2 | 3.3 | 3.2 | 3.3 |

## Coolant system (HT circuit)

|   |   |     |     |     |     |     |
|---|---|-----|-----|-----|-----|-----|
| Number of cylinders   |   |     | 12  | 12  | 16  | 16  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 | 100 | 100 | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 | 102 | 102 | 102 |
| Coolant temperature after engine, shut-down                             | L | °C  | 104 | 104 | 104 | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

### Coolant system (LT circuit)

| Number of cylinders   |   |     | 12  | 12  | 16  | 16  |
|---|---|-----|-----|-----|-----|-----|
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 45  | 45  | 45  | 45  |
| Coolant antifreeze content, max.  | L | %   | 50  | 50  | 50  | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 | 0.7 | 0.7 | 0.7 |

### Lube oil system

| Number of cylinders                                 |   |     | 12  | 12  | 16  | 16  |
|---|---|-----|-----|-----|-----|-----|
| Lube-oil operating temperature before engine, from  | R | °C  | 88  | 88  | 88  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 98  | 98  | 94  | 94  |
| Lube-oil temperature before engine, warning         | R | °C  | 99  | 99  | 97  | 97  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 101 | 101 | 99  | 99  |
| Lube-oil operating pressure before engine, from     | R | bar | 5.0 | 5.0 | 4.7 | 4.7 |
| Lube-oil operating pressure before engine, to       | R | bar | 7.0 | 7.0 | 6.5 | 6.5 |
| Lube-oil operating pressure before engine, warning  | R | bar | --  | --  | --  | --  |
| Lube-oil operating pressure before engine, shutdown | L | bar | --  | --  | --  | --  |

### Fuel system

| Number of cylinders  |   |     | 12   | 12   | 16   | 16   |
|--|---|-----|------|------|------|------|
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 | -0.1 | -0.1 | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  | 1.5  | 1.5  | 1.5  |

### General operating data

| Number of cylinders   |   |     | 12  | 12  | 16  | 16  |
|---|---|-----|-----|-----|-----|-----|
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  | 10  | 10  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  | 32  | 32  | 32  |
| Firing speed, from  | R | rpm | 80  | 80  | 80  | 80  |
| Firing speed, to  | R | rpm | 120 | 120 | 120 | 120 |

## Capacities

| Number of cylinders  |   |        | 12  | 12  | 16  | 16  |
|--|---|--------|-----|-----|-----|-----|
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 160 | 160 | 260 | 260 |
| Charge-air coolant, engine side  | R | Liters | 40  | 40  | 50  | 50  |
| Engine oil, total, for initial filling (standard oil system) (option: max. operating inclinations)   | R | Liters | 260 | 260 | 300 | 300 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations)                | R | Liters |     |     | 240 | 240 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 | 160 | 210 | 210 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 | 200 | 240 | 240 |

## Weights / main dimensions

| Number of cylinders  |   |    | 12    | 12    | 16   | 16   |
|--|---|----|-------|-------|------|------|
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 6200* | 6200* | 7700 | 7700 |

## Acoustics

| Number of cylinders  |   |       | 12  | 12  | 16  | 16  |
|--|---|-------|-----|-----|-----|-----|
| Exhaust noise, unsilenced - BL (sound power level LW, ISO 6798)                                  | R | dB(A) | 127 | 129 | 129 | 130 |
| Engine surface noise with attenuated intake noise (filter) - BL (sound power level LW, ISO 6798) | R | dB(A) | 123 | 124 | 125 | 126 |

### 3.9 16 V 4000 G83L engine data: Standby operation 3D, optimized fuel consumption

#### Explanation

| Abbrevia-<br>tion | Meaning   |
|-------------------|---|
| DL                | Ref. value: Continuous power  |
| BL                | Ref. value: Fuel stop power   |
| A                 | Design value  |
| G                 | Guaranteed value  |
| R                 | Guideline value   |
| L                 | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N                 | Not yet defined value   |
| -                 | Not applicable  |
| X                 | Applicable  |

#### Reference conditions

|                                |  |      |                 |
|--------------------------------|--|------|-----------------|
| Engine model                   |  |      | 16V<br>4000G83L |
| Application group              |  |      | 3D              |
| Intake air temperature         |  | °C   | 25              |
| Charge-air coolant temperature |  | °C   | 45              |
| Raw water inlet temperature    |  | °C   | -               |
| Barometric pressure            |  | mbar | 1000            |
| Site altitude above sea level  |  | m    | 100             |

#### Power-related data (power ratings are net brake power to ISO 3046)

|                          |   |     |      |
|--------------------------|---|-----|------|
| Number of cylinders      |   |     | 16   |
| Rated engine speed       | A | rpm | 1800 |
| Fuel stop power ISO 3046 | A | kW  | 2740 |

#### General conditions (for maximum power)

|                                |   |      |    |
|--------------------------------|---|------|----|
| Number of cylinders            |   |      | 16 |
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max.        | L | mbar | 30 |
| Exhaust overpressure           | A | mbar | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 |

TIM-ID: 0000039902 - 001

## Model related data (basic design)

|  |  |             |      |
|--|--|-------------|------|
| Number of cylinders  |  |             | 16   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |  |             | X    |
| Uncooled exhaust lines   |  |             | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |  |             | X    |
| Combustion method: direct fuel injection                             |  |             | X    |
| Cooling method: Treated water  |  |             | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |  |             | X    |
| Number of cylinders  |  |             | 16   |
| Cylinder arrangement: V-angle  |  | Degrees (°) | 90   |
| Bore   |  | mm          | 170  |
| Stroke   |  | mm          | 210  |
| Cylinder displacement  |  | Liters      | 4.77 |
| Total displacement   |  | Liters      | 76.3 |
| Compression ratio  |  |             | 16.4 |
| Inlet valves per cylinder  |  |             | 2    |
| Cylinder heads: individual cylinder heads                            |  |             | X    |
| Cylinder liners: wet, replaceable                                    |  |             | X    |
| Exhaust valves per cylinder  |  |             | 2    |
| Standard housing connecting flange (engine main PTO)                 |  | SAE         | 00   |
| Flywheel interface (DISC)  |  |             | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |
|--|---|---------|-----|
| Number of cylinders                      |   |         | 16  |
| Charge-air pressure before cylinder - BL | R | bar abs | 3.7 |

## Coolant system (HT circuit)

|   |   |     |     |
|---|---|-----|-----|
| Number of cylinders   |   |     | 16  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 |
| Coolant temperature after engine, shutdown                              | L | °C  | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 |

## Coolant system (LT circuit)

|   |   |     |     |
|---|---|-----|-----|
| Number of cylinders   |   |     | 16  |
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 45  |
| Coolant antifreeze content, max.  | L | %   | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 |

## Lube oil system

|   |   |     |     |
|---|---|-----|-----|
| Number of cylinders                                 |   |     | 16  |
| Lube-oil operating temperature before engine, from  | R | °C  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 94  |
| Lube-oil temperature before engine, warning         | R | °C  | 97  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 99  |
| Lube-oil operating pressure before engine, from     | R | bar | 4.7 |
| Lube-oil operating pressure before engine, to       | R | bar | 6.5 |
| Lube-oil operating pressure before engine, warning  | R | bar | -   |
| Lube-oil operating pressure before engine, shutdown | L | bar | -   |

## Fuel system

|  |   |     |      |
|--|---|-----|------|
| Number of cylinders  |   |     | 16   |
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  |

## General operating data

|   |   |     |     |
|---|---|-----|-----|
| Number of cylinders   |   |     | 16  |
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  |
| Firing speed, from  | R | rpm | 80  |
| Firing speed, to  | R | rpm | 120 |

## Capacities

|  |   |        |     |
|--|---|--------|-----|
| Number of cylinders  |   |        | 16  |
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 175 |
| Charge-air coolant, engine side  | R | Liters | 50  |
| Engine oil capacity, initial filling (standard oil system) (Option: max. operating inclinations)     | R | Liters | 300 |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations)                | R | Liters | 240 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (Option: max. operating inclinations) | L | Liters | 210 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (Option: max. operating inclinations) | L | Liters | 240 |

## Weights / main dimensions

|  |   |    |      |
|--|---|----|------|
| Number of cylinders  |   |    | 16   |
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 7700 |

## Acoustics

|  |   |       |     |
|--|---|-------|-----|
| Number of cylinders  |   |       | 16  |
| Exhaust noise, silenced - BL (sound power level LW, ISO 6798+3)                                  | R | dB(A) | 130 |
| Engine surface noise with attenuated intake noise (filter) - BL (sound power level LW, ISO 6798) | R | dB(A) | 126 |

### 3.10 16 V 4000 G83L engine data: Standby operation 3D, optimized exhaust emissions (EPA stage 2)

#### Explanation

| Abbrevia-<br>tion | Meaning   |
|-------------------|---|
| DL                | Ref. value: Continuous power  |
| BL                | Ref. value: Fuel stop power   |
| A                 | Design value  |
| G                 | Guaranteed value  |
| R                 | Guideline value   |
| L                 | Limit value, up to which the engine can be operated, without change (e.g. of power settings). |
| N                 | Not yet defined value   |
| -                 | Not applicable  |
| X                 | Applicable  |

#### Reference conditions

|                                |  |      |                 |
|--------------------------------|--|------|-----------------|
| Engine model                   |  |      | 16V<br>4000G83L |
| Application group              |  |      | 3D              |
| Intake air temperature         |  | °C   | 25              |
| Charge-air coolant temperature |  | °C   | 45              |
| Raw water inlet temperature    |  | °C   | -               |
| Barometric pressure            |  | mbar | 1000            |
| Site altitude above sea level  |  | m    | 100             |

#### Power-related data (power ratings are net brake power to ISO 3046)

|                          |   |     |      |
|--------------------------|---|-----|------|
| Number of cylinders      |   |     | 16   |
| Rated engine speed       | A | rpm | 1800 |
| Fuel stop power ISO 3046 | A | kW  | 2740 |

#### General conditions (for maximum power)

|                                |   |      |    |
|--------------------------------|---|------|----|
| Number of cylinders            |   |      | 16 |
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max.        | L | mbar | 30 |
| Exhaust overpressure           | A | mbar | 30 |
| Exhaust overpressure, max.     | L | mbar | 85 |

## Model related data (basic design)

|  |  |             |      |
|--|--|-------------|------|
| Number of cylinders  |  |             | 16   |
| Engine with exhaust turbocharging (ETC) and charge-air cooling (CAC) |  |             | X    |
| Uncooled exhaust lines   |  |             | X    |
| Operating method: Four-stroke cycle, diesel, single-action           |  |             | X    |
| Combustion method: direct fuel injection                             |  |             | X    |
| Cooling method: Treated water  |  |             | X    |
| Direction of rotation: c.c.w. (facing driving end)                   |  |             | X    |
| Number of cylinders  |  |             | 16   |
| Cylinder arrangement: V-angle  |  | Degrees (°) | 90   |
| Bore   |  | mm          | 170  |
| Stroke   |  | mm          | 210  |
| Cylinder displacement  |  | Liters      | 4.77 |
| Total displacement   |  | Liters      | 76.3 |
| Compression ratio  |  |             | 16.4 |
| Inlet valves per cylinder  |  |             | 2    |
| Cylinder heads: individual cylinder heads                            |  |             | X    |
| Cylinder liners: wet, replaceable                                    |  |             | X    |
| Exhaust valves per cylinder  |  |             | 2    |
| Standard housing connecting flange (engine main PTO)                 |  | SAE         | 00   |
| Flywheel interface (DISC)  |  |             | 21   |

## Combustion air / Exhaust gas

|  |   |         |     |
|--|---|---------|-----|
| Number of cylinders                      |   |         | 16  |
| Charge-air pressure before cylinder - BL | R | bar abs | 3,7 |

## Coolant system (HT circuit)

|   |   |     |     |
|---|---|-----|-----|
| Number of cylinders   |   |     | 16  |
| Coolant temperature (at engine connection: outlet to cooling equipment) | A | °C  | 100 |
| Coolant temperature after engine, warning                               | R | °C  | 102 |
| Coolant temperature after engine, shutdown                              | L | °C  | 104 |
| Coolant antifreeze content, max.  | L | %   | 50  |
| Pressure loss in off-engine cooling system, max.                        | L | bar | 0.7 |

## Coolant system (LT circuit)

|   |   |     |     |
|---|---|-----|-----|
| Number of cylinders   |   |     | 16  |
| Coolant temperature before intercooler (at engine connection: from cooling equipment) | A | °C  | 45  |
| Coolant antifreeze content, max.  | L | %   | 50  |
| Pressure loss in off-engine cooling system, max.                                      | L | bar | 0.7 |

## Lube oil system

|   |   |     |     |
|---|---|-----|-----|
| Number of cylinders                                 |   |     | 16  |
| Lube-oil operating temperature before engine, from  | R | °C  | 88  |
| Lube-oil operating temperature before engine, to    | R | °C  | 94  |
| Lube-oil temperature before engine, warning         | R | °C  | 97  |
| Lube-oil temperature before engine, shutdown        | L | °C  | 99  |
| Lube-oil operating pressure before engine, from     | R | bar | 4.7 |
| Lube-oil operating pressure before engine, to       | R | bar | 6.5 |
| Lube-oil operating pressure before engine, warning  | R | bar | -   |
| Lube-oil operating pressure before engine, shutdown | L | bar | -   |

## Fuel system

|  |   |     |      |
|--|---|-----|------|
| Number of cylinders  |   |     | 16   |
| Fuel pressure at engine inlet connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine inlet connection, max. (when engine is starting) | L | bar | 1.5  |

## General operating data

|   |   |     |     |
|---|---|-----|-----|
| Number of cylinders   |   |     | 16  |
| Cold start capability: air temperature (w/o start aid, w/o preheating) - (case A) | R | °C  | 10  |
| Coolant preheating: preheating temperature (min.)                                 | R | °C  | 32  |
| Firing speed, from  | R | rpm | 80  |
| Firing speed, to  | R | rpm | 120 |

## Capacities

|  |   |        |     |
|--|---|--------|-----|
| Number of cylinders  |   |        | 16  |
| Engine coolant capacity, engine side (without cooling equipment)                                     | R | Liters | 175 |
| Charge-air coolant, engine side  | R | Liters | 50  |
| Engine oil capacity, initial filling (standard oil system) (Option: max. operating inclinations)     | R | Liters | 300 |
| Oil change quantity, max. (standard oil system) (Option: max. operating inclinations)                | R | Liters | 240 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (Option: max. operating inclinations) | L | Liters | 210 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (Option: max. operating inclinations) | L | Liters | 240 |

## Weights / main dimensions

|  |   |    |      |
|--|---|----|------|
| Number of cylinders  |   |    | 16   |
| Engine dry weight (basic engine configuration according to scope of delivery specifications) | R | kg | 7700 |

## Acoustics

|  |   |       |     |
|--|---|-------|-----|
| Number of cylinders  |   |       | 16  |
| Exhaust noise, unsilenced - BL (sound power level LW, ISO 6798+3)                                | R | dB(A) | 130 |
| Engine surface noise with attenuated intake noise (filter) - BL (sound power level LW, ISO 6798) | R | dB(A) | 126 |

### 3.11 Final compression pressure

**Final compression pressure**

|                                       |                  |
|---------------------------------------|------------------|
| Final compression pressure at 120 rpm | 24 bar to 28 bar |
|---------------------------------------|------------------|


## 3.12 Firing order

### Firing order

| Number of cylinders | Firing order  |
|---------------------|---|
| 8V                  | A1-B4-A4-A2-B3-A3-B2-B1                                       |
| 12V                 | A1-B5-A5-B3-A3-B6-A6-B2-A2-B4-A4-B1                           |
| 16 V                | A1-A7-B4-B6-A4-B8-A2-A8-B3-B5-A3-A5-B2-A6-B1-B7               |
| 20 V                | A1-B5-A8-B7-A5-B2-A7-B10-A2-B3-A10-B6-A3-B4-A6-B9-A4-B1-A9-B8 |

### 3.13 Engine – Main dimensions

Also valid for 12 V and 16 V engines.



| Engine model  | Length (A)      | Width (B)       | Height (C)      |
|---------------|-----------------|-----------------|-----------------|
| 12 V 4000 Gx3 | approx. 2520 mm | approx. 1660 mm | approx. 2160 mm |
| 16 V 4000 Gx3 | approx. 2990 mm | approx. 1660 mm | approx. 2160 mm |

# 4 Operation

## 4.1 Putting the engine into operation after extended out-of-service periods (>3 months)

### Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ MTU Preservation and Represervation Specifications (A001070/..) are available.

### Putting the PowerPack into operation after extended out-of-service-periods (>3 months)

| Item                            | Action   |
|---------------------------------|--|
| Engine                          | Depreserve (→ MTU Fluids and Lubricants Specifications A001070/..).  |
| Valve gear                      | Lubricate valve gear every $\geq 6$ months (→ Page 140).   |
| Lube oil system                 | Check engine oil level (→ Page 169).   |
| Fuel prefilter                  | Fill with fuel (→ Page 159).   |
| Fuel prefilter, pressure gauge  | Align adjustable pointer with position of pressure indicator (→ Page 155).   |
| Coolant circuit                 | If engine is out of service for more than one year, change engine coolant (→ Page 177).<br>Change charge-air coolant (→ Page 185). |
| Coolant circuit                 | Check engine coolant level (→ Page 176);<br>Check charge-air coolant level (→ Page 184).   |
| Coolant circuit                 | Heat engine coolant with coolant preheating unit.  |
| Engine governor                 | Check plug-in connections (→ Page 197).  |
| Monitoring system               | Carry out lamp test (see manufacturer's documentation).  |
| Engine/generator control system | Switch ON;<br>Select operating mode, e.g. MANUAL OPERATION, AUTOMATIC OPERATION.   |
| HP fuel pump                    | Only for engines without oil priming pump<br>Fill HP fuel pump with new engine oil (→ Page 145).                                   |

## 4.2 Putting the engine into operation after scheduled out-of-service-period

### Preconditions

- ☑ Engine is stopped and starting disabled.

### Putting the engine into operation

| Item                            | Task   |
|---------------------------------|--|
| Lube oil system                 | Check oil level (→ Page 169);  |
| Cooling system                  | Check engine coolant level (→ Page 176);<br>Check charge-air coolant level (→ Page 184). |
| Cooling system                  | Preheat coolant with preheating unit.  |
| Fuel prefilter                  | Drain (→ Page 156).  |
| Monitoring equipment            | Carry out lamp test (see manufacturer's documentation).                                  |
| Engine/generator control system | Switch ON;<br>Select operating mode, e.g. MANUAL OPERATION, AUTOMATIC OPERATION.         |

## 4.3 Start engine in manual mode (testing mode)

### Preconditions

- ☑ Generator (if provided) not connected to network.
- ☑ External start interlock is not activated.

|        |  |
|--------|--|
| DANGER |  <p>Unguarded rotating and moving engine components.<br/> <b>Risk of serious injury – danger to life!</b></p> <ul style="list-style-type: none"> <li>• Before barring or starting the engine, make sure that nobody is in the danger zone.</li> </ul> |
|--------|--|

|         |  |
|---------|--|
| WARNING |  <p>Engine noise above 85 dB (A).<br/> <b>Risk of damage to hearing!</b></p> <ul style="list-style-type: none"> <li>• Wear ear protectors.</li> </ul> |
|---------|--|

### Preparation

| Item   | Task                   |
|--|------------------------|
| Operating mode selector switch (if provided) | Change to manual mode. |
| Preheating pump (if provided)                | Switch ON.             |

### Starting the engine

| Item   | Task   |
|--|--|
| Switchgear cabinet, control panel etc. (depending on manufacturer) | <p>If coolant temperature is</p> <ul style="list-style-type: none"> <li>• &gt; 40 °C (with preheating equipment), or</li> <li>• &gt; 5 °C (without preheating equipment):</li> </ul> <p>Press start button.</p> <ul style="list-style-type: none"> <li>• Automatic starting sequence is performed;</li> <li>• Engine speed display instrument indicates increasing crankshaft speed;</li> <li>• After the starting sequence is completed, engine is running at rated speed.</li> </ul> |

### Connect generator to network (if provided), run engine to reach operating temperature )

| Item   | Task   |
|--|--|
| Switchgear cabinet, control panel etc. (depending on manufacturer) | Close the generator circuit breaker.   |
| Engine   | Apply full load only after engine has reached operating temperature (coolant temperature approx. 75 °C). |

## 4.4 Safety system – Override

|         |  |
|---------|--|
| CAUTION | <p>Safety functions and engine shutdown alarms will be disregarded.</p> <p><b>Serious damage to plant!</b></p> <ul style="list-style-type: none"> <li>Initiate emergency start only in emergency situations.</li> </ul>                        |
| CAUTION | <p>Inadmissible operational condition.</p> <p><b>Major material damage!</b></p> <ul style="list-style-type: none"> <li>Use override function only in hazardous situations to ensure full capability in case of engine malfunctions.</li> </ul> |

### Preparation

Note: This function is only available when a pushbutton is provided.

### Bypassing the safety system (Override)

| Item   | Action  |
|--|---|
| Switchgear cabinet, control panel etc. (depending on manufacturer) | Activate pushbutton for Override input of the ECU. <ul style="list-style-type: none"> <li>Certain shutdown criteria and/or starting prerequisites are ignored.</li> </ul> |
| Switchgear cabinet, control panel etc. (depending on manufacturer) | Actuate start button, for further starting sequence, refer to engine start (→ Page 69).   |
| Control and display panels   | During operation, check the displayed operational data (speed, temperature, pressures).<br><br>Constantly monitor plant limit values.                                     |

## 4.5 Starting the engine in emergency situations (override mode)

CAUTION



Safety functions and engine shutdown alarms will be disregarded.

**Serious damage to plant!**

- Initiate emergency start only in emergency situations.

### Preparation

| Item                  | Task                   |
|-----------------------|------------------------|
| Operating mode switch | Set to emergency mode. |

### Starting the engine in emergency situations

| Item            | Task   |
|-----------------|--|
| Control cabinet | Actuate switch/button for ECU override input.  |
| Control cabinet | <ul style="list-style-type: none"><li>• Automatic starting procedure is performed; any safety functions and alarms leading to engine shutdown are disregarded;</li><li>• Tachometer indicates increasing crankshaft speed;</li><li>• Engine is running at rated speed when the starting sequence is completed.</li></ul> |

### Connecting the generator (if fitted) to mains

| Item            | Task   |
|-----------------|--|
| Control cabinet | If generator is not connected to mains: Close generator circuit breaker. |
| Engine          | Operate engine at rated power.   |

## 4.6 Operational checks

|         |  |
|---------|--|
| DANGER  |  <p>Unguarded rotating and moving engine components.<br/> <b>Risk of serious injury – danger to life!</b></p> <ul style="list-style-type: none"> <li>• Take special care when working on a running engine.</li> </ul> |
| WARNING |  <p>Engine noise above 85 dB (A).<br/> <b>Risk of damage to hearing!</b></p> <ul style="list-style-type: none"> <li>• Wear ear protectors.</li> </ul>   |

### Operational checks

| Item                                 | Measure  |
|--------------------------------------|--|
| Control and display panels           | Check readings of operational data (speed, temperature, pressures).  |
| Engine oil                           | Check engine oil level (→ Page 169)  |
| Engine under load                    | Check engine/plant and piping for leaks, repair leaky pipes with the engine stopped (exhaust lines and turbocharger turbine housings may be red-hot. If the maximum exhaust temperatures are not exceeded, no restrictions in engine operation are required)<br><br>Check for abnormal running noises and vibration. |
| Engine at nominal speed              |  |
| Fuel prefilter                       | Check reading on differential pressure gauge to ensure that maximum permissible value is not exceeded (→ Page 155).  |
| Exhaust system                       | Check exhaust color (→ Page 79).   |
| Intercooler                          | Check condensate drain(s) for water discharge and obstruction (→ Page 161).  |
| Air filter                           | Check signal ring position of contamination indicator (→ Page 165).<br><br>Replace air filter (→ Page 162) if the signal ring is completely visible in the contamination indicator control window.   |
| Engine coolant pump                  | Check relief bore (→ Page 182).  |
| Charge-air coolant pump              | Check relief bore (→ Page 190).  |
| Compressed-air system (if installed) | Check operating pressure on pressure gauge;<br>Always fill compressed-air tank to max. pressure;<br><br>Drain condensate from compressed-air tank, pressure drop must not exceed 1 bar.  |

## 4.7 Stop engine in manual mode (testing mode)

### Preconditions

- ☑ Generator (if provided) not connected to network.
- ☑ Engine is running in manual mode.

CAUTION



Stopping the engine when it is running at full load causes extreme stress to the engine.

**Risk of overheating, damage to components!**

- Before stopping the engine, operate it at idle speed until operating temperatures decrease and stable values are indicated.

### Preparing the generator drive (only with generator breaker)

| Item   | Task  |
|--------|---|
| Engine | After opening the generator breaker (if provided), allow to cool down off-load for approx. 5 minutes. |

### Preparing the pump drive (diesel-mechanical/diesel-electric)

| Item   | Task  |
|--------|---|
| Engine | Allow to cool down for approx. 5 minutes at reduced engine speed. Observe natural resonance of engine (installation-dependent)! |

### Stopping the engine

| Item   | Task  |
|--|---|
| Switchgear cabinet, control panel etc. (depending on manufacturer) | Press stop button. <ul style="list-style-type: none"><li>• Automatic stopping sequence is performed;</li><li>• Engine is stopped.</li></ul> |

### After stopping the engine

| Item         | Task  |
|--------------|---|
| Coolant pump | Allow to run on for sufficient time after stopping. |

## 4.8 Emergency stop

CAUTION



An emergency stop causes extreme stress to the engine.

**Risk of overheating, damage to components!**

- Initiate emergency stop only in emergency situations.

### Emergency stop from LOP

| Item                  | Task  |
|-----------------------|---|
| EMERGENCY STOP button | Press. <ul style="list-style-type: none"><li>• Engine is stopped by switching off power supply to ECU;</li><li>• Signalization (e.g. by horn, flashing lamp) is released.</li></ul> |

### After emergency stop from LOP

| Item  | Task  |
|---|---|
| Switching cabinet, control panel etc. (depending on manufacturer) | Press button for alarm acknowledgement. <ul style="list-style-type: none"><li>• Audible and visual signalization stops.</li></ul> |

## 4.9 After stopping the engine – Engine remains ready for operation

### After stopping the engine

| Item                          | Action   |
|-------------------------------|--|
| Engine/generator/pump control | Select operating mode, e.g. MANUAL, AUTOMATIC OPERATION. |

## 4.10 After stopping the engine – putting the engine out of service

### Preconditions

- ☑ MTU-Preservation and Rereservation Specifications (A001070/..) are available.

### After stopping the engine

| Item                             | Task  |
|----------------------------------|---|
| Cooling system                   | Drain engine coolant (→ Page 178);<br>Drain charge-air coolant (→ Page 186) if: <ul style="list-style-type: none"><li>• freezing temperatures are expected and the engine is to remain out of service for an extended period and coolant has no antifreeze additive;</li><li>• the engine room is not heated;</li><li>• the coolant is not maintained at a suitable temperature;</li><li>• the antifreeze concentration is insufficient for the engine-room temperature;</li><li>• antifreeze concentration is 50 % and engine-room temperature is below -40°C.</li></ul> |
| Engine/generator/pump controller | Switch OFF.   |
| Air intake and exhaust system    | If the engine is to remain out of service for more than 1 week, seal the engine's air and exhaust sides. If the engine is to remain out of service for more than 1 month, preserve engine (→ MTU-Preservation and Rereservation Specifications A001070/..).   |

## 4.11 Plant cleaning

### Preconditions

- Engine is stopped and starting disabled.
- Operating voltage is not present.

### Special tools, Material, Spare parts

| Designation / Use     | Part No. | Qty. |
|-----------------------|----------|------|
| Steam jet cleaner     | -        | 1    |
| Cleaner (Hakupur 312) | 30390    | 1    |

|   |   |
|---|---|
| <b>WARNING</b><br>   | <b>Compressed air</b><br><b>Risk of injury!</b> <ul style="list-style-type: none"><li>• Do not direct compressed-air jet at persons.</li><li>• Wear protective goggles / safety mask and ear protectors.</li></ul>  |
| <b>WARNING</b><br>  | <b>Water jet.</b><br><b>Risk of injury and scalding!</b> <ul style="list-style-type: none"><li>• Do not direct water jet at persons.</li><li>• Wear protective clothing, gloves, and goggles / safety mask.</li></ul>   |
| <b>CAUTION</b><br> | <b>Excessive reaction time of cleaning agents on components.</b><br><b>Damage to component!</b> <ul style="list-style-type: none"><li>• Observe manufacturer's instructions.</li><li>• Wear protective clothing, gloves, and goggles / safety mask.</li></ul> |
| <b>NOTICE</b><br>  | <b>Dry with compressed air.</b><br><b>Damage to component!</b> <ul style="list-style-type: none"><li>• Never aim compressed air directly at electronic components.</li></ul>  |

### Plant cleaning

1. Carry out plant cleaning only in areas where an appropriate oil separator is provided (environmental protection).
2. Prior to putting the cleaning unit into operation, read the Operating Instructions of the water/steam jet unit carefully and observe the safety precautions.
3. During external cleaning of the plant with water/steam-jet units, the pressure of the high-pressure jet (cleaning jet) must not exceed 50 bar. A minimum distance between spray nozzle and plant of 1 m must be observed. The temperature of the cleaning medium must not exceed 80 °C.
4. For external cleaning with high-pressure jet, use a flat-mouth nozzle only.
5. Carry out external cleaning as follows:
  - a) Seal all openings in a suitable fashion.
  - b) Remove coarse dirt.
  - c) Spray on cleaner sparingly and leave it for 1 to 5 minutes.
  - d) Use the high-pressure jet to remove the loosened dirt.

Note: Never aim compressed air directly at electronic components.  
e) Dry engine.

# 5 Maintenance

## 5.1 Maintenance task reference table [QL1]

The maintenance tasks and intervals for this product are defined in the Maintenance Schedule. The Maintenance Schedule is a stand-alone publication.

The task numbers in this table provide reference to the maintenance tasks specified in the Maintenance Schedule.

| Task  | Option | Maintenance tasks   |              |
|-------|--------|---|--------------|
| W0500 |        | Check engine oil level.   | (→ Page 169) |
| W0501 |        | Visually inspect engine for leaks and general condition.  | (→ Page 72)  |
| W0502 | X      | Check intercooler drain(s).   | (→ Page 161) |
| W0503 |        | Check signal ring position of service indicator on air filter.  | (→ Page 165) |
| W0505 |        | Check relief bores of water pump(s).  | (→ Page 182) |
| W0506 |        | Check engine for abnormal running noises, exhaust color and vibrations.   | (→ Page 72)  |
| W0507 | X      | Drain water and contaminants from fuel prefilter.   | (→ Page 72)  |
| W0508 | X      | Check reading on differential pressure gage of fuel prefilter.  | (→ Page 72)  |
| W0534 |        | Carry out test run, minimum duration: until steady-state temperature is reached, no less than 1/3 load (monthly). | (→ Page 133) |
| W1001 |        | Replace fuel filter or fuel filter element.   | (→ Page 153) |
| W1005 |        | Replace air filter.   | (→ Page 162) |
| W1006 |        | Replace fuel injectors.   | (→ Page 146) |
| W1008 |        | Replace engine oil filter when changing engine oil, or when the interval (years) is reached, at the latest.       | (→ Page 171) |
| W1009 | X      | Check layer thickness of the oil residue, clean out and replace filter sleeve.                                    | (→ Page 174) |
| W1011 |        | Perform endoscopic examination.   | (→ Page 134) |
| W1046 |        | Crankcase breather: Replace filter or filter element.   | (→ Page 138) |
| W1207 |        | Check and adjust valve clearance. Attention!First adjustment after 1,000 operating hours.                         | (→ Page 141) |
| W1241 |        | Check condition of belt drive and replace if necessary; adjust belt tension.                                      | (→ Page 191) |
| W1463 |        | Check general condition of engine mounting (visual inspection).   | (→ Page 194) |
| W1714 | X      | Check and clean oil indicator filter.   | (→ Page 172) |

Table 1: Maintenance task reference table [QL1]

# 6 Troubleshooting

## 6.1 Troubleshooting

### Engine does not turn when starter is actuated

| Component                       | Probable cause  | Task  |
|---------------------------------|---|---|
| Battery                         | Low or defective  | Charge or replace (see manufacturer's documentation).                               |
|                                 | Cable connections defective                             | Check if cable connections are properly secured (see manufacturer's documentation). |
| Starter (electric)              | Engine wiring or starter defective                      | Check cable connections for secure seating,<br>Contact Service.                     |
| Starter (compressed air)        | Cabling on starting valve or starter defective          | Check cable connections for secure seating,<br>Contact Service.                     |
| Engine wiring                   | Defective   | Check (→ Page 195).   |
| Engine/generator control system | Secure seating of assemblies or connectors not provided | Perform visual inspection (see manufacturer's documentation).                       |
| Engine Governor                 | Plug-in connections are loose                           | Check plug connections (→ Page 197).  |
| Engine                          | Running gear blocked (engine cannot be barred manually) | Contact Service.  |

### Engine turns but does not fire

| Component                | Probable cause                                     | Task  |
|--------------------------|--|---|
| Starter (electric)       | Poor rotation by starter: Battery low or defective | Charge or replace battery (see manufacturer's documentation). |
| Starter (compressed air) | Poor rotation by starter: Air pressure too low     | Check compressed air system.                                  |
| Engine wiring            | Defective  | Check (→ Page 195).   |
| Fuel system              | Not vented   | Vent fuel system (→ Page 152).                                |
| Engine Governor          | Defective  | Contact Service.  |

### Engine fires unevenly

| Component                | Probable cause     | Task                           |
|--------------------------|--------------------|--------------------------------|
| Fuel injection equipment | Injector defective | Replace (→ Page 146).          |
| Engine wiring            | Defective          | Check (→ Page 195).            |
| Fuel system              | Not vented         | Vent fuel system (→ Page 152). |
| Engine Governor          | Defective          | Contact Service.               |

## Engine does not reach nominal speed

| Component                | Probable cause                  | Task  |
|--------------------------|---------------------------------|---|
| Fuel supply              | Fuel prefilter clogged          | Replace (→ Page 159).   |
|                          | Easy-change fuel filter clogged | Replace (→ Page 153).   |
| Air supply               | Air filter clogged              | Check signal ring position of service indicator (→ Page 165). |
| Fuel injection equipment | Injector defective              | Replace (→ Page 146).   |
| Engine wiring            | Defective                       | Check (→ Page 195).   |
| Engine                   | Overloaded                      | Contact Service.  |

## Engine speed not steady

| Component                | Probable cause     | Task                           |
|--------------------------|--------------------|--------------------------------|
| Fuel injection equipment | Injector defective | Replace (→ Page 146).          |
| Speed sensor             | Defective          | Contact Service.               |
| Fuel system              | Not vented         | Vent fuel system (→ Page 152). |
| Engine Governor          | Defective          | Contact Service.               |

## Charge-air temperature too high

| Component      | Probable cause                  | Task   |
|----------------|---------------------------------|--|
| Engine coolant | Incorrect coolant concentration | Check (MTU test kit).                          |
| Intercooler    | Contaminated                    | Contact Service.                               |
| Engine room    | Air-intake temperature too high | Check fans and air supply / ventilation ducts. |

## Charge air pressure too low

| Component            | Probable cause     | Task  |
|----------------------|--------------------|---|
| Air supply           | Air filter clogged | Check signal ring position of service indicator (→ Page 165). |
| Intercooler          | Contaminated       | Contact Service.  |
| Exhaust turbocharger | Defective          | Contact Service.  |

## Coolant leaks on intercooler

| Component   | Probable cause                   | Task             |
|-------------|----------------------------------|------------------|
| Intercooler | Leaking, major coolant discharge | Contact Service. |

## Exhaust gas black

| Component                | Probable cause     | Task  |
|--------------------------|--------------------|---|
| Air supply               | Air filter clogged | Check signal ring position of service indicator (→ Page 165). |
| Fuel injection equipment | Injector defective | Replace (→ Page 146).   |
| Engine                   | Overloaded         | Contact Service.  |

## Exhaust gas blue

| Component   | Probable cause                                   | Task                           |
|---|--|--------------------------------|
| Engine oil  | Too much engine oil in the engine                | Drain engine oil (→ Page 167). |
|   | Oil separator of crankcase breather contaminated | Replace (→ Page 138).          |
| Exhaust turbocharger, cylinder head, piston rings, cylinder liner | Defective  | Contact Service.               |

## Exhaust gas white

| Component   | Probable cause               | Task   |
|-------------|------------------------------|--|
| Engine      | Not at operating temperature | Run engine to reach operating temperature.                                 |
| Fuel system | Water in fuel                | Check fuel system on fuel prefilter.<br>Drain fuel prefilter (→ Page 156). |
| Intercooler | Leaking                      | Contact Service.   |

## 6.2 Engine governor ADEC (ECU 7) for Series 4000 genset engines – Fault messages

### 003 – HI T-Fuel

ZKP-Number: 2.0122.931

Limit value 1

| Cause                      | Corrective action  |
|----------------------------|--------------------|
| Fuel temperature too high. | ▶ Contact Service. |

### 004 – SS T-Fuel

ZKP-Number: 2.0122.932

Limit value 2

| Cause                                      | Corrective action  |
|--|--------------------|
| Fuel temperature too high;<br>Engine stop. | ▶ Contact Service. |

### 005 – HI T-Charge Air

ZKP-Number: 2.0121.931

Limit value 1

| Cause                            | Corrective action                         |
|----------------------------------|---|
| Charge-air temperature too high. | 1. Reduce power.<br>2. Check intercooler. |

### 006 – SS T-Charge Air

ZKP-Number: 2.0121.932

Limit value 2

| Cause   | Corrective action                         |
|---|---|
| Charge-air temperature too high<br>Engine stop. | 1. Reduce power.<br>2. Check intercooler. |

### 009 – HI T-Coolant Intercooler

ZKP-Number: 2.0124.931

Limit value 1

| Cause  | Corrective action |
|--|-------------------|
| Coolant temperature in intercooler too high. | ▶ Reduce power.   |

## 010 – SS T-Coolant Intercooler

ZKP-Number: 2.0124.932

Limit value 2

| Cause  | Corrective action |
|--|-------------------|
| Coolant temperature in intercooler too high;Engine stop. | ▶ Reduce power.   |

## 015 – LO P-Lube Oil

ZKP-Number: 2.0100.921

Limit value 1

| Cause                      | Corrective action                                    |
|----------------------------|--|
| Lube oil pressure too low. | ▶ Check oil level, top up as necessary (→ Page 169). |

## 016 – SS P-Lube Oil

ZKP-Number: 2.0100.922

Limit value 2

| Cause  | Corrective action   |
|--|---|
| Lube oil pressure too low;Automatic engine shutdown. | ▶ Engine must not be started (risk of engine failure), contact Service. |

## 019 – HI T-Exhaust A

ZKP-Number: 2.0126.931

Limit value 1

| Cause                                      | Corrective action                                    |
|--|--|
| Exhaust gas temperature (A-side) too high. | 1. Check wiring (→ Page 195).<br>2. Contact Service. |

## 020 – SS T-Exhaust A

ZKP-Number: 2.0126.932

Limit value 2

| Cause  | Corrective action                                    |
|--|--|
| Exhaust gas temperature (A-side) too high;Engine stop. | 1. Check wiring (→ Page 195).<br>2. Contact Service. |

## 021 – HI T-Exhaust B

ZKP-Number: 2.0127.931

Limit value 1

| Cause                                      | Corrective action                                    |
|--|--|
| Exhaust gas temperature (B-side) too high. | 1. Check wiring (→ Page 195).<br>2. Contact Service. |

## 022 – SS T-Exhaust B

ZKP-Number: 2.0127.932

Limit value 2

| Cause   | Corrective action                                    |
|---|--|
| Exhaust gas temperature (B-side) too high; Engine stop. | 1. Check wiring (→ Page 195).<br>2. Contact Service. |

## 023 – LO Coolant Level

ZKP-Number: 2.0152.921

Limit value 1

| Cause                  | Corrective action                                     |
|------------------------|---|
| Coolant level too low. | ▶ Check coolant level in expansion tank(→ Page 176) . |

## 025 – HI P-Diff. Lube Oil

ZKP-Number: 2.0154.931

Limit value 1

| Cause                                      | Corrective action                  |
|--|------------------------------------|
| Oil filter differential pressure too high. | ▶ Replace oil filter (→ Page 171). |

## 026 – SS P-Diff. Lube Oil

ZKP-Number: 2.0154.932

Limit value 2

| Cause                                      | Corrective action                  |
|--|------------------------------------|
| Oil filter differential pressure too high. | ▶ Replace oil filter (→ Page 171). |

## 027 – HI Level Leakage Fuel

ZKP-Number: 2.0151.931

Limit value 1

| Cause                     | Corrective action                            |
|---------------------------|--|
| Leak-fuel level too high. | 1. Check fuel system.<br>2. Contact Service. |

## 029 – HI ETC 2 Idle Speed too High

ZKP-Number: 1.8004.206

| Cause                         | Corrective action  |
|-------------------------------|--------------------|
| Idle speed of ETC 2 too high. | ▶ Contact Service. |

## 030 – SS Engine Overspeed

ZKP-Number: 2.2510.932

Limit value 2

| Cause                   | Corrective action                                      |
|-------------------------|--|
| Reduced fuel injection. | 1. Acknowledge alarm.<br>2. Attempt to restart engine. |

## 031 – HI ETC 1 Overspeed

ZKP-Number: 2.3011.931

Limit value 1

| Cause                                   | Corrective action  |
|---|--------------------|
| Speed of primary turbocharger too high. | ► Contact Service. |

## 032 – SS ETC 1 Overspeed

ZKP-Number: 2.3012.932

Limit value 2

| Cause                                   | Corrective action  |
|---|--|
| Speed of primary turbocharger too high. | 1. Automatic power reduction by engine control system.<br>2. Check air filters (→ Page 163). |

## 33 – HI P-Diff-Fuel

ZKP-Number: 20.114.931

Limit value 1

| Cause                                       | Corrective action                   |
|---|-------------------------------------|
| Fuel filter differential pressure too high. | ► Replace fuel filter (→ Page 153). |

## 34 – SS P-Diff-Fuel

ZKP-Number: 20.114.932

Limit value 2

| Cause                                       | Corrective action                   |
|---|-------------------------------------|
| Fuel filter differential pressure too high. | ► Replace fuel filter (→ Page 153). |

## 036 – HI ETC 2 Overspeed

ZKP-Number: 2.3013.931

Limit value 1

| Cause   | Corrective action                       |
|---|---|
| Speed of first secondary turbocharger too high. | 1. Reduce power.<br>2. Contact Service. |

## 037 – SS ETC 2 Overspeed

ZKP-Number: 2.3013.912

Limit value 2

| Cause   | Corrective action                       |
|---|---|
| Speed of first secondary turbocharger too high. | 1. Reduce power.<br>2. Contact Service. |

## 038 – AL ETC Speed Deviation

ZKP-Number: 1.8004.205

| Cause  | Corrective action                       |
|--|---|
| Synchro fault between primary turbocharger and one of the secondary turbochargers. | 1. Reduce power.<br>2. Contact Service. |

## 039 – AL ETC 2 Cutin Failure

ZKP-Number: 1.8004.204

| Cause                                | Corrective action                       |
|--------------------------------------|---|
| Cut-in of turbocharger ETC 2 failed. | 1. Reduce power.<br>2. Contact Service. |

## 044 – LO Coolant Level Intercooler

ZKP-Number: 2.0153.921

Limit value 1

| Cause                              | Corrective action                   |
|------------------------------------|-------------------------------------|
| Intercooler coolant level too low. | ▶ Check coolant level (→ Page 184). |

## 051 – HI T-Lube Oil

ZKP-Number: 2.0125.931

Limit value 1

| Cause                          | Corrective action |
|--------------------------------|-------------------|
| Lube oil temperature too high. | ▶ Reduce power.   |

## 052 – SS T-Lube Oil

ZKP-Number: 2.0125.932

Limit value 2

| Cause  | Corrective action   |
|--|---|
| Lube oil temperature too high.<br>Engine stop. | 1. Reduce power.<br>2. Check engine oil level (→ Page 169). |

## 057 – LO P-Coolant

ZKP-Number: 2.0101.921

Limit value 1

| Cause                     | Corrective action        |
|---------------------------|--------------------------|
| Coolant pressure too low. | ▶ Check coolant circuit. |

## 058 – SS P-Coolant

ZKP-Number: 2.0101.922

Limit value 2

| Cause   | Corrective action  |
|---|--|
| Coolant pressure too low;<br>Engine stop or reduced fuel injection. | <ol style="list-style-type: none"><li>1. Automatic engine shutdown.</li><li>2. Check coolant level (→ Page 176).</li></ol> |

## 59 – SS T-Coolant L3

ZKP-Number: 20.120.933

Limit value 3

| Cause                                | Corrective action   |
|--------------------------------------|---|
| Coolant temperature too high/<br>low | <ol style="list-style-type: none"><li>1. Allow engine to cool down.</li><li>2. Check engine coolant cooler, clean if dirty.</li><li>3. Contact Service.</li></ol> |

## 60 – SS T-Coolant L4

ZKP-Number: 20.120.934

Limit value 4

| Cause                                | Corrective action   |
|--------------------------------------|---|
| Coolant temperature too high/<br>low | <ol style="list-style-type: none"><li>1. Allow engine to cool down.</li><li>2. Check engine coolant cooler, clean if dirty.</li><li>3. Contact Service.</li></ol> |

## 063 – HI P-Crankcase

ZKP-Number: 2.0106.931

Limit value 1

| Cause                        | Corrective action   |
|------------------------------|---|
| Crankcase pressure too high. | <ol style="list-style-type: none"><li>1. Reduce power.</li><li>2. Replace oil separator element (→ Page 138).</li></ol> |

## 064 – SS P-Crankcase

ZKP-Number: 2.0106.932

Limit value 2

| Cause  | Corrective action   |
|--|---|
| Crankcase pressure too high;<br>Automatic engine shutdown. | ▶ Engine must not be started (risk of engine failure), contact Service. |

## 065 – LO P-Fuel

ZKP-Number: 2.0102.921

Limit value 1

| Cause                         | Corrective action   |
|-------------------------------|---|
| Fuel supply pressure too low. | <ol style="list-style-type: none"><li>1. Check fuel lines for leakage.</li><li>2. Clean fuel prefilter (→ Page 154).</li><li>3. Flush fuel prefilter (→ Page 157).</li><li>4. Replace filter element of fuel prefilter (→ Page 159).</li><li>5. Replace fuel filter (→ Page 153).</li></ol> |

## 066 – SS P-Fuel

ZKP-Number: 2.0102.922

Limit value 2

| Cause                                      | Corrective action   |
|--|---|
| Fuel supply pressure too low; Engine stop. | <ol style="list-style-type: none"><li>1. Check fuel lines for leakage.</li><li>2. Clean fuel prefilter (→ Page 154).</li><li>3. Flush fuel prefilter (→ Page 157).</li><li>4. Replace filter element of fuel prefilter (→ Page 159).</li><li>5. Replace fuel filter (→ Page 153).</li></ol> |

## 067 – HI T-Coolant

ZKP-Number: 2.0120.931

Limit value 1

| Cause                         | Corrective action |
|-------------------------------|-------------------|
| Coolant temperature too high. | ▶ Reduce power.   |

## 068 – SS T-Coolant

ZKP-Number: 2.0120.932

Limit value 2

| Cause   | Corrective action  |
|---|--|
| Coolant temperature too high;<br>Engine stop. | <ol style="list-style-type: none"><li>1. Allow engine to cool down.</li><li>2. Check engine coolant cooler, clean if dirty.</li><li>3. Restart engine (→ Page 69).</li><li>4. Contact Service.</li></ol> |

## 081 – AL Rail Leakage

ZKP-Number: 1.8004.046

| Cause   | Corrective action  |
|---|--------------------|
| Pressure gradient in rail is too low during starting or too high during stopping; HP system leaky, air in system. | ▶ Contact Service. |

## 082 – HI P-Fuel (Common Rail)

ZKP-Number: 2.0104.931

| Cause   | Corrective action  |
|---|--------------------|
| Rail pressure > set value; Speed-sensitive fuel limiter reduction, start of injection moved towards late; Suction restrictor of HP fuel block jamming or HP fuel control block wiring faulty. | ▶ Contact Service. |

## 083 – LO P-Fuel (Common Rail)

ZKP-Number: 2.0104.921

| Cause   | Corrective action  |
|---|--------------------|
| Rail pressure < set value; Speed-sensitive fuel limiter reduction; Suction restrictor of HP fuel control block faulty or leakage in HP fuel system. | ▶ Contact Service. |

## 085 – HI T-Umblasen

ZKP-Number: 2.0128.931

Limit value 1

| Cause                               | Corrective action |
|-------------------------------------|-------------------|
| Recirculation temperature too high. | ▶ Reduce power.   |

## 086 – SS T-Umblasen

ZKP-Number: 2.0128.932

Limit value 2

| Cause                               | Corrective action |
|-------------------------------------|-------------------|
| Recirculation temperature too high. | ▶ Reduce power.   |

## 089 – SS Engine Speed too Low

ZKP-Number: 2.2500.030

| Cause                 | Corrective action                |
|-----------------------|----------------------------------|
| Engine speed too low. | ▶ Check for additional messages. |

## 090 – SS Idle Speed Not Reached

ZKP-Number: 2.1090.925

| Cause                          | Corrective action  |
|--------------------------------|--------------------|
| Idling speed was not attained. | ▶ Contact Service. |

## 091 – SS Release Speed Not Reached

ZKP-Number: 2.1090.924

| Cause                         | Corrective action  |
|-------------------------------|--------------------|
| Runup speed was not attained. | ▶ Contact Service. |

## 092 – SS Starter Speed Not Reached

ZKP-Number: 2.1090.923

| Cause   | Corrective action  |
|---|--------------------|
| Starter speed was not attained; Termination of starting sequence; Starter rotates too slowly or does not rotate at all. | ▶ Contact Service. |

## 093 – SS T-Preheat

ZKP-Number: 2.1090.922

Limit value 2

| Cause  | Corrective action  |
|--|--------------------|
| Preheating temperature too low; coolant temperature too low for engine start; engine start interlock active. | ▶ Check preheater. |

## 094 – LO T-Preheat

ZKP-Number: 2.1090.921

Limit value 1

| Cause   | Corrective action  |
|---|--------------------|
| Preheating temperature too low; coolant temperature too low for engine start. | ▶ Check preheater. |

## 095 – AL Prelubrication Fault

ZKP-Number: 2.1090.920

| Cause              | Corrective action           |
|--------------------|-----------------------------|
| Oil priming fault. | ▶ Check oil priming system. |

## 102 – AL Fuel Cons. Counter Defect

ZKP-Number: 1.8004.624

| Cause                     | Corrective action  |
|---------------------------|--------------------|
| Consumption meter faulty. | ▶ Contact Service. |

## 104 – AL Eng Hours Counter Defect

ZKP-Number: 1.8004.623

| Cause              | Corrective action  |
|--------------------|--------------------|
| Hour meter faulty. | ▶ Contact Service. |

## 118 – LO ECU Power Supply Voltage

ZKP-Number: 2.0140.921

Limit value 1

| Cause                   | Corrective action                                   |
|-------------------------|---|
| Supply voltage too low. | 1. Check ECU supply voltage.<br>2. Contact Service. |

## 119 – LOLO ECU Power Supply Voltage

ZKP-Number: 2.0140.922

Limit value 2

| Cause                   | Corrective action                                   |
|-------------------------|---|
| Supply voltage too low. | 1. Check ECU supply voltage.<br>2. Contact Service. |

## 120 – HI ECU Power Supply Voltage

ZKP-Number: 2.0140.931

Limit value 1

| Cause                    | Corrective action                                   |
|--------------------------|---|
| Supply voltage too high. | 1. Check ECU supply voltage.<br>2. Contact Service. |

## 121 – HIHI ECU Power Supply Voltage

ZKP-Number: 2.0140.932

Limit value 2

| Cause                    | Corrective action                                   |
|--------------------------|---|
| Supply voltage too high. | 1. Check ECU supply voltage.<br>2. Contact Service. |

## 122 – HI T-ECU

ZKP-Number: 2.0132.921

Limit value 1

| Cause                                 | Corrective action                                       |
|---------------------------------------|---|
| Electronic unit temperature too high. | 1. Reduce power.<br>2. Improve engine room ventilation. |

## 141 – AL Power too high

ZKP-Number: 11.088.007

| Cause   | Corrective action |
|---|-------------------|
| Alarm is triggered if the mean value of the power has exceeded the maximum value stipulated by PR1.1088.001 within the last 24 hours. | ▶ Reduce power.   |

## 142 – AL MCR exceeded 1 hour

ZKP-Number: 1.1088.006

| Cause  | Corrective action |
|--|-------------------|
| the alarm is triggered if the MCR has been exceeded for more than 1 hour within the last 12 hours. | ▶ Reduce power.   |

## 176 – AL LifeData not available

ZKP-Number: 2.4000.004

| Cause   | Corrective action  |
|---|--------------------|
| No (appropriate) LifeData backup system available, ECU reset after expiration of time-out period. | ▶ Contact Service. |

## 177 – AL LifeData restore incomplete

ZKP-Number: 2.4000.006

| Cause   | Corrective action  |
|---|--------------------|
| this error message is generated if a CRC is faulty during a data upload to ADEC (indicated for each individual module). | ▶ Contact Service. |

## 180 – AL CAN1 Node Lost

ZKP-Number: 2.0500.680

| Cause                                     | Corrective action  |
|---|--------------------|
| Connection to a node on CAN bus 1 failed. | ▶ Contact Service. |

## 181 – AL CAN2 Node Lost

ZKP-Number: 2.0500.681

| Cause                                     | Corrective action  |
|---|--------------------|
| Connection to a node on CAN bus 2 failed. | ▶ Contact Service. |

## 182 – AL CAN Wrong Parameters

ZKP-Number: 2.0500.682

| Cause  | Corrective action  |
|--|--------------------|
| Incorrect parameter values entered in data record. | ▶ Contact Service. |

## 183 – AL CAN No PU-Data

ZKP-Number: 2.0500.683

| Cause   | Corrective action  |
|---|--------------------|
| The selected CAN mode initializes communication by means of the PU data module. However, the necessary PU data module is not present or is invalid. | ▶ Contact Service. |

## 184 – AL CAN PU-Data Flash Error

ZKP-Number: 2.0500.684

| Cause   | Corrective action  |
|---|--------------------|
| A programming error occurred when attempting to copy a received PU data module into the Flash module. | ▶ Contact Service. |

## 186 – AL CAN1 Bus Off

ZKP-Number: 2.0500.686

| Cause                                    | Corrective action   |
|--|---|
| CAN controller 1 is in "Bus-Off" status. | <ol style="list-style-type: none"><li>1. Check CAN bus for short circuit, rectify short circuit as necessary.</li><li>2. Check shielding, improve shielding as necessary.</li><li>3. Contact Service.</li></ol> |

## 187 – AL CAN1 Error Passive

ZKP-Number: 2.0500.687

| Cause                                     | Corrective action   |
|---|---|
| CAN controller 1 has indicated a warning. | <ol style="list-style-type: none"><li>1. Check CAN bus for short circuit, rectify short circuit as necessary.</li><li>2. Check shielding, improve shielding as necessary.</li><li>3. Contact Service.</li></ol> |

## 188 – AL CAN2 Bus Off

ZKP-Number: 2.0500.688

| Cause  | Corrective action   |
|--|---|
| CAN controller 2 is in "Bus-Off" status. => automatic changeover to CAN 1. Short circuit, massive interference or Baud rate incompatibility. | <ol style="list-style-type: none"><li>1. Check CAN bus for short circuit, rectify short circuit as necessary.</li><li>2. Check shielding, improve shielding as necessary.</li><li>3. Contact Service.</li></ol> |

## 189 – AL CAN2 Error Passive

ZKP-Number: 2.0500.689

| Cause                                     | Corrective action   |
|---|---|
| CAN controller 2 has indicated a warning. | <ol style="list-style-type: none"><li>1. Check CAN bus for short circuit, rectify short circuit as necessary.</li><li>2. Check shielding, improve shielding as necessary.</li><li>3. Contact Service.</li></ol> |

## 190 – AL EMU Parameter Not Supported

ZKP-Number: 2.0500.690

| Cause                             | Corrective action  |
|-----------------------------------|--------------------|
| EMU parameters are not supported. | ▶ Contact Service. |

## 201 – SD T-Coolant

ZKP-Number: 1.8004.570

| Cause   | Corrective action  |
|---|--|
| Coolant temperature sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B6), replace as necessary.<br>Error cleared after restarting the engine. |

## 202 – SD T-Fuel

ZKP-Number: 1.8004.572

| Cause  | Corrective action  |
|--|--|
| Fuel temperature sensor faulty; short circuit or wire break. | ▶ Check sensor and wiring (B33), replace as necessary.<br>Error cleared after restarting the engine. |

## 203 – SD T-Charge Air

ZKP-Number: 1.8004.571

| Cause  | Corrective action  |
|--|--|
| Charge-air temperature sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B9), replace as necessary.<br>Error cleared after restarting the engine. |

## 204 – SD Level Lube Oil

ZKP-Number: 1.8004.602

| Cause   | Corrective action                                 |
|---|---|
| Lube oil level sensor defective; short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary. |

## 205 – SD T-Coolant Intercooler

ZKP-Number: 1.8004.574

| Cause   | Corrective action  |
|---|--|
| Intercooler coolant temperature sensor faulty; short circuit or wire break. | ▶ Check sensor and wiring (B26), replace as necessary.<br>Error cleared after restarting the engine. |

## 206 – SD T-Exhaust A

ZKP-Number: 1.8004.576

| Cause   | Corrective action   |
|---|---|
| Exhaust temperature sensor on A-side faulty; short circuit or wire break. | ▶ Check sensor and cabling (B4.21), replace if necessary.<br>Error cleared after restarting the engine. |

## 207 – SD T-Exhaust B

ZKP-Number: 18.004.577

| Cause   | Corrective action   |
|---|---|
| Exhaust temperature sensor on B-side faulty. short circuit or wire break. | ▶ Check sensor and cabling (B4.22), replace as necessary. |

## 208 – SD P-Charge Air

ZKP-Number: 1.8004.566

| Cause   | Corrective action   |
|---|---|
| Charge-air pressure sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B10), replace as necessary.<br>Error cleared after restarting the engine. |

## 211 – SD P-Lube Oil

ZKP-Number: 1.8004.563

| Cause   | Corrective action  |
|---|--|
| Lube oil pressure sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B5), replace as necessary.<br>Error cleared after restarting the engine. |

## 212 – SD P-Coolant

ZKP-Number: 1.8004.564

| Cause  | Corrective action   |
|--|---|
| Coolant pressure sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B16), replace as necessary.<br>Error cleared after restarting the engine. |

## 213 – SD P-Coolant Intercooler

ZKP-Number: 1.8004.569

| Cause  | Corrective action   |
|--|---|
| Intercooler coolant pressure sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B43), replace as necessary.<br>Error cleared after restarting the engine. |

## 214 – SD P-Crankcase

ZKP-Number: 1.8004.568

| Cause  | Corrective action   |
|--|---|
| Crankcase pressure sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B50), replace as necessary.<br>Error cleared after restarting the engine. |

## 215 – SD P-HD

ZKP-Number: 1.8004.567

| Cause  | Corrective action   |
|--|---|
| Rail pressure sensor faulty;<br>High-pressure regulator in<br>emergency mode ==> Short<br>circuit or wire break. | ▶ Check sensor and cabling (B48), replace as necessary.<br>Error cleared after restarting the engine. |

## 216 – SD T-Lube Oil

ZKP-Number: 1.8004.575

| Cause   | Corrective action  |
|---|--|
| Lube oil temperature sensor<br>faulty; short circuit or wire break. | ▶ Check sensor and cabling (B7), replace as necessary.<br>Error cleared after restarting the engine. |

## 219 – SD T-Intake Air

ZKP-Number: 1.8004.573

| Cause   | Corrective action  |
|---|--|
| Intake air temperature sensor<br>faulty; short circuit or wire break. | ▶ Check sensor and cabling (B3), replace as necessary.<br>Error cleared after restarting the engine. |

## 220 – SD Level Coolant Water

ZKP-Number: 1.8004.584

| Cause  | Corrective action   |
|--|---|
| Coolant level sensor faulty; short<br>circuit or wire break. | ▶ Check sensor and cabling (F33), replace as necessary.<br>Error cleared after restarting the engine. |

## 221 – SD P-Diff Lube Oil

ZKP-Number: 1.8004.585

| Cause  | Corrective action   |
|--|---|
| Lube oil pressure differential<br>sensor faulty; short circuit or wire<br>break. | ▶ Check sensor and cabling (F25), replace as necessary.<br>Error cleared after restarting the engine. |

## 222 – SD Level Leakage Fuel

ZKP-Number: 1.8004.582

| Cause  | Corrective action   |
|--|---|
| Leak-off fuel level sensor faulty;<br>short circuit or wire break. | ▶ Check sensor and cabling (F46), replace as necessary.<br>Error cleared after restarting the engine. |

## 223 – SD Level Coolant Intercooler

ZKP-Number: 1.8004.583

| Cause   | Corrective action   |
|---|---|
| Sensor for intercooler coolant level faulty; short circuit or wire break. | ▶ Check sensor and cabling (F57), replace as necessary.<br>Error cleared after restarting the engine. |

## 227 – SD P-Lube Oil before Filter

ZKP-Number: 1.8004.620

| Cause   | Corrective action  |
|---|--|
| Sensor for lube oil pressure before filter faulty; short circuit or wire break. | ▶ Check sensor and cabling (B5.3), replace as necessary.<br>Error cleared after restarting the engine. |

## 228 – SD P-Fuel before Filter

ZKP-Number: 18.004.595

| Cause   | Corrective action  |
|---|--|
| Fuel pressure sensor faulty. short circuit or wire break. | ▶ Check sensor and cabling (B5.3), replace as necessary. |

## 229 – AL Stop Camshaft Sensor Defect

ZKP-Number: 1.8004.562

| Cause  | Corrective action   |
|--|---|
| Engine stop due to camshaft sensor fault (and a previous crankshaft sensor fault in the same operating cycle). | ▶ Check sensor and cabling to connector B1, replace as necessary.<br>Error cleared after restarting the engine. |

## 230 – SD Crankshaft Speed

ZKP-Number: 1.8004.498

| Cause  | Corrective action   |
|--|---|
| Crankshaft sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B13), replace as necessary.<br>Error cleared after restarting the engine. |

## 231 – SD Crankshaft Speed

ZKP-Number: 1.8004.499

| Cause  | Corrective action   |
|--|---|
| Camshaft sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B13), replace as necessary.<br>Error cleared after restarting the engine. |

## 232 – SD Charger 1 Speed

ZKP-Number: 1.3011.128

| Cause   | Corrective action   |
|---|---|
| Speed sensor of primary turbocharger faulty; short circuit or wire break. | ▶ Check sensor and cabling (B44.1), replace as necessary.<br>Error cleared after restarting the engine. |

## 233 – SD Charger 2 Speed

ZKP-Number: 1.3011.129

| Cause   | Corrective action   |
|---|---|
| Speed sensor of secondary turbocharger faulty; short circuit or wire break. | ▶ Check sensor and cabling (B44.2), replace as necessary.<br>Error cleared after restarting the engine. |

## 239 – SD P-Diff Fuel

ZKP-Number: 18.004.598

| Cause  | Corrective action               |
|--|---------------------------------|
| Fuel differential pressure sensor faulty.<br>This alarm occurs only in combination with the alarm SD P-Fuel before Filter or SD P-Fuel after Filter. | ▶ Check for additional message. |

## 240 – SD P-Fuel

ZKP-Number: 1.8004.565

| Cause   | Corrective action   |
|---|---|
| Fuel pressure sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B34), replace as necessary.<br>Error cleared after restarting the engine. |

## 241 – SD T-Umblasen

ZKP-Number: 1.8004.581

| Cause   | Corrective action   |
|---|---|
| Recirculation sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling (B49), replace as necessary.<br>Error cleared after restarting the engine. |

## 242 – SD T-Coolant (R)

ZKP-Number: 1.8004.622

| Cause  | Corrective action   |
|--|---|
| Redundant coolant pressure sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 244 – SD P-Lube Oil (R)

ZKP-Number: 1.8004.621

| Cause   | Corrective action   |
|---|---|
| Redundant lube oil pressure sensor faulty; short circuit or wire break. | ► Check sensor and cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 245 – SD ECU Power Supply Voltage

ZKP-Number: 2.8006.589

| Cause                                   | Corrective action              |
|---|--------------------------------|
| Internal ECU fault; Electronics faulty. | ► Replace Engine Control Unit. |

## 266 – SD Speed Demand

ZKP-Number: 2.8006.586

| Cause   | Corrective action                           |
|---|---|
| Analog speed setting faulty; short circuit or wire break. | 1. Check cabling.<br>2. Check speed demand. |

## 268 – SD Spinning Value

ZKP-Number: 28.006.591

| Cause   | Corrective action                                 |
|---|---|
| Analog wheel slip signal faulty; short circuit or wire break. | ► Check sensor and cabling, replace as necessary. |

## 269 – SD Loadp.Analog filt.

ZKP-Number: 2.8006.588

| Cause  | Corrective action  |
|--|--|
| Filtered analog signal of load pulse missing; short circuit or wire break. | ► Check cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 270 – SD Frequency Input

ZKP-Number: 2.8006.590

| Cause  | Corrective action  |
|--|--|
| Frequency input faulty; short circuit or wire break. | 1. Check cabling.<br>2. Check speed demand transmitter.<br>3. Contact Service. |

## 301 – AL Timing Cylinder A1

ZKP-Number: 1.8004.500

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 302 – AL Timing Cylinder A2

ZKP-Number: 1.8004.501

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 303 – AL Timing Cylinder A3

ZKP-Number: 1.8004.502

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 304 – AL Timing Cylinder A4

ZKP-Number: 1.8004.503

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 305 – AL Timing Cylinder A5

ZKP-Number: 1.8004.504

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 306 – AL Timing Cylinder A6

ZKP-Number: 1.8004.505

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 307 – AL Timing Cylinder A7

ZKP-Number: 1.8004.506

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 308 – AL Timing Cylinder A8

ZKP-Number: 1.8004.507

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 309 – AL Timing Cylinder A9

ZKP-Number: 1.8004.508

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 310 – AL Timing Cylinder A10

ZKP-Number: 1.8004.509

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

TIM-ID: 0000008506 - 002

## 311 – AL Timing Cylinder B1

ZKP-Number: 1.8004.510

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 312 – AL Timing Cylinder B2

ZKP-Number: 1.8004.511

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 313 – AL Timing Cylinder B3

ZKP-Number: 1.8004.512

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 314 – AL Timing Cylinder B4

ZKP-Number: 1.8004.513

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 315 – AL Timing Cylinder B5

ZKP-Number: 1.8004.514

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 316 – AL Timing Cylinder B6

ZKP-Number: 1.8004.515

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 317 – AL Timing Cylinder B7

ZKP-Number: 1.8004.516

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 318 – AL Timing Cylinder B8

ZKP-Number: 1.8004.517

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 319 – AL Timing Cylinder B9

ZKP-Number: 1.8004.518

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 320 – AL Timing Cylinder B10

ZKP-Number: 1.8004.519

| Cause  | Corrective action  |
|--|--|
| Time-of-flight measuring fault of injector: Time-of flight measured value extremely low or extremely high. | ► Replace injector concerned if the fault message appears frequently (→ Page 146). |

## 321 – AL Wiring Cylinder A1

ZKP-Number: 1.8004.520

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 322 – AL Wiring Cylinder A2

ZKP-Number: 1.8004.521

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 323 – AL Wiring Cylinder A3

ZKP-Number: 1.8004.522

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 324 – AL Wiring Cylinder A4

ZKP-Number: 1.8004.523

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 325 – AL Wiring Cylinder A5

ZKP-Number: 1.8004.524

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 326 – AL Wiring Cylinder A6

ZKP-Number: 1.8004.525

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 327 – AL Wiring Cylinder A7

ZKP-Number: 1.8004.526

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 328 – AL Wiring Cylinder A8

ZKP-Number: 1.8004.527

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 329 – AL Wiring Cylinder A9

ZKP-Number: 1.8004.528

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 330 – AL Wiring Cylinder A10

ZKP-Number: 1.8004.529

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 331 – AL Wiring Cylinder B1

ZKP-Number: 1.8004.530

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 332 – AL Wiring Cylinder B2

ZKP-Number: 1.8004.531

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 333 – AL Wiring Cylinder B3

ZKP-Number: 1.8004.532

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 334 – AL Wiring Cylinder B4

ZKP-Number: 1.8004.533

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 335 – AL Wiring Cylinder B5

ZKP-Number: 1.8004.534

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 336 – AL Wiring Cylinder B6

ZKP-Number: 1.8004.535

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 337 – AL Wiring Cylinder B7

ZKP-Number: 1.8004.536

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 338 – AL Wiring Cylinder B8

ZKP-Number: 1.8004.537

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 339 – AL Wiring Cylinder B9

ZKP-Number: 1.8004.538

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 340 – AL Wiring Cylinder B10

ZKP-Number: 1.8004.539

| Cause   | Corrective action                               |
|---|---|
| Short circuit in injector cabling to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 341 – AL Open Load Cylinder A1

ZKP-Number: 1.8004.540

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 342 – AL Open Load Cylinder A2

ZKP-Number: 1.8004.541

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 343 – AL Open Load Cylinder A3

ZKP-Number: 1.8004.542

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 344 – AL Open Load Cylinder A4

ZKP-Number: 1.8004.543

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 345 – AL Open Load Cylinder A5

ZKP-Number: 1.8004.544

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 346 – AL Open Load Cylinder A6

ZKP-Number: 1.8004.545

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 347 – AL Open Load Cylinder A7

ZKP-Number: 1.8004.546

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

### 348 – AL Open Load Cylinder A8

ZKP-Number: 1.8004.547

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 349 – AL Open Load Cylinder A9

ZKP-Number: 1.8004.548

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 350 – AL Open Load Cylinder A10

ZKP-Number: 1.8004.549

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 351 – AL Open Load Cylinder B1

ZKP-Number: 1.8004.550

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 352 – AL Open Load Cylinder B2

ZKP-Number: 1.8004.551

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 353 – AL Open Load Cylinder B3

ZKP-Number: 1.8004.552

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 354 – AL Open Load Cylinder B4

ZKP-Number: 1.8004.553

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 355 – AL Open Load Cylinder B5

ZKP-Number: 1.8004.554

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 356 – AL Open Load Cylinder B6

ZKP-Number: 1.8004.555

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 357 – AL Open Load Cylinder B7

ZKP-Number: 1.8004.556

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 358 – AL Open Load Cylinder B8

ZKP-Number: 1.8004.557

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 359 – AL Open Load Cylinder B9

ZKP-Number: 1.8004.558

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 360 – AL Open Load Cylinder B10

ZKP-Number: 1.8004.559

| Cause   | Corrective action                               |
|---|---|
| Open circuit in injector wiring to cylinder. Result: Misfiring. | 1. Check solenoid valve.<br>2. Contact Service. |

## 361 – AL Power Stage Low

ZKP-Number: 1.8004.496

| Cause  | Corrective action   |
|--|---|
| Internal electronic fault (electronics possibly faulty: start ITS). Check additional messages if ITS indicates diagnosis "Electronics OK" (e.g. cabling faulty). | 1. Check solenoid valve cabling.<br>2. Replace Engine Control Unit. |

## 362 – AL Power Stage high

ZKP-Number: 1.8004.497

| Cause  | Corrective action  |
|--|--|
| Internal electronic fault (electronics possibly faulty: start ITS). Check additional messages if ITS indicates diagnosis "Electronics OK" (e.g. cabling faulty). | <ol style="list-style-type: none"><li>1. Check solenoid valve cabling.</li><li>2. Replace Engine Control Unit.</li></ol> |

## 363 – AL Stop Power Stage

ZKP-Number: 1.8004.560

| Cause   | Corrective action   |
|---|---|
| Internal electronic fault (electronics possibly faulty: start ITS). | <ol style="list-style-type: none"><li>1. Check cabling.</li><li>2. Attempt to restart engine.</li></ol> |

## 365 – AL Stop MV-Wiring Ground

ZKP-Number: 1.8004.561

| Cause  | Corrective action   |
|--|---|
| Injector cabling fault. If bit "1.1020.021" (power stage failure: Stop engine) is set, engine is additionally stopped in this case. 1. Short circuit of injector + connection of one or more injectors to ground 2. Short circuit of injector – connection of one or more injectors to ground. | <ol style="list-style-type: none"><li>1. Check cabling.</li><li>2. Attempt to restart engine.</li></ol> |

## 371 – AL Wiring TO 1

ZKP-Number: 1.8004.634

| Cause  | Corrective action  |
|--|--|
| Short circuit or wire break on transistor output 1 (TO 1). | <ol style="list-style-type: none"><li>1. Check charger valve/cabling, repair as necessary.</li><li>2. Replace Engine Control Unit.</li></ol> |

## 372 – AL Wiring TO 2

ZKP-Number: 1.8004.635

| Cause  | Corrective action  |
|--|--|
| Short circuit or wire break on transistor output 2 (TO 2). | <ol style="list-style-type: none"><li>1. Check recirculation valve/cabling, repair as necessary.</li><li>2. Replace ECU.</li></ol> |

### 373 – AL Wiring TO 3

ZKP-Number: 1.8004.636

| Cause  | Corrective action |
|--|-------------------|
| Short circuit or wire break on transistor output 3 (TO 3). | ▶ -               |

### 374 – AL Wiring TO 4

ZKP-Number: 1.8004.637

| Cause  | Corrective action |
|--|-------------------|
| Short circuit or wire break on transistor output 4 (TO 4). | ▶ -               |

### 381 – AL Wiring TOP 1

ZKP-Number: 2.8006.638

| Cause   | Corrective action         |
|---|---------------------------|
| Short circuit or wire break on transistor output, plant-side 1 (TOP 1). | ▶ Check cabling to plant. |

### 382 – AL Wiring TOP 2

ZKP-Number: 2.8006.639

| Cause   | Corrective action         |
|---|---------------------------|
| Short circuit or wire break on transistor output, plant-side 2 (TOP 2). | ▶ Check cabling to plant. |

### 383 – AL Wiring TOP 3

ZKP-Number: 2.8006.640

| Cause   | Corrective action         |
|---|---------------------------|
| Short circuit or wire break on transistor output, plant-side 3 (TOP 3). | ▶ Check cabling to plant. |

### 384 – AL Wiring TOP 4

ZKP-Number: 2.8006.641

| Cause   | Corrective action         |
|---|---------------------------|
| Short circuit or wire break on transistor output, plant-side 4 (TOP 4). | ▶ Check cabling to plant. |

### 390 – AL MCR exceeded

ZKP-Number: 1.1085.009

| Cause                           | Corrective action   |
|---------------------------------|---|
| DBR/MCR function: MCR exceeded. | 1. No action required if alarm only applied temporarily.<br>2. Contact Service if alarm applied constantly. |

### 392 – HI T-Coolant Red

ZKP-Number: 2.0129.931

Limit value 1

| Cause   | Corrective action                        |
|---|--|
| Redundant coolant temperature reading too high. | 1. Check cabling.<br>2. Contact Service. |

### 393 – SS T-Coolant Red

ZKP-Number: 2.0129.932

Limit value 2

| Cause  | Corrective action                                   |
|--|---|
| Redundant coolant temperature reading too high; Engine stop. | 1. Check cabling and sensor.<br>2. Contact Service. |

### 394 – LO P-Lube Oil Red

ZKP-Number: 2.0112.921

Limit value 1

| Cause  | Corrective action                                   |
|--|---|
| Redundant lube oil pressure reading too low. | 1. Check cabling and sensor.<br>2. Contact Service. |

### 395 – SS P-Lube Oil Red

ZKP-Number: 2.0112.922

Limit value 2

| Cause  | Corrective action                                   |
|--|---|
| Redundant lube oil pressure reading too low. | 1. Check cabling and sensor.<br>2. Contact Service. |

### 396 – TD T-Coolant Sensor Deviation

ZKP-Number: 1.0480.193

| Cause                                  | Corrective action                                   |
|--|---|
| Maximum coolant temperature deviation. | 1. Check cabling and sensor.<br>2. Contact Service. |

## 397 – TD P-Oil Sensor Deviation

ZKP-Number: 1.0480.293

| Cause                                | Corrective action                                   |
|--------------------------------------|---|
| Maximum lube oil pressure deviation. | 1. Check cabling and sensor.<br>2. Contact Service. |

## 400 – AL Open Load Digital Input 1

ZKP-Number: 2.8006.625

| Cause  | Corrective action   |
|--|---|
| Line disruption on digital input 1; Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 401 – AL Open Load Digital Input 2

ZKP-Number: 2.8006.626

| Cause  | Corrective action   |
|--|---|
| Line disruption on digital input 2; Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 402 – AL Open Load Digital Input 3

ZKP-Number: 2.8006.627

| Cause  | Corrective action   |
|--|---|
| Line disruption on digital input 3; Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 403 – AL Open Load Digital Input 4

ZKP-Number: 2.8006.628

| Cause  | Corrective action   |
|--|---|
| Line disruption on digital input 4; Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 404 – AL Open Load Digital Input 5

ZKP-Number: 2.8006.629

| Cause  | Corrective action   |
|--|---|
| Line disruption on digital input 5; Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 405 – AL Open Load Digital Input 6

ZKP-Number: 2.8006.630

| Cause   | Corrective action   |
|---|---|
| Line disruption on digital input 6;<br>Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 406 – AL Open Load Digital Input 7

ZKP-Number: 2.8006.631

| Cause   | Corrective action   |
|---|---|
| Line disruption on digital input 7;<br>Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 407 – AL Open Load Digital Input 8

ZKP-Number: 2.8006.632

| Cause   | Corrective action   |
|---|---|
| Line disruption on digital input 8;<br>Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 408 – AL Open Load Emerg. Stop Input ESI

ZKP-Number: 2.8006.633

| Cause   | Corrective action   |
|---|---|
| Line disruption on the input for emergency stop; Cabling faulty or no resistance over switch. | 1. Check cabling.<br>2. Check target device input.<br>3. Contact Service. |

## 410 – LO U-PDU

ZKP-Number: 2.0141.921

Limit value 1

| Cause                     | Corrective action  |
|---------------------------|--|
| Injector voltage too low. | 1. Check cabling.<br>2. Check supply.<br>3. Contact Service. |

## 411 – LOLO U-PDU

ZKP-Number: 2.0141.922

Limit value 2

| Cause                     | Corrective action  |
|---------------------------|--|
| Injector voltage too low. | 1. Check cabling.<br>2. Check supply.<br>3. Contact Service. |

## 412 – HI U-PDU

ZKP-Number: 2.0141.931

Limit value 1

| Cause                      | Corrective action  |
|----------------------------|--|
| Injector voltage too high. | <ol style="list-style-type: none"><li>1. Check cabling.</li><li>2. Check supply.</li><li>3. Contact Service.</li></ol> |

## 413 – HIHI U-PDU

ZKP-Number: 2.0141.932

Limit value 2

| Cause                      | Corrective action  |
|----------------------------|--|
| Injector voltage too high. | <ol style="list-style-type: none"><li>1. Check cabling.</li><li>2. Check supply.</li><li>3. Contact Service.</li></ol> |

## 414 – HI Level Water Fuel Prefilter

ZKP-Number: 2.0156.931

Limit value 1

| Cause                                   | Corrective action           |
|---|-----------------------------|
| Water level in fuel prefilter too high. | ► Drain water (→ Page 156). |

## 415 – LO P-Coolant Intercooler

ZKP-Number: 2.0107.921

Limit value 1

| Cause                                    | Corrective action              |
|--|--------------------------------|
| Coolant pressure in intercooler too low. | ► Top up coolant (→ Page 187). |

## 416 – SS P-Coolant Intercooler

ZKP-Number: 2.0107.922

Limit value 2

| Cause   | Corrective action              |
|---|--------------------------------|
| Coolant pressure in intercooler too low; Engine stop. | ► Top up coolant (→ Page 187). |

## 417 – SD Level Water Fuel Prefilter

ZKP-Number: 1.8004.594

| Cause   | Corrective action   |
|---|---|
| Sensor for water level in fuel prefilter faulty; short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 419 – SD T-Coolant b.Engine

ZKP-Number: 18.004.604

| Cause   | Corrective action                                      |
|---|--|
| Coolant inlet temperature sensor faulty. short circuit or wire break. | ▶ Check sensor and cabling (B3), replace as necessary. |

## 420 – AL L1 Aux 1

ZKP-Number: 2.0160.921

Limit value 1

| Cause  | Corrective action   |
|--|---|
| Input signal of Aux 1 has exceeded/not attained limit value 1, depending on configuration. | ▶ Determine cause of limit value violation and rectify fault. |

## 421 – AL L2 Aux 1

ZKP-Number: 2.0160.922

Limit value 2

| Cause  | Corrective action   |
|--|---|
| Input signal of Aux 1 has exceeded/not attained limit value 2, depending on configuration. | ▶ Determine cause of limit value violation and rectify fault. |

## 428 – AL L1 T-Aux 1

ZKP-Number: 2.0130.921

Limit value 1

| Cause  | Corrective action   |
|--|---|
| Temperature signal of Aux 1 has exceeded / not attained limit value 1, depending on configuration. | ▶ Determine cause of limit value violation and rectify fault. |

## 430 – LO P-Coolant before Engine

ZKP-Number: 20.168.921

Limit value 1

| Cause                     | Corrective action        |
|---------------------------|--------------------------|
| Coolant pressure too low. | ▶ Check coolant circuit. |

## 431 – SS P-Coolant before Engine

ZKP-Number: 20.168.922

Limit value 2

| Cause                     | Corrective action        |
|---------------------------|--------------------------|
| Coolant pressure too low. | ▶ Check coolant circuit. |

## 434 – HI T-Coolant before Engine

ZKP-Number: 20.173.931

Limit value 1

| Cause                         | Corrective action        |
|-------------------------------|--------------------------|
| Coolant temperature too high. | ▶ Check coolant circuit. |

## 435 – SS T-Coolant before Engine

ZKP-Number: 20.173.932

Limit value 2

| Cause                         | Corrective action        |
|-------------------------------|--------------------------|
| Coolant temperature too high. | ▶ Check coolant circuit. |

## 440 – AL L1 P-Aux 1

ZKP-Number: 2.0110.921

Limit value 1

| Cause   | Corrective action   |
|---|---|
| Pressure signal of Aux 1 has exceeded / not attained limit value 1, depending on configuration. | ▶ Determine cause of limit value violation and rectify fault. |

## 442 – AL L2 P-Aux 1

ZKP-Number: 2.0110.931

Limit value 2

| Cause   | Corrective action   |
|---|---|
| Pressure signal of Aux 1 has exceeded / not attained limit value 2, depending on configuration. | ▶ Determine cause of limit value violation and rectify fault. |

## 444 – SD U-PDU

ZKP-Number: 1.8004.578

| Cause  | Corrective action              |
|--|--------------------------------|
| Injector power stage sensor defect; Internal fault in ECU. | ► Replace Engine Control Unit. |

## 445 – SD P-Ambient Air

ZKP-Number: 1.8004.580

| Cause                               | Corrective action              |
|-------------------------------------|--------------------------------|
| Ambient air pressure sensor faulty. | ► Replace Engine Control Unit. |

## 448 – HI P-Charge Air

ZKP-Number: 2.0103.931

Limit value 1

| Cause                         | Corrective action  |
|-------------------------------|--------------------|
| Charge-air pressure too high. | ► Contact Service. |

## 449 – SS P-Charge Air

ZKP-Number: 2.0103.932

Limit value 2

| Cause                         | Corrective action  |
|-------------------------------|--------------------|
| Charge-air pressure too high. | ► Contact Service. |

## 450 – SD Idle/End-Torque Input [%]

ZKP-Number: 2.8006.592

| Cause  | Corrective action   |
|--|---|
| Input signal for initial/final torque faulty; short circuit or wire break. | ► Check signal transmitter and cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 454 – SS Power Reduction Active

ZKP-Number: 2.7000.011

| Cause                      | Corrective action  |
|----------------------------|--|
| Power reduction is active. | 1. Note further fault messages.<br>2. Determine cause of power reduction and rectify fault |

## 455 – AL L1 Aux1 Plant

ZKP-Number: 2.8006.650

Limit value 1

| Cause   | Corrective action   |
|---|---|
| Input signal of Aux 1 (plant side) has exceeded/not attained limit value 1, depending on configuration. | ► Determine cause of limit value violation and rectify fault. |

## 456 – AL L2 Aux1 Plant

ZKP-Number: 2.8006.651

Limit value 2

| Cause   | Corrective action   |
|---|---|
| Input signal of Aux 1 (plant side) has exceeded/not attained limit value 2, depending on configuration. | ► Determine cause of limit value violation and rectify fault. |

## 460 – HI T-Exhaust EMU

ZKP-Number: 2.8006.652

Limit value 1

| Cause                                       | Corrective action                        |
|---|--|
| EMU exhaust gas temperature value too high. | 1. Check cabling.<br>2. Contact Service. |

## 461 – LO T-Exhaust EMU

ZKP-Number: 2.8006.653

Limit value 1

| Cause                                      | Corrective action                        |
|--|--|
| EMU exhaust gas temperature value too low. | 1. Check cabling.<br>2. Contact Service. |

## 462 – HI T-Coolant EMU

ZKP-Number: 2.8006.654

Limit value 1

| Cause   | Corrective action                  |
|---|------------------------------------|
| EMU coolant temperature value too high / low. | ► Check configuration with DiaSys. |

TIM-ID: 0000008506 - 002

## 464 – SD P-AUX 1

ZKP-Number: 1.8004.589

| Cause   | Corrective action   |
|---|---|
| Analog input signal for Aux 1 pressure faulty; short circuit or wire break. | ▶ Check pressure transmitter and cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 467 – AL L2 T-Aux 1

ZKP-Number: 2.0130.922

Limit value 2

| Cause  | Corrective action   |
|--|---|
| Temperature signal of Aux 1 has exceeded / not attained limit value 2, depending on configuration. | ▶ Determine cause of limit value violation and rectify fault. |

## 468 – SD T-AUX 1

ZKP-Number: 1.8004.579

| Cause                                      | Corrective action              |
|--|--------------------------------|
| Analog input for Aux 1 temperature faulty. | ▶ Replace Engine Control Unit. |

## 469 – SD AUX 1

ZKP-Number: 1.8004.590

| Cause  | Corrective action   |
|--|---|
| Analog input signal for Aux 1 faulty; short circuit or wire break. | ▶ Check signal transmitter and cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 470 – SD T-ECU

ZKP-Number: 1.8004.587

| Cause   | Corrective action   |
|---|---|
| Temperature sensor for ECU faulty; short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 471 – SD Coil Current

ZKP-Number: 1.8004.592

| Cause   | Corrective action   |
|---|---|
| Control of HP fuel control block faulty; short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary.<br>Error cleared after restarting the engine. |

## 472 – AL Stop SD

ZKP-Number: 2.8006.593

| Cause  | Corrective action                        |
|--|--|
| Engine stop, since all shutdown channels have "sensor faulty". | 1. Check cabling.<br>2. Contact Service. |

## 473 – AL Wiring PWM\_CM2

ZKP-Number: 1.8004.593

| Cause  | Corrective action                        |
|--|--|
| Cable break or short circuit on channel PWM_CM2. | 1. Check cabling.<br>2. Contact Service. |

## 474 – AL Wiring FO

ZKP-Number: 2.8006.655

| Cause                                       | Corrective action                        |
|---|--|
| Cable break or short circuit on channel FO. | 1. Check cabling.<br>2. Contact Service. |

## 475 – AL CR Trigger Engine Stop

ZKP-Number: 1.8010.009

| Cause  | Corrective action  |
|--|--|
| Tripped by crash recorder triggering due to engine shutdown. | ► Determine and rectify cause of triggering / engine shutdown. |

## 476 – AL Crash Rec. Init. Error

ZKP-Number: 1.8010.007

| Cause                                   | Corrective action             |
|---|-------------------------------|
| Initialization error of crash recorder. | ► Check settings with DiaSys. |

## 478 – AL Comb. Alarm Yel (Plant)

ZKP-Number: 2.8006.001

| Cause                             | Corrective action            |
|-----------------------------------|------------------------------|
| Combined alarm YELLOW from plant. | ► Check additional messages. |

TIM-ID: 0000008506 - 002

## 479 – AL Comb. Alarm Red (Plant)

ZKP-Number: 2.8006.002

| Cause                          | Corrective action            |
|--------------------------------|------------------------------|
| Combined alarm RED from plant. | ▶ Check additional messages. |

## 480 – AL Ext. Engine Protection

ZKP-Number: 20.291.921

| Cause                                       | Corrective action  |
|---|--|
| External engine protection function active. | ▶ Monitoring of plant signal by ECU active (plant side). Check plant signal. |

## 482 – SD T-Exhaust C

ZKP-Number: 18.004.596

| Cause   | Corrective action   |
|---|---|
| Exhaust temperature sensor on A side faulty. short circuit or wire break. | ▶ Check sensor and cabling (B4.23), replace as necessary. |

## 483 – SD T-Exhaust D

ZKP-Number: 18.004.597

| Cause   | Corrective action   |
|---|---|
| Exhaust temperature sensor on A side faulty. short circuit or wire break. | ▶ Check sensor and cabling (B4.24), replace as necessary. |

## 484 – HI T-Exhaust C

ZKP-Number: 20.133.931

Limit value 1

| Cause                                      | Corrective action                       |
|--|---|
| Exhaust gas temperature (C-side) too high. | 1. Reduce power.<br>2. Contact Service. |

## 485 – SS T-Exhaust C

ZKP-Number: 20.133.932

Limit value 2

| Cause                                      | Corrective action                       |
|--|---|
| Exhaust gas temperature (C-side) too high. | 1. Reduce power.<br>2. Contact Service. |

## 486 – HI T-Exhaust D

ZKP-Number: 20.134.931

Limit value 1

| Cause                                      | Corrective action                       |
|--|---|
| Exhaust gas temperature (D-side) too high. | 1. Reduce power.<br>2. Contact Service. |

## 487 – SS T-Exhaust D

ZKP-Number: 20.134.932

Limit value 2

| Cause                                      | Corrective action                       |
|--|---|
| Exhaust gas temperature (D-side) too high. | 1. Reduce power.<br>2. Contact Service. |

## 488 – HI ETC3 Overspeed

ZKP-Number: 23.014.931

Limit value 1

| Cause  | Corrective action |
|--|-------------------|
| Speed of second secondary turbocharger too high. | ▶ Reduce power.   |

## 489 – SS ETC3 Overspeed

ZKP-Number: 23.014.932

Limit value 2

| Cause  | Corrective action |
|--|-------------------|
| Speed of second secondary turbocharger too high. | ▶ Reduce power.   |

## 490 – HI ETC4 Overspeed

ZKP-Number: 23.015.931

Limit value 1

| Cause   | Corrective action |
|---|-------------------|
| Speed of the 3rd secondary turbocharger too high. | ▶ Reduce power.   |

## 491 – SS ETC4 Overspeed

ZKP-Number: 23.015.932

Limit value 2

| Cause   | Corrective action |
|---|-------------------|
| Speed of the 3rd secondary turbocharger too high. | ▶ Reduce power.   |

## 492 – AL ETC4 Cutin Failure

ZKP-Number: 18.004.202

| Cause                  | Corrective action                        |
|------------------------|--|
| ETC4 failed to cut in. | ▶ Check control valve at turbocharger 4. |

## 493 – AL ETC3 Cutin Failure

ZKP-Number: 18.004.203

| Cause                  | Corrective action                        |
|------------------------|--|
| ETC3 failed to cut in. | ▶ Check control valve at turbocharger 3. |

## 500 – AL Wiring POM Starter 1

ZKP-Number: 14.500.900

| Cause  | Corrective action                           |
|--|---|
| A cabling fault in connection of starter 1 of CPM has been detected. This may be due to a missing consumer, wire break or a short circuit. | ▶ Check connection between POM and starter. |

## 501 – AL Wiring POM Starter 2

ZKP-Number: 14.500.901

| Cause  | Corrective action                           |
|--|---|
| A cabling fault in connection of starter 2 of CPM has been detected. This may be due to a missing consumer, wire break or a short circuit. | ▶ Check connection between POM and starter. |

## 502 – AL Open Load POM Alternator

ZKP-Number: 14.500.902

| Cause  | Corrective action  |
|--|--|
| A line interruption was detected at the battery-charging connection for the POM. | ▶ Check connection between POM and battery-charging generator. |

## 503 – AL Battery Not Charging

ZKP-Number: 14.500.903

| Cause   | Corrective action                               |
|---|---|
| Battery is not charged by battery-charging generator. | ▶ Check battery-charging generator and cabling. |

## 504 – AL CAN POM Node Lost

ZKP-Number: 14.500.904

| Cause                   | Corrective action           |
|-------------------------|-----------------------------|
| POM missing on CAN bus. | ▶ Check connection and POM. |

## 506 – AL Low Starter Voltage

ZKP-Number: 14.500.906

| Cause  | Corrective action                    |
|--|--------------------------------------|
| The battery voltage is too low for the starting process. | ▶ Check starter battery and cabling. |

## 507 – AL POM Error

ZKP-Number: 14.500.907

| Cause                         | Corrective action |
|-------------------------------|-------------------|
| A general POM fault occurred. | ▶ Replace POM.    |

## 508 – AL Wrong POM-ID

ZKP-Number: 14.500.908

| Cause  | Corrective action           |
|--|-----------------------------|
| POM sends a different ID number than expected. | ▶ Check POM wiring harness. |

## 510 – AL Override applied

ZKP-Number: 27.002.010

| Cause                   | Corrective action                       |
|-------------------------|---|
| Override was activated. | ▶ Deactivate Override pushbutton again. |

## 515 – AL Starter Not Engaged

ZKP-Number: 21.090.926

| Cause   | Corrective action   |
|---|---|
| Starter on CPM / POM could not be engaged. If the number of automatic start attempts from PR 2.1090.134 Number of Start Attempts is used up then start is canceled. Check CPM, starter and cabling. | <ol style="list-style-type: none"><li>1. Repeat starting attempt</li><li>2. Check CPM, starter and cabling.</li></ol> |

## 519 – Oillevel Calibration Error

ZKP-Number: 10.158.921

| Cause  | Corrective action  |
|--|--|
| Error when writing the calibration value to flash memory or level sensor defect. | <ol style="list-style-type: none"><li>1. Check sensor and cabling, replace as necessary.</li><li>2. Contact Service.</li></ol> |

## 521 – SS P-Lube Oil Mid Val

ZKP-Number: 20.480.289

Limit value 1

| Cause   | Corrective action                       |
|---|---|
| Average oil pressure value from three sources is too low. | ▶ Check oil level, top up as necessary. |

## 523 – SS T-Coolant Red Mid Val

ZKP-Number: 20.480.189

Limit value 2

| Cause   | Corrective action |
|---|-------------------|
| Average coolant temperature value from three sources is too high. | ▶ Reduce power.   |

## 524 – SS Engine Overspeed Mid Val

ZKP-Number: 20.480.089

Limit value 2

| Cause  | Corrective action   |
|--|---|
| Average engine overspeed value from three sources is too high. | <ol style="list-style-type: none"><li>1. Acknowledge alarm.</li><li>2. Attempt to restart engine.</li></ol> |

## 525 – SD P-Lube Oil (R2)

ZKP-Number: 18.004.638

| Cause   | Corrective action                                 |
|---|---|
| Redundant lube-oil pressure sensor faulty. short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary. |

## 526 – SD T-Coolant (R2)

ZKP-Number: 18.004.639

| Cause  | Corrective action                                 |
|--|---|
| Redundant coolant pressure sensor faulty. short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary. |

## 527 – TD EngineSpd. Sensor Deviation

ZKP-Number: 10.480.093

| Cause                              | Corrective action  |
|------------------------------------|--|
| Maximum deviation of speed sensors | <ol style="list-style-type: none"><li>1. Check speed sensor cabling.</li><li>2. Check for additional messages.</li><li>3. Contact Service.</li></ol> |

## 528 – SD Engine Speed 3rd Sensor

ZKP-Number: 12.500.102

| Cause  | Corrective action                                 |
|--|---|
| Redundant crankshaft speed sensor faulty; short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary. |

## 529 – SS T-Coolant Red2

ZKP-Number: 20.480.195

Limit value 2

| Cause  | Corrective action        |
|--|--------------------------|
| Second redundant coolant temperature too high. | ▶ Check coolant circuit. |

## 530 – SS P-Lube Oil Red2

ZKP-Number: 20.480.295

Limit value 2

| Cause  | Corrective action                       |
|--|---|
| Second redundant lube-oil pressure too high. | ▶ Check oil level, top up as necessary. |

## 543 – AL Multiple FDH Slaves

ZKP-Number: 20.555.005

| Cause   | Corrective action  |
|---|--------------------|
| There is more than one device activated as backup medium for FDH. | ▶ Contact Service. |

## 544 – AL Configuration Changed

ZKP-Number: 20.555.003

| Cause  | Corrective action  |
|--|--|
| This fault becomes active in cases in which the system configuration has been changed, e.g. due to replacement of an ECU or a SAM. | ▶ Fault remains active until changes are revoked or data have been transferred by active maintenance. Fault is then automatically cleared. |

## 549 – AL Power Cut-Off detected

ZKP-Number: 27.001.952

This is an alarm from the emergency stop counter function.

| Cause  | Corrective action   |
|--|---|
| ECU operating voltage was switched off while the engine was running. This may lead to overpressure in the HP system which can damage the engine. | ► Instruct operators to switch off the power supply only after the engine has come to a standstill. |

## 550 – SS Engine Overspeed Red2

ZKP-Number: 20.480.095

Limit value 2

| Cause                       | Corrective action                                      |
|-----------------------------|--|
| Redundant engine overspeed. | 1. Acknowledge alarm.<br>2. Attempt to restart engine. |

## 551 – SS Engine Overspeed Camshaft

ZKP-Number: 22.510.933

Limit value 2

| Cause               | Corrective action                                      |
|---------------------|--|
| Camshaft overspeed. | 1. Acknowledge alarm.<br>2. Attempt to restart engine. |

## 555 – AL Call MTU Field Service

ZKP-Number: 20.555.001

| Cause   | Corrective action                     |
|---|---------------------------------------|
| This fault becomes active if a maintenance case has been processed by the ECU Field Data Handling (FDH) feature that results in a change of engine parameters.<br>This fault remains active even after switching off and back on until a valid enabling code is entered via the SAM display and key controls. This enabling code can be requested via the internet using a special procedure. | ► Request enabling code via internet. |

## 576 – AL ESCM Override

ZKP-Number: 11.075.083

| Cause   | Corrective action |
|---|-------------------|
| Violation of corrected MCR or DBR/MCR curve. Engine overload! | ▶ Reduce power.   |

## 577 – SD T-Lube Oil Pan

ZKP-Number: 10.137.900

| Cause   | Corrective action                                 |
|---|---|
| Oil pan temperature sensor faulty. Short circuit or wire break. | ▶ Check sensor and cabling, replace as necessary. |

## 578 – AL L1 T-Lube Oil Pan

ZKP-Number: 20.137.921

Limit value 1

| Cause   | Corrective action |
|---|-------------------|
| L1 T-Lube Oil Pan has violated limit value 1. | ▶                 |

## 579 – AL MD Forced Idle

ZKP-Number: 21.063.511

| Cause   | Corrective action |
|---|-------------------|
| MD forced idle demand => node failure (node 3,4 or 5) | ▶                 |

## 580 – AL MD Request Speed Limit

ZKP-Number: 21.063.513

| Cause  | Corrective action |
|--|-------------------|
| MD speed limitation demand => node failure (node 3,4 or 5) | ▶                 |

## 581 – AL MD CAN Stop

ZKP-Number: 21.063.515

| Cause  | Corrective action |
|--|-------------------|
| MD CAN stop demand => node failure (node 3,4 or 5) | ▶                 |

TIM-ID: 0000008506 - 002

# 7 Task Description

## 7.1 Engine

### 7.1.1 Engine – Barring manually

#### Preconditions

- ☑ Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use      | Part No.  | Qty. |
|------------------------|-----------|------|
| Barring device         | F6555766  | 1    |
| Ratchet with extension | F30006212 | 1    |

DANGER




Unguarded rotating and moving engine components.

**Risk of serious injury – Danger to life!**

- Before barring the engine, ensure that nobody is in the danger zone.

#### Engine – Barring manually

1. Remove guard plate.
2. Engage barring device (2) with ring gear (3) and install on flywheel housing.
3. Place ratchet (1) onto barring device (2).
4. Rotate crankshaft in engine direction of rotation. Apart from the normal compression resistance, there should be no further resistance.
5. For barring device removal, follow reverse sequence of working steps.



## 7.1.2 Engine – Barring with starting system

DANGER



Unguarded rotating and moving engine components.

**Risk of serious injury – danger to life!**

- Before barring or starting the engine, ensure that nobody is in the danger zone.
- After working on the engine, check that all protective devices have been reinstalled and all tools removed from the engine.

### Engine – Barring with starting system

1. Release latch of connector X4.
2. Remove connector from engine governor.
3. Bar engine in unloaded condition: Press START button.
4. Let the crankshaft rotate until oil pressure is indicated.
5. Engine start is automatically interrupted when specified starting period has passed. If necessary, re-start the engine after approx. 20 seconds.
6. Connect connector X4 to engine governor and latch in position.

### 7.1.3 Engine – Test run

#### DANGER



Unguarded rotating and moving engine components.

**Risk of serious injury – danger to life!**

- Before barring or starting the engine, make sure that nobody is in the danger zone.

#### WARNING



Engine noise above 85 dB (A).

**Risk of damage to hearing!**

- Wear ear protectors.

### Engine – Test run

1. Start engine (→ Page 69).
2. Perform test run not below 1/3 load and at least until steady-state temperature is reached.
3. Carry out operational checks (→ Page 72).
4. Stop engine (→ Page 73).

## 7.2 Cylinder Liner

### 7.2.1 Cylinder liner – Endoscopic examination

#### Preconditions

- Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use | Part No.  | Qty. |
|-------------------|-----------|------|
| Rigid endoscope   | Y20097353 | 1    |

#### Preparatory steps

1. Remove cylinder head cover (→ Page 144).
2. Remove injector (→ Page 147).

#### Positioning crankshaft at BDC

1. Using barring gear, turn crankshaft until crankshaft journal of the cylinder to be inspected has reached BDC.
2. Insert endoscope into cylinder liner through injector seat.

#### Cylinder liner – Endoscopic examination

| Findings  | Action  |
|---|---|
| <ul style="list-style-type: none"> <li>• Thin carbon coating on circumference of carbon scraper ring</li> <li>• Slight localized additive deposits at top edge</li> <li>• Singular smooth areas at lower edge</li> <li>• Carbon deposits on circumference in clearance between top piston ring and bottom edge of carbon scraper ring</li> <li>• First signs of marks left by top piston ring</li> <li>• Bright mark on entire circumference</li> <li>• Consistent honing pattern without objections</li> <li>• First signs of marks left by lower cooling bores</li> <li>• Running pattern seems darker</li> </ul> | No action required  |
| <ul style="list-style-type: none"> <li>• Dark areas with even or varying degrees of discoloration</li> <li>• Beginning and end of the discoloration are not sharply defined and do not cover the entire stroke area</li> <li>• Dark areas in the upper section of the cooling bore, remaining circumference without objections</li> <li>• Piston rings without objections</li> </ul>  | Further endoscopic examination required as part of maintenance work |
| <ul style="list-style-type: none"> <li>• On the entire circumference, apart from light areas of discoloration (that do not impair operation) clearly darker stripes that start at the top piston ring</li> <li>• Heat discoloration in the direction of stroke and honing pattern damage</li> <li>• Heat discoloration of piston rings</li> </ul>   | Cylinder liner must be replaced; Service must be contacted          |

1. Compile endoscopy report using the table.
2. Use technical terms for description of the liner surface (→ Page 136).
3. Depending on findings:
  - do not take any action or
  - carry out a further endoscopic examination as part of maintenance work or
  - contact Service; cylinder liner must be replaced.

## Final steps

1. Install injector (→ Page 147).
2. Install cylinder head cover (→ Page 144).

## 7.2.2 Instructions and comments on endoscopic and visual examination of cylinder liners

### Terms used for endoscopic examination

Use the terms listed below to describe the condition of the cylinder-liner surface in the endoscopic examination report.

| Findings                 | Action  |
|--------------------------|---|
| Minor dirt scores        | <p>Minor dirt scores can occur during the assembly of a new engine (honing products, particles, broken-off burrs). Removed cylinders clearly show such scoring on the running surface under endoscope magnification. Cannot be felt with the fingernail.</p> <p>Findings not critical.</p>  |
| Single scores            | <p>Clearly visible scores caused by hard particles. They usually start in the TDC area and cross through the hone pattern in the direction of stroke.</p> <p>Findings not critical.</p>   |
| Scored area              | <p>These areas consist of scores of different length and depth next to one another. In most cases, they are found at the 6-o'clock and 12-o'clock positions (inlet/exhaust) along the transverse engine axis.</p> <p>Findings not critical.</p>   |
| Smoothened area          | <p>Smoothened areas are on the running surface but almost the whole honing pattern is still visible. Smoothened areas appear brighter and more brilliant than the surrounding running surface.</p> <p>Findings not critical.</p>  |
| Bright area              | <p>Bright areas are on the running surface and show local removal of the honing pattern. Grooves from honing process are not visible any more.</p>  |
| Discoloration            | <p>This is caused by oxidation (surface discoloration through oil or fuel) and temperature differences around the liner. It appears rather darker within the honed structure in contrast to the bright metallic running surface. The honing pattern is undisturbed. Discolorations extend in stroke direction and may be interrupted.</p> <p>Findings not critical.</p> |
| Corrosion fields / spots | <p>Corrosion fields / spots result from water (condensed water) with the valves in the overlap (open) position. They are clearly visible due to the dark color of the honing groove bottom.</p> <p>This corrosion is not critical unless there is corrosion pitting.</p>  |
| Black lines              | <p>Black lines are a step towards heat discoloration. They are visible as a clear discoloration from TDC to BDC in the running surface and the start of localized damage to the honing pattern.</p> <p>Cylinder liners with a large number of black lines around the running surface have limited service life and should be replaced.</p>                              |

| Findings                | Action  |
|-------------------------|---|
| Burn mark               | <p>This is caused by a malfunction in the liner / ring tribosystem. Usually they run over the whole ring-travel area (TDC/BDC), starting at the first TDC-ring and becoming more visible from the second TDC-ring 2 onwards and less pronounced from TDC-ring 1. The honing pattern is usually no longer visible and displays a clearly defined (straight) edge to the undisturbed surface. The damaged surface is usually discolored. The circumferential length varies.</p> <p>Liners with burn marks, or heat discoloration, starting in TDC-ring 1 have to be replaced.</p> |
| Seizure marks, scuffing | <p>Irregular circumference lengths and depths. Can be caused either by the piston skirt or the piston crown. Material deposits on the liner (smear), heavy discoloration. Severe, visible scoring.</p> <p>Replace liner.</p>  |

### Evaluation of findings and further measures

The findings in the start phase of oxidation discoloration and heat discoloration are similar. A thorough investigation and compliance with the above evaluation criteria allow an unambiguous evaluation. To avoid unnecessary disassembly work, it is recommended that another inspection be carried out after further operation of the engine.

## 7.3 Crankcase Breather

### 7.3.1 Crankcase breather – Oil separator element replacement, diaphragm check and replacement

#### Preconditions

- Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use      | Part No.                | Qty. |
|------------------------|-------------------------|------|
| Torque wrench, 6-50 Nm | F30027336               | 1    |
| Ratchet adapter        | F30027340               | 1    |
| Engine oil             |                         |      |
| Filter element         | (→ Spare Parts Catalog) |      |
| Diaphragm              | (→ Spare Parts Catalog) |      |
| Gasket                 | (→ Spare Parts Catalog) |      |


#### WARNING



- Hot oil.  
Oil can contain combustion residues which are harmful to health.  
**Risk of injury and poisoning!**
- Wear protective clothing, gloves, and goggles / safety mask.
  - Avoid contact with skin.
  - Do not inhale oil vapor.

#### Replacing oil separator element

1. Remove cover (2) with O-ring (3).
2. Remove filter element (1) from housing (4).
3. Insert new filter element in housing (4).
4. Install cover (2) with new O-ring.




5. Use torque wrench to tighten the screws of cover (2) to the specified torque.

| Name  | Size | Type              | Lubricant    | Value/Standard |
|-------|------|-------------------|--------------|----------------|
| Screw |      | Tightening torque | (Engine oil) | 10 Nm –2 Nm    |

6. Replace further oil separator elements in the same way.

## Checking diaphragm

1. Remove cover (4).
2. Remove spring (5), gasket (2) and diaphragm (3).
3. Check diaphragm (3) for damage, fit new diaphragm if used one is damaged.
4. Install diaphragm (3) on housing (1).
5. Install new seal (2) and spring (5) together with cover (4).



01801221

6. Use torque wrench to tighten the screws of cover (4) to the specified torque.

| Name  | Size | Type              | Lubricant    | Value/Standard   |
|-------|------|-------------------|--------------|------------------|
| Screw |      | Tightening torque | (Engine oil) | 10 Nm $\pm$ 2 Nm |

7. Check diaphragms in further oil separators in the same way.

## 7.4 Valve Drive

### 7.4.1 Valve gear – Lubrication

#### Preconditions


- ☑ Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Engine oil        |          |      |

#### Valve gear – Lubrication

1. Remove cylinder head covers (→ Page 144).
2. Fill oil chambers of valve bridges with oil.
3. Fill oil chambers of rocker arms and adjusting screws with oil.
4. Install cylinder head covers (→ Page 144).



## 7.4.2 Valve clearance – Check and adjustment

### Preconditions

- Engine is stopped and starting disabled.
- Engine coolant temperature is max. 40 °C.
- Valves are closed.

### Special tools, Material, Spare parts


| Designation / Use        | Part No.  | Qty. |
|--------------------------|-----------|------|
| Feeler gauge             | Y20010128 | 1    |
| Torque wrench, 60-320 Nm | F30047446 | 1    |
| Ring socket, 24 mm       | F30039526 | 1    |
| Engine oil               |           |      |

### Preparatory steps


1. Remove cylinder head cover (→ Page 144).
2. Install barring device (→ Page 131).

Note: The OT mark (if fitted) on the flywheel must not be used for reference.


3. Rotate crankshaft with barring device in engine direction of rotation until "OT-A1" mark and pointer are aligned.



## Diagram for 12 V engines (two crankshaft positions)



## Diagram for 16 V engines (two crankshaft positions)




### Checking valve clearance at two crankshaft positions

1. Check TDC position of piston in cylinder A1:
  - If the rocker arms are unloaded on cylinder A1, the piston is in firing TDC.
  - If the rocker arms are under load on cylinder A1, the piston is in overlap TDC.
2. Check valve clearance with cold engine:
  - Inlet valves (long rocker arm) = 0.2 mm  $\pm$ 0.05 mm
  - Exhaust valves (short rocker arm) = 0.5 mm  $\pm$ 0.05 mm
3. Check all valve clearances in two crankshaft positions (firing TDC and overlap TDC of cylinder A1) as per diagram.
  - 1 Cylinder A1 is in firing TDC
  - 2 Cylinder A1 is in overlap TDC
  - I Inlet valve
  - X Exhaust valve
4. Use feeler gauge to determine the distance between valve bridge and rocker arm.
5. If the deviation from the reference value exceeds 0.1 mm, adjust valve clearance.

## Adjusting valve clearance

1. Release locknut (1).
2. Insert feeler gauge (3) between valve bridge and rocker arm.
3. Using Allen key, set adjusting screw (2) so that the specified valve clearance is provided.
4. Feeler gauge (3) must just pass through gap.



5. Tighten locknut (1) with torque wrench to the specified tightening torque, holding the adjusting screw (2) to prevent it from turning.

| Name    | Size      | Type              | Lubricant    | Value/Standard |
|---------|-----------|-------------------|--------------|----------------|
| Locknut | M16 x 1.5 | Tightening torque | (Engine oil) | 90 Nm +9 Nm    |

6. Replace or rectify adjusting screws and/or locknuts which do not move freely.
7. Check valve clearance.

## Final steps

1. Remove barring device (→ Page 131).
2. Install cylinder head cover (→ Page 144).

## 7.4.3 Cylinder head cover – Removal and installation

### Preconditions


- ☑ Engine is stopped and starting disabled.

### Special tools, Material, Spare parts

| Designation / Use                       | Part No.                | Qty. |
|---|-------------------------|------|
| Grease (Kluthe Hakuform 30-10/Emulgier) | X00029933               |      |
| O-ring                                  | (→ Spare Parts Catalog) |      |

### Removing cylinder head cover

1. Clean very dirty cylinder head covers (1) prior to removal.
2. Remove screws (3, 4,) with washers (2, 5).
3. Take off cylinder head cover (1) with O-ring (6) from cylinder head (7).



### Installing cylinder head cover

1. Clean mounting surface.
2. Check O-ring (6) for damage, replace if necessary.
3. Coat O-ring (6) with grease.
4. Position O-ring (6) in groove of cylinder head cover (1).
5. Fit cylinder head cover (1) on cylinder head (7).
6. Install cylinder head cover (1) with screws (3, 4) and washers (2, 5).

## 7.5 Injection Pump / HP Pump

### 7.5.1 HP pump – Filling with engine oil

#### Preconditions

- ☑ Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Engine oil        |          |      |

#### WARNING



Fuels are combustible.

#### Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

#### WARNING



Oils/oil vapors are combustible/explosive.

#### Risk of fire and explosion!

- Avoid open flames, electric sparks and ignition sources.
- Do not smoke.

#### CAUTION




Fuel system high-pressure pump not filled with engine oil.

#### Damage to components, major material damage!

- Make sure that the high-pressure fuel pump is filled with engine oil before installation or initial operation.

#### Filling HP pump

1. Remove plug screw (1).
2. Use pump oiler to fill HP pump with engine oil until engine oil emerges.
3. Insert plug screw (1).



## 7.6 Injection Valve / Injector

### 7.6.1 Injector – Replacement

#### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Injector          | (→ Spare Parts Catalog) |      |

#### Replacing injector

- ▶ Remove injector and install new injector (→ Page 147).

## 7.6.2 Injector – Removal and installation

### Preconditions

- ☑ Engine is stopped and starting disabled.

### Special tools, Material, Spare parts

| Designation / Use                       | Part No.                | Qty. |
|---|-------------------------|------|
| Installation/removal tool               | F6789889                | 1    |
| Milling cutter                          | F30452739               | 1    |
| Torque wrench, 0.5-5 Nm                 | 0015384230              | 1    |
| Torque wrench, 10-60 Nm                 | F30452769               | 1    |
| Torque wrench, 60-320 Nm                | F30452768               | 1    |
| Assembly paste (Optimoly Paste White T) | 40477                   | 1    |
| Grease (Kluthe Hakuform 30-10/Emulgier) | X00029933               | 1    |
| Engine oil                              |                         |      |
| O-ring                                  | (→ Spare Parts Catalog) |      |

#### WARNING



Fuels are combustible.

#### Risk of fire and explosion!


- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

### Preparatory steps

1. Shut off fuel supply to engine.
2. Remove cylinder head cover (→ Page 144).

### Removing injector


1. Disconnect cable connector on injector.




2. Remove HP fuel line (4).
3. Remove return line (5).

Note: The injector accumulator will be emptied when removing the adapter.


4. Remove adapter (3).
5. Remove screw (2) and take off hold-down clamp (1).



6. Install installation/removal tool on cylinder head.
7. Remove injector with installation/removal tool.
8. Remove installation/removal tool.






9. Remove sealing ring (4) from injector or use a self-made hook to take it out of the cylinder head.
10. Remove O-rings (3), O-ring (2) and damper ring (1) from injector.
11. Clean all mating and sealing surfaces.
12. Cover all connections and bores, or seal with suitable plugs.




## Installing injector

1. Remove plug before installing the injector. (Do not remove the plug from the HP line before installing the adapter.)
2. Coat injector with assembly paste at the seat of the nozzle clamping nut.
3. Fit new sealing ring (included in the scope of supply of the injector) with grease on injector, observe installation position of sealing ring.
4. Fit new O-rings (3) (included in the scope of supply of the injector), O-ring (2) and damping ring (1) onto the injector and coat with grease.
5. Remove oil carbon from sealing face on cylinder head and protective sleeve with milling cutter.
6. Insert injector into cylinder head, ensuring that the HP line adapter is correctly aligned.
7. Use installation/removal tool to press in injector.
8. Remove installation/removal tool.



9. Coat screw head mating face (2) and thread with engine oil.



10. Fit hold-down clamp (1) in the correct position and use torque wrench to tighten screw (2) to the specified initial tightening torque.

| Name  | Size | Type           | Lubricant    | Value/Standard |
|-------|------|----------------|--------------|----------------|
| Screw | M12  | Preload torque | (Engine oil) | 5 Nm to 10 Nm  |

Note: Ensure special cleanness.

11. Coat thread and sealing cone of adapter (3) with engine oil.  
 12. Install adapter (3) and use torque wrench to tighten to the specified initial tightening torque.

| Name    | Size | Type           | Lubricant    | Value/Standard |
|---------|------|----------------|--------------|----------------|
| Adapter |      | Preload torque | (Engine oil) | 5 Nm to 10 Nm  |

13. Tighten screw (2) with torque wrench to the specified tightening torque.

| Name  | Size | Type              | Lubricant | Value/Standard |
|-------|------|-------------------|-----------|----------------|
| Screw | M12  | Tightening torque |           | 100 Nm + 10 Nm |

14. Tighten adapter (3) with torque wrench to the specified tightening torque.

| Name    | Size | Type              | Lubricant | Value/Standard |
|---------|------|-------------------|-----------|----------------|
| Adapter |      | Tightening torque |           | 100 Nm + 10 Nm |

15. Install return line (7).

Note: Ensure special cleanness.

16. Coat thread and sealing cone of HP line (5) with engine oil.

Note: Two HP line versions (single- and double-walled) with different torques as described below.


17. Mount single-walled HP line (5) and use torque wrench to tighten to the specified torque. Tightening sequence:  
 1 Rail (6)  
 2 Adapter (4)

| Name                     | Size | Type              | Lubricant | Value/Standard |
|--------------------------|------|-------------------|-----------|----------------|
| Union nut / thrust screw |      | Tightening torque |           | 30 Nm + 5 Nm   |

18. Mount double-walled HP line (5) and use torque wrench to tighten to the specified torque. Tightening sequence:
  - 1 Adapter (4)
  - 2 Rail (6)

| Name                     | Size | Type              | Lubricant | Value/Standard |
|--------------------------|------|-------------------|-----------|----------------|
| Union nut / thrust screw |      | Tightening torque |           | 40 Nm + 5 Nm   |

19. Fit cable connector onto injector.
- Note: Failure to reset drift compensation (CDC) will void the emissions certification.
20. Reset drift compensation (CDC) with DiaSys® (→ E531920/...). If DiaSys® is not available, contact Service.



### Final steps

1. Install cylinder head cover (→ Page 144).
2. Open fuel supply to engine.

## 7.7 Fuel System

### 7.7.1 Fuel system – Venting

#### Preconditions

- Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Diesel fuel       |          |      |

#### WARNING




Fuels are combustible.

#### Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

#### Venting LP fuel system

1. Open vent plug (1).
2. Unlock fuel priming pump (2), screw out handle by turning it counterclockwise.
3. Operate the pump with the handle (2) until bubble-free fuel emerges from the vent plug (1).
4. Close vent plug (1).
5. Screw in handle by turning it clockwise.
6. Verify that fuel priming pump (2) is locked: handle must be tightened.



## 7.8 Fuel Filter

### 7.8.1 Fuel filter – Replacement

#### Preconditions

- ☑ Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use  | Part No.                | Qty. |
|--------------------|-------------------------|------|
| Filter wrench      | F30379104               | 1    |
| Engine oil         |                         |      |
| Easy-change filter | (→ Spare Parts Catalog) |      |

#### WARNING




Fuels are combustible.

#### Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

#### Fuel filter – Replacement

1. Remove easy-change filter using the filter wrench.
2. Clean sealing surface on filter head.
3. Slightly lubricate seal on the easy-change filter (arrow).
4. Screw on the easy-change filter by hand until the seal makes contact and tighten finger-tight.
5. Replace further easy-change filters in the same way.
6. Vent fuel system (→ Page 152).



## 7.8.2 Fuel prefilter cleaning

### Preconditions

- ☑ Engine is stopped and starting disabled.

### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Diesel fuel       |                         |      |
| Sealing ring      | (→ Spare Parts Catalog) |      |

#### WARNING




Fuels are combustible.

#### Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

### Fuel prefilter cleaning

1. Shut off fuel supply.
2. Remove nuts from filter head.
3. Take off filter housing and drain fuel into appropriate container.
4. Remove filter-element securing nut and remove filter element by pulling it downwards.
5. Wash filter element in clean fuel using a smooth brush.
6. Wash filter housing with clean fuel.
7. Insert filter element into filter housing and secure with nut.
8. Place new sealing ring into groove in filter head.
9. Fit cover with seal and secure it with nuts crosswise.
10. Open fuel supply.



### 7.8.3 Fuel prefilter – Differential pressure gauge check and adjustment

#### DANGER



Unguarded rotating and moving engine components.  
**Risk of serious injury – danger to life!**  
• Take special care when working on a running engine.


#### WARNING



Engine noise above 85 dB (A).  
**Risk of damage to hearing!**  
• Wear ear protectors.

#### Adjusting differential pressure gauge

1. When installing the new filter element: align adjustable pointer (2) with pressure-indicating pointer (3) of pressure gauge (1).
2. Check differential pressure.



#### Checking differential pressure of fuel prefilter

1. With the engine running at full load or rated power, read off pressure at gauge (1).
2. If differential pressure as indicated between position of adjustable pointer (2) and pressure-indicating pointer (3) of pressure gauge is  $\geq 0.3$  bar, flush filter element of the cut-in filter (→ Page 157).

## 7.8.4 Fuel prefilter – Draining

### Preconditions

- Engine is stopped and starting disabled.

### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Diesel fuel       |                         |      |
| Gasket            | (→ Spare Parts Catalog) |      |

#### WARNING





Fuels are combustible.

#### Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

### Fuel prefilter – Draining

1. Cut out filter to be drained.
  - 1 Left filter cut in
  - 2 Right filter cut in
  
2. Open threaded vent plug (5) of filter to be drained.
3. Unlock drain valve (6) by pressing toggle and open it.
4. Drain water and contaminants from filter until pure fuel emerges.
5. Close drain valve (6).
6. Remove screws for cover and take off cover (2).
7. Fill filter housing with clean fuel.
8. Place new gasket in cover (2).
9. Fit cover with gasket and secure it with screws.
10. Cut in the cut-out filter again.
11. Close threaded vent plug (5) when fuel emerges.



## 7.8.5 Fuel prefilter – Flushing

### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Fuel              |                         |      |
| Gasket            | (→ Spare Parts Catalog) |      |

#### DANGER



Unguarded rotating and moving engine components.  
**Risk of serious injury – danger to life!**  
• Take special care when working on a running engine.

#### WARNING



Fuels are combustible.  
**Risk of fire and explosion!**  
• Avoid open flames, electrical sparks and ignition sources.  
• Do not smoke.


#### WARNING



Engine noise above 85 dB (A).  
**Risk of damage to hearing!**  
• Wear ear protectors.

### Fuel prefilter – Flushing


1. Cut out clogged filter.  
I Left filter cut in  
II Right filter cut in



2. Open threaded vent plug (5) of filter to be flushed.
3. Unlock drain valve (6) by pressing valve toggle, open it and drain fuel.

Result: Fuel flows from filtered side back to the unfiltered side, flushing the filter deposits downwards out of the filter.

4. Close threaded vent plug (5) and drain valve (6).



### Fuel prefilter – Topping up with fuel

1. Stop engine (→ Page 73) and disable engine start.
2. Remove screws for cover and take off cover (2).
3. Fill filter housing with clean fuel.
4. Place new gasket in cover (2).
5. Fit cover with gasket and secure it with screws.
6. Check differential pressure (→ Page 155).

Result: If flushing did not lead to an improvement of the differential pressure, replace filter element of fuel prefilter (→ Page 159).

## 7.8.6 Fuel prefilter – Filter element replacement

### Preconditions

- ☑ Engine is stopped and starting disabled.

### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Diesel fuel       |                         |      |
| Filter element    | (→ Spare Parts Catalog) |      |
| Gasket            | (→ Spare Parts Catalog) |      |

#### WARNING




Fuels are combustible.

#### Risk of fire and explosion!


- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

### Replacing filter element

1. Cut out filter to be drained.
  - I Left filter cut in
  - II Right filter cut in



2. Open threaded vent plug (5) of contaminated filter.
3. Unlock drain valve (6) by pressing toggle and open it.
4. Drain water and dirt from filter.
5. Close drain valve (6).
6. Remove screws securing the cover and take off cover (2).
7. Remove spring housing (4) and filter element (3).
8. Insert new filter element (3) and spring housing (4).
9. Fill filter housing with clean fuel.
10. Place new gasket in cover (2).
11. Fit cover with gasket and secure it with screws.
12. Cut in the cut-out filter again.
13. Close threaded vent plug (5) when fuel emerges.
14. Adjust the differential pressure gauge (→ Page 155).




## 7.9 Charge-Air Cooling

### 7.9.1 Intercooler – Checking condensate drain for coolant discharge and obstructions

|   |   |
|---|---|
| <b>DANGER</b><br>  | Unguarded rotating and moving engine components.<br><b>Risk of serious injury – danger to life!</b> <ul style="list-style-type: none"><li>• Take special care when working on a running engine.</li></ul>   |
| <b>WARNING</b><br> | Engine noise above 85 dB (A).<br><b>Risk of damage to hearing!</b> <ul style="list-style-type: none"><li>• Wear ear protectors.</li></ul>   |
| <b>WARNING</b><br> | Compressed air<br><b>Risk of injury!</b> <ul style="list-style-type: none"><li>• Do not direct compressed-air jet at persons.</li><li>• Wear protective goggles / safety mask and ear protectors.</li></ul> |

#### Intercooler – Checking condensate drain for coolant discharge and obstructions

1. With the engine running, verify that air emerges from the condensate drain bore(s) at driving end, left and right engine side. If no air emerges:
  - Clean condensate drain bore(s)
  - Blow out with compressed air
2. If a large amount of coolant is continuously discharged, the intercooler is leaking. Contact Service.



#### Emergency measures prior to engine start with a leaking intercooler

1. Remove injectors (→ Page 147).
2. Bar engine manually (→ Page 131).
3. Bar engine with starting system to blow out combustion chambers (→ Page 132).
4. Install injectors (→ Page 147).

## 7.10 Air Filter

### 7.10.1 Air filter – Replacement

#### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Air filter        | (→ Spare Parts Catalog) |      |

#### Air filter – Replacement

1. Remove air filter and install new one (→ Page 164).
2. Reset signal ring of service indicator (→ Page 165).

## 7.10.2 Air filter – Check

### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Air filter        | (→ Spare Parts Catalog) |      |

### Air filter – Check

1. Check entire circumference of air filter for damage.
2. Fit new air filter if damaged (→ Page 164).


### 7.10.3 Air filter – Removal and installation

#### Preconditions

- ☑ Engine is stopped and starting disabled.

#### Air filter – Removal and installation

1. Release clamp (2).
2. Remove air filter (1) and clamp (2) from connecting flange of intake housing (3).
3. Verify that there are no objects in the connecting flange of the intake housing (3) and clean it.
4. Place new air filter (1) with clamp (2) onto intake housing (3).
5. Tighten clamp (2).



## 7.11 Air Intake

### 7.11.1 Service indicator – Signal ring position check (optional)


#### Preconditions

- ☑ Engine is stopped and starting disabled.

#### Checking signal ring position

1. If the signal ring is completely visible in the control window (2), replace air filter (→ Page 162).
2. After installation of new filter, press reset button (1).

Result: Engaged piston with signal ring moves back to initial position.



08401046

## 7.12 Starting Equipment

### 7.12.1 Air starter – Manual operation

#### DANGER



Unguarded rotating and moving engine components.

**Risk of serious injury – danger to life!**

- Before barring or starting the engine, make sure that nobody is in the danger zone.

#### WARNING




Engine noise above 85 dB (A).

**Risk of damage to hearing!**

- Wear ear protectors.

#### Air starter – Manual operation

1. Press pushbutton for manual start and hold it.
2. Allow compressed air to enter the air starter, until the engine fires evenly.
3. Release pushbutton.



17100168b

## 7.13 Lube Oil System, Lube Oil Circuit

### 7.13.1 Engine oil – Change

#### Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ Engine is at operating temperature.
- ☑ MTU fluids and lubricants specifications (A001061/..) are available.

#### Special tools, Material, Spare parts

| Designation / Use        | Part No.                | Qty. |
|--------------------------|-------------------------|------|
| Torque wrench, 40-200 Nm | F30027337               | 1    |
| Ratchet adapter          | F30027341               | 1    |
| Engine oil               |                         |      |
| Sealing ring             | (→ Spare Parts Catalog) |      |

#### WARNING



- Hot oil.  
Oil can contain combustion residues which are harmful to health.  
**Risk of injury and poisoning!**
- Wear protective clothing, gloves, and goggles / safety mask.
  - Avoid contact with skin.
  - Do not inhale oil vapor.

#### Version without semirotary hand pump: Drain the engine oil through the drain plug(s) on the oil pan.


1. Provide a suitable container in which to collect the engine oil.
2. Remove drain plug(s) and drain engine oil.
3. Install drain plug(s) with new sealing ring.

#### Version with semirotary hand pump: Extracting the engine oil

1. Provide a suitable container in which to collect the engine oil.
2. Extract all engine oil from oil pan using the semirotary hand pump.

### Draining residual oil from equipment carrier (only with unscheduled engine oil change)

1. Provide a suitable container in which to collect the engine oil.
2. Remove drain plug (1) and drain engine oil from engine oil heat exchanger and from engine oil filter.
3. Remove drain plugs (2) and (3) and drain engine oil.
4. Replace engine oil filter (→ Page 171).
5. Install drain plug(s) with new sealing ring.




6. Tighten drain (2) and (3) with torque wrench to specified tightening torque.

| Name  | Size      | Type              | Lubricant    | Value/Standard |
|-------|-----------|-------------------|--------------|----------------|
| Screw | M26 x 1.5 | Tightening torque | (Engine oil) | 100 Nm +10 Nm  |

### Filling with new engine oil

1. Open cover on filler neck.
2. Pour engine oil through the filler neck up to the "max." mark on the oil dipstick.
3. Close cover on filler neck.
4. Check engine oil level (→ Page 169).



## 7.13.2 Engine oil – Level check

### Preconditions


- ☑ Engine is stopped and starting disabled.

### Checking oil level prior to engine start

1. Withdraw oil dipstick from guide tube and wipe it.
2. Insert oil dipstick into guide tube up to stop, withdraw after approx. 10 seconds and check oil level.

Note: After extended standstill, the oil level may exceed the mark (1) by up to 2 cm. This can be caused by oil flowing from e.g. oil filter or heat exchanger back to the oil pan.

3. The oil level must reach mark (1) or exceed mark (1) by up to 2 cm.
4. Top up with oil to mark (1) as necessary (→ Page 167).
5. Insert oil dipstick into guide tube up to the stop.



### Checking oil level after the engine is stopped

1. 5 minutes after stopping the engine, remove oil dipstick from the guide tube and wipe it.
2. Insert oil dipstick into guide tube up to stop, withdraw after approx. 10 seconds and check oil level.
3. Oil level must be between marks (1) and (2).
4. Top up with oil to mark (1) as necessary (→ Page 167).
5. Insert oil dipstick into guide tube up to the stop.

### 7.13.3 Engine oil – Sample extraction and analysis

#### Preconditions

- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.


#### Special tools, Material, Spare parts

| Designation / Use | Part No.      | Qty. |
|-------------------|---------------|------|
| MTU test kit      | 5605892099/00 | 1    |

|   |   |
|---|---|
| <b>DANGER</b><br>    | Unguarded rotating and moving engine components.<br><b>Risk of serious injury – danger to life!</b> <ul style="list-style-type: none"><li>• Take special care when working on a running engine.</li></ul>   |
| <b>WARNING</b><br>   | Hot oil.<br>Oil can contain combustion residues which are harmful to health.<br><b>Risk of injury and poisoning!</b> <ul style="list-style-type: none"><li>• Wear protective clothing, gloves, and goggles / safety mask.</li><li>• Avoid contact with skin.</li><li>• Do not inhale oil vapor.</li></ul> |
| <b>WARNING</b><br> | Engine noise above 85 dB (A).<br><b>Risk of damage to hearing!</b> <ul style="list-style-type: none"><li>• Wear ear protectors.</li></ul>   |

#### Engine oil – Sample extraction and analysis

1. With the engine running at operating temperature, open screw on centrifugal oil filter carrier by 1 to 2 rotations.
2. Drain approx. 2 liters engine oil to flush out the oil sludge.
3. Drain approx. 1 liter engine oil into a clean container.
4. Close screw.
5. Using the equipment and chemicals of the MTU test kit, examine oil for:
  - Dispersion capability (spot test);
  - Water content;
  - Dilution by fuel.



TIM-ID: 0000000932 - 004

## 7.14 Oil Filtration / Cooling

### 7.14.1 Engine oil filter – Replacement

#### Preconditions

- ☑ Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Filter wrench     | F30379104               |      |
| Engine oil        |                         |      |
| Oil filter        | (→ Spare Parts Catalog) |      |

#### WARNING



Hot oil.


Oil can contain combustion residues which are harmful to health.

#### Risk of injury and poisoning!

- Wear protective clothing, gloves, and goggles / safety mask.
- Avoid contact with skin.
- Do not inhale oil vapor.

#### Engine oil filter – Replacement

1. Unscrew engine oil filter with filter wrench.
2. Clean sealing face on connecting piece.
3. Check sealing ring of new engine oil filter and apply a thin layer of engine oil.
4. Screw on and tighten engine oil filter by hand.
5. Replace other engine oil filters in the same way.
6. Check engine oil level (→ Page 169).
7. After changing engine oil and replacing oil filter(s), bar engine with starting equipment (→ Page 132).



## 7.14.2 Oil indicator filter – Check

### Preconditions

- ☑ Engine is stopped and starting disabled.

### Special tools, Material, Spare parts

| Designation / Use         | Part No.                | Qty. |
|---------------------------|-------------------------|------|
| Cleaner (Snow-White 11-0) | 40460                   | 1    |
| Cleaner (Hakupur 312)     | 30390                   | 1    |
| Engine oil                |                         |      |
| Strainer                  | (→ Spare Parts Catalog) |      |
| Square-section ring       | (→ Spare Parts Catalog) |      |
| O-ring                    | (→ Spare Parts Catalog) |      |

#### WARNING



- Hot oil.  
Oil can contain combustion residues which are harmful to health.  
**Risk of injury and poisoning!**
- Wear protective clothing, gloves, and goggles / safety mask.
  - Avoid contact with skin.
  - Do not inhale oil vapor.

#### WARNING



- Compressed air  
**Risk of injury!**
- Do not direct compressed-air jet at persons.
  - Wear protective goggles / safety mask and ear protectors.


#### CAUTION



- Unsuitable cleaning tool.  
**Damage to component!**
- Observe manufacturer's instructions.
  - Use appropriate cleaning tool.

### Removing strainer

1. Clean oil indicator filter before disassembling it.
2. Remove screws (1).
3. Take off cover (2) with O-ring (3).
4. Remove strainer (5) from housing and allow oil to drip into container.



18300256b

## Cleaning strainer

1. Shake coarse contamination out of strainer (5).
2. Clean all metallic parts with cleaner (Snow-White 11-0), then rinse with cleaner (Hakupur 312).
3. Use a soft brush to remove stubborn deposits from strainer if required. Ensure that the mesh is not damaged.
4. Blow out strainer (5) with compressed air from inside.

## Checking strainer

| Item                | Findings          | Action   |
|---------------------|-------------------|--|
| Strainer            | Metallic residues | <ul style="list-style-type: none"><li>• Clean</li><li>• Monitor engine operation</li><li>• Check strainer daily</li><li>• Contact Service.</li></ul> |
| Strainer            | Damaged           | Fit new part   |
| Square-section ring | Damaged           | Fit new part   |
| O-ring              | Damaged           | Fit new part   |

## Installing strainer

1. Coat square-section ring (4) on strainer (5) with engine oil and install strainer (5).
2. Insert strainer into housing.
3. Fill housing with new engine oil.
4. Coat O-ring (3) with engine oil and fit in filter housing.
5. Fit cover (2) and secure with screws (1) and washers.

### 7.14.3 Centrifugal oil filter – Cleaning and filter sleeve replacement

#### Preconditions

- Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use         | Part No.                | Qty. |
|---------------------------|-------------------------|------|
| Torque wrench, 6-50 Nm    | F30027336               | 1    |
| Cold cleaner (Hakutex 60) | X00056750               | 1    |
| Filter sleeve             | (→ Spare Parts Catalog) |      |
| Sealing ring              | (→ Spare Parts Catalog) |      |
| Sealing ring              | (→ Spare Parts Catalog) |      |

#### WARNING



Hot oil.  
Oil can contain combustion residues which are harmful to health.  
**Risk of injury and poisoning!**

- Wear protective clothing, gloves, and goggles / safety mask.
- Avoid contact with skin.
- Do not inhale oil vapor.

#### WARNING




Compressed air  
**Risk of injury!**

- Do not direct compressed-air jet at persons.
- Wear protective goggles / safety mask and ear protectors.

## Centrifugal oil filter – Cleaning and filter sleeve replacement

1. Remove clamp (14).
  2. Release cover screw (2) and take off cover (1).
  3. Carefully lift rotor (11), allow oil to drain and remove from housing.
  4. Holding the rotor (11) firmly, release rotor cover nut (3).
  5. Take off rotor cover (4).
  6. Remove filter sleeve (6).
  7. Measure thickness of oil residues on filter sleeve (6).
  8. If maximum layer thickness of oil residues exceeds 45 mm, shorten maintenance interval.
  9. Disassemble rotor tube (7), conical disk (8) and rotor base (10).
  10. Wash rotor cover (4), rotor tube (7), conical disk (8) and rotor base (10) with cold cleaner.
  11. Blow out with compressed air.
  12. Check sealing ring (9), fit new one if necessary.
  13. Assemble rotor tube (7), conical disk (8) and rotor base (10) with sealing ring (9).
  14. Insert new filter sleeve (6) in rotor tube (7) with the smooth paper surface facing the outer wall.
  15. Check sealing ring (5), fit new one if necessary.
  16. Mount rotor cover (4) with sealing ring (5).
  17. Tighten rotor cover nut (3) with torque wrench to the specified torque.
18. Place rotor (11) in housing (12) and check for ease of movement.
  19. Check sealing ring (13), fit new one if necessary.
  20. Fit sealing ring (13) on housing (12).
  21. Fit cover (1).
  22. Fit cover screw (2) by hand.
  23. Install clamp (14) and tighten with torque wrench to the specified torque.



| Name | Size | Type              | Lubricant | Value/Standard |
|------|------|-------------------|-----------|----------------|
| Nut  |      | Tightening torque |           | 35 Nm to 45 Nm |

23. Install clamp (14) and tighten with torque wrench to the specified torque.

| Name  | Size | Type              | Lubricant | Value/Standard |
|-------|------|-------------------|-----------|----------------|
| Clamp |      | Tightening torque |           | 8 N to 10 Nm   |

24. Tighten cover nut (2) with torque wrench to the specified torque.

| Name  | Size | Type              | Lubricant | Value/Standard |
|-------|------|-------------------|-----------|----------------|
| Screw |      | Tightening torque |           | 5 Nm to 7 Nm   |

## 7.15 Coolant Circuit, General, High-Temperature Circuit

### 7.15.1 Engine coolant – Level check

#### Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

#### WARNING



Coolant is hot and under pressure.

#### Risk of injury and scalding!


- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

#### Checking engine coolant level at filler neck:

1. Turn breather valve on coolant expansion tank counterclockwise to the first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Check engine coolant level (coolant must be visible at the bottom edge of the filler neck's cast eye).

#### Checking engine coolant level at remote cooler:

1. Check engine coolant level (coolant must be visible at marker plate).
2. Top up engine coolant if necessary (→ Page 179).
3. Check and clean breather valve.
4. Place breather valve on filler neck and close.



01400308b

#### Checking engine coolant level via level sensor:

1. Switch on engine control system and check readings on the display.
2. Top up engine coolant if necessary (→ Page 179).

## 7.15.2 Engine coolant – Change

### Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Coolant           |          |      |

### Engine coolant – Change

1. Drain engine coolant (→ Page 178).
2. Fill with engine coolant (→ Page 179).

## 7.15.3 Engine coolant – Draining

### Preconditions

- Engine is stopped and starting disabled.

#### WARNING



Coolant is hot and under pressure.

#### Risk of injury and scalding!


- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

### Preparatory steps

1. Provide an appropriate container to drain the coolant into.
2. Switch off preheating unit.

### Engine coolant – Draining

1. Turn breather valve of coolant expansion tank counterclockwise until the first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Draw off separated corrosion inhibitor oil in expansion tank through the filler neck.
4. Open drain valves and/or drain plugs and drain coolant at the following points:
  - Preheating unit
  - Thermostat housing
  - Twin elbow
  - HT coolant pump elbow;
  - Crankcase, left and right sides.
5. Close all open drain points.
6. Place breather valve on filler neck and close.



20202572

## 7.15.4 Engine coolant – Filling

### Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

### Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Coolant           |          |      |

#### WARNING



Coolant is hot and under pressure.

#### Risk of injury and scalding!

- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

#### CAUTION




Cold coolant in hot engine can cause thermal stress.

#### Formation of cracks in components!

- Fill / top up coolant only into cold engine.



### Preparatory steps

1. Turn breather valve of coolant expansion tank counterclockwise until the first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.




## Filling with coolant using a pump

1. Connect appropriate pump with hose to the drain valve of the engine coolant pump (arrow).
2. Undo the vent line union at the distributor piece (arrowed).
3. Open drain valve and pump coolant into engine at 0.5 bar minimum.
4. Tighten the union (arrowed) if coolant leaks out at the loose union.
5. Fill expansion tank until overflow edge is reached.
6. Close drain valve.
7. Check proper condition of breather valve on coolant expansion tank, clean sealing faces if required.
8. Fit breather valve and close it.
9. Start engine (→ Page 69).
10. After 10 seconds of running the engine without load, shut down the engine (→ Page 73).
11. Turn breather valve of coolant expansion tank counterclockwise until the first stop and allow pressure to escape.
12. Continue to turn breather valve counterclockwise and remove.
13. Check coolant level (→ Page 176) and top up engine coolant as required:
  - a) Top up coolant in expansion tank via filler neck until coolant level at top edge of filler neck remains constant.
  - b) Fit breather valve and close it.
14. Repeat the steps from "Start engine" (→ Step 9) until coolant is no longer needed to be topped up.
15. Disconnect pump and hose.



### Alternatively: Filling with coolant through filler neck

1. Undo the vent line union at the distributor piece (arrowed).
2. Top up coolant in expansion tank via filler neck until coolant level at top edge of filler neck remains constant.
3. Tighten the union (arrowed) if coolant leaks out at the loose union.
4. Check proper condition of breather valve on coolant expansion tank, clean sealing faces if required.
5. Fit breather valve and close it.
6. Start engine (→ Page 69).
7. After 10 seconds of running the engine without load, shut down the engine (→ Page 73).
8. Turn breather valve of coolant expansion tank counterclockwise until the first stop and allow pressure to escape.
9. Turn breather valve counterclockwise and remove.
10. Check coolant level (→ Page 176) and top up with coolant through the filler neck if required:
  - a) Top up coolant in expansion tank via filler neck until coolant level at top edge of filler neck remains constant.
  - b) Fit breather valve and close it.
11. Repeat the steps from "Start engine" (→ Step 6) until coolant is no longer needed to be topped up.



### Final steps

1. Start the engine and run it without load for some minutes.
2. Check coolant level (→ Page 176) and top up engine coolant as required.

## 7.15.5 Engine coolant pump – Relief bore check

### DANGER



Unguarded rotating and moving engine components.  
**Risk of serious injury – danger to life!**

- Take special care when working on a running engine.

### WARNING




Engine noise above 85 dB (A).  
**Risk of damage to hearing!**

- Wear ear protectors.

### Engine coolant pump – Relief bore check

1. Check relief bore for oil and coolant discharge.
2. Shut down engine (→ Page 73) and disable engine start, observe general safety instructions “Maintenance and Repair”.
3. Clean the relief bore with a wire if it is dirty.
  - Permissible coolant discharge: up to 10 drops per hour;
  - Permissible oil discharge: up to 5 drops per hour.
4. If discharge exceeds the specified limits: Contact Service.



## 7.15.6 Engine coolant – Sample extraction and analysis

### Preconditions

- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.


### Special tools, Material, Spare parts

| Designation / Use | Part No.      | Qty. |
|-------------------|---------------|------|
| MTU test kit      | 5605892099/00 | 1    |

|   |  |
|---|--|
| <b>DANGER</b><br>    | Unguarded rotating and moving engine components.<br><b>Risk of serious injury – danger to life!</b> <ul style="list-style-type: none"><li>• Take special care when working on a running engine.</li></ul>                    |
| <b>WARNING</b><br>   | Coolant is hot and under pressure.<br><b>Risk of injury and scalding!</b> <ul style="list-style-type: none"><li>• Let the engine cool down.</li><li>• Wear protective clothing, gloves, and goggles / safety mask.</li></ul> |
| <b>WARNING</b><br> | Engine noise above 85 dB (A).<br><b>Risk of damage to hearing!</b> <ul style="list-style-type: none"><li>• Wear ear protectors.</li></ul>  |

### Engine coolant – Sample extraction and analysis

1. With the engine running, open drain valve (1).
2. Flush sample-extraction point by draining approx. 1 liter coolant.
3. Drain approx. 1 liter coolant into a clean container.
4. Close drain valve (1).
5. Using the equipment and chemicals of the MTU test kit, check the coolant for:
  - Antifreeze concentration
  - Corrosion inhibitor concentration
  - pH value.
6. For engine coolant change intervals, (→ MTU Fluids and Lubricants Specifications (A001061/..)).



## 7.16 Low-Temperature Circuit

### 7.16.1 Charge-air coolant – Level check

#### Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

#### WARNING




Coolant is hot and under pressure.

#### Risk of injury and scalding!

- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

#### Checking charge-air coolant level at filler neck:

1. Turn breather valve on coolant expansion tank counterclockwise to the first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Check coolant level (coolant must be visible at marking plate).
4. Top up coolant if necessary (→ Page 187).
5. Check proper condition of breather valve, clean sealing faces if required.
6. Fit breather valve and close it.



#### Checking charge-air coolant level by means of level sensor:

1. Switch on engine control system and check display (coolant level is automatically monitored by engine control system).
2. Top up coolant if necessary (→ Page 187).

## 7.16.2 Charge-air coolant – Change

### Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Coolant           |          |      |

### Charge-air coolant – Change

1. Drain charge-air coolant (→ Page 186).
2. Fill with charge-air coolant (→ Page 187).

## 7.16.3 Charge-air coolant – Draining

### Preconditions

- ☑ Engine is stopped and starting disabled.

### Special tools, Material, Spare parts

| Designation / Use | Part No.                | Qty. |
|-------------------|-------------------------|------|
| Sealing ring      | (→ Spare Parts Catalog) |      |

#### WARNING





Coolant is hot and under pressure.

#### Risk of injury and scalding!

- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

### Charge-air coolant – Draining

1. Provide an appropriate container to drain the coolant into.
2. Turn breather valve of coolant expansion tank counterclockwise until the first stop and allow pressure to escape.
3. Continue to turn breather valve counterclockwise and remove.
4. Draw off separated corrosion inhibitor oil in expansion tank through the filler neck.
5. Open drain valves and/or drain plugs and drain coolant at the following points:
  - at the LT coolant pump
  - at the LT thermostat housing.
6. Draining of residual coolant:
  - at the intercooler
7. Close all drain valves and screw in drain plugs with new sealing rings.
8. Place breather valve on filler neck and close.



## 7.16.4 Charge-air coolant – Filling

### Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

### Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Coolant           |          |      |

#### WARNING



Coolant is hot and under pressure.

#### Risk of injury and scalding!

- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

#### CAUTION




Cold coolant in hot engine can cause thermal stress.

#### Formation of cracks in components!

- Fill / top up coolant only into cold engine.



### Preparatory steps

1. Turn breather valve of coolant expansion tank counterclockwise until the first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.




## Filling with coolant using a pump

1. Connect a suitable pump with a hose to the drain valve (arrowed).
2. Undo the vent line union at the distributor piece (arrowed).
3. Open drain valve and pump coolant into engine at 0.5 bar minimum.
4. Tighten the union (arrowed) if coolant leaks out at the loose union.
5. Fill expansion tank until overflow edge is reached.
6. Close drain valve.
7. Check proper condition of breather valve and clean sealing faces if required.
8. Place breather valve on filler neck and close.
9. Start engine (→ Page 69).
10. After 10 seconds of running the engine without load, shut down the engine (→ Page 73).
11. Turn breather valve of coolant expansion tank counterclockwise until the first stop and allow pressure to escape.
12. Continue to turn breather valve counterclockwise and remove.
13. Check coolant level (→ Page 184) and top up coolant as required:
  - a) Fill in coolant in expansion tank until the coolant level at top edge of filler neck remains constant.
  - b) Place breather valve on filler neck and close.
14. Repeat the steps from "Start engine" (→ Step 9) until coolant is no longer needed to be topped up.
15. Disconnect pump and hose.



### Alternatively: Filling with coolant through filler neck

1. Undo the vent line union at the distributor piece (arrowed).
2. Top up coolant in expansion tank via filler neck until coolant level at top edge of filler neck remains constant.
3. Tighten the union (arrowed) if coolant leaks out at the loose union.
4. Check proper condition of breather valve on coolant expansion tank, clean sealing faces if required.
5. Fit breather valve and close it.
6. Start engine (→ Page 69).
7. After 10 seconds of running the engine without load, shut down the engine (→ Page 73).
8. Turn breather valve of coolant expansion tank counterclockwise until the first stop and allow pressure to escape.
9. Turn breather valve counterclockwise and remove.
10. Check coolant level (→ Page 184) and top up with coolant through the filler neck if required:
  - a) Top up coolant in expansion tank via filler neck until coolant level at top edge of filler neck remains constant.
  - b) Fit breather valve and close it.
11. Repeat the steps from "Start engine" (→ Step 6) until coolant is no longer needed to be topped up.



### Final steps

1. Start the engine and run it without load for some minutes.
2. Check coolant level (→ Page 184) and top up coolant as required.

## 7.16.5 Charge-air coolant pump – Relief bore check

### DANGER



Unguarded rotating and moving engine components.  
**Risk of serious injury – danger to life!**

- Take special care when working on a running engine.

### WARNING




Engine noise above 85 dB (A).  
**Risk of damage to hearing!**

- Wear ear protectors.

### Charge-air coolant pump – Relief bore check

1. Check relief bore for oil and coolant discharge.
2. Shut down engine (→ Page 73) and disable engine start, observe general safety instructions “Maintenance and Repair”.
3. Clean the relief bore with a wire if it is dirty.
  - Permissible coolant discharge: up to 10 drops per hour;
  - Permissible oil discharge: up to 5 drops per hour.
4. If discharge exceeds the specified limits: Contact Service.




## 7.17 Belt Drive

### 7.17.1 Drive belt – Condition check

#### Preconditions

- Engine is stopped and starting disabled.
- Guard is removed.

#### Drive belt – Condition check



| Item         | Findings                                 | Action               |
|--------------|--|----------------------|
| Drive belt A | Singular cracks                          | None                 |
| Drive belt   | Belt is oily, shows signs of overheating | Replace (→ Page 193) |
| Drive belt B | Cracks on entire circumference           |                      |
| Drive belt C | Chunking                                 |                      |

## 7.18 Battery-Charging Generator

### 7.18.1 Battery-charging generator drive – Drive belt tension adjustment

#### Preconditions

- Engine is stopped and starting disabled.

#### WARNING



Spring/circlip/tensioning roller preload.


#### Risk of injury!

- Only use specified tool and equipment.

#### Adjusting belt tension

1. Remove protective cover.
2. Slacken screws (1) and (2) by half a turn.

Result: Belt tensioner moves against the drive belt and tensions it.



21300436

3. Tighten screw (2) with torque wrench to the specified tightening torque.

| Name  | Size    | Type              | Lubricant | Value/Standard |
|-------|---------|-------------------|-----------|----------------|
| Screw | M10x1.5 | Tightening torque |           | 60 Nm +5 Nm    |

4. Tighten screw (1) to specified tightening torque using a torque wrench.

| Name  | Size    | Type              | Lubricant | Value/Standard |
|-------|---------|-------------------|-----------|----------------|
| Screw | M10x1.5 | Tightening torque |           | 42 Nm          |

5. Install protective cover.

## 7.18.2 Battery-charging generator drive – Drive belt replacement

### Preconditions

- Engine is stopped and starting disabled.

#### WARNING




Spring/circlip/tensioning roller preload.

#### Risk of injury!

- Only use specified tool and equipment.

### Battery-charging generator drive – Drive belt replacement

1. Remove protective cover.
  2. Slacken screws (2) and (3) by half a turn.
  3. Mount socket or box wrench on screw (1) and press belt tensioner in direction of arrow as far as the stop.
  4. Tighten screw (3).
  5. Remove the used drive belt.
  6. Fit new drive belt.
  7. Slacken screw (3) by half a turn.
- Result: Belt tensioner moves against the drive belt and tensions it.



8. Tighten screw (3) to specified tightening torque using a torque wrench.

| Name  | Size    | Type              | Lubricant | Value/Standard |
|-------|---------|-------------------|-----------|----------------|
| Screw | M10x1.5 | Tightening torque |           | 60 Nm +5 Nm    |

9. Tighten screw (2) with torque wrench to the specified tightening torque.

| Name  | Size    | Type              | Lubricant | Value/Standard |
|-------|---------|-------------------|-----------|----------------|
| Screw | M10x1.5 | Tightening torque |           | 42 Nm          |

10. Install protective cover.
11. Readjust belt tension after 30 minutes and again after 8 hours engine runtime (→ Page 192).

## 7.19 Engine Mounting / Support

### 7.19.1 Engine mounting – Check

#### Engine mounting – Check

| Item                     | Findings  | Action                     |
|--------------------------|---|----------------------------|
| Visually inspect mounts. | <ul style="list-style-type: none"><li>• Damage</li><li>• Brittleness</li><li>• Deformation</li><li>• Crack formation</li><li>• Swelling visible</li></ul> | Replace (contact Service). |

---

## 7.20 Wiring (General) for Engine/Gearbox/Unit

### 7.20.1 Engine wiring – Check

#### Preconditions

- Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use | Part No.  | Qty. |
|-------------------|-----------|------|
| Isopropyl alcohol | X00058037 | 1    |

#### Engine wiring – Check

1. Check securing screws of cable clamps on engine and tighten loose threaded connections.
  2. Ensure that cables are fixed in their clamps and cannot swing freely.
  3. Check that cable ties are firm, tighten loose cable ties.
  4. Replace faulty cable ties.
  5. Visually inspect the following electrical line components for damage:
    - connector housings;
    - contacts;
    - sockets;
    - cables and terminals;
    - plug-in contacts.
  6. (→ Contact Service) if cable conductors are damaged.
- Note: Close male connectors that are not plugged in with the protective cap supplied.
7. Clean dirty connector housings, sockets and contacts with isopropyl alcohol.
  8. Ensure that all sensor connectors are securely engaged.

## 7.21 Accessories for (Electronic) Engine Governor / Control System

### 7.21.1 Engine governor and connectors – Cleaning

#### Preconditions

- Engine is stopped and starting disabled.

#### Special tools, Material, Spare parts

| Designation / Use | Part No.  | Qty. |
|-------------------|-----------|------|
| Isopropyl alcohol | X00058037 | 1    |

Note: Always use test connectors to enter the connectors. Never use test leads for this purpose. Otherwise the contacts could be bent.

#### Engine governor and connectors – Cleaning

1. Remove coarse dirt from housing surface with isopropyl alcohol.
2. Remove dirt from connector and cable surfaces with isopropyl alcohol.
3. Check legibility of cable labels. Clean or replace illegible labels.

#### Cleaning severely contaminated connectors on the engine governor

Note: Seal unused connectors with the supplied protective cap.

1. Release the latch and pull off connectors.
2. Clean connector housings, connector socket housings and all contacts with isopropyl alcohol.
3. When connectors, sockets and all contacts are dry: Fit connectors and lock them.

## 7.21.2 Engine governor – Checking plug-in connections

### Preconditions

- Engine is stopped and starting disabled.

Note: Always use test connectors to enter the connectors. Never use test leads for this purpose. Otherwise the contacts could be bent.

### Checking plug-in connections on engine governor

1. Check all plug-in connections for secure seating.
2. Latch connectors if loose.

## 7.21.3 ECU 7 engine governor – Removal and installation

### Preconditions

- Engine is stopped and starting disabled.

#### CAUTION




Wrong engine governor installed.

#### Engine damage!

- When reassembling an engine, make sure that the governor with the data record for the given engine is installed.

### Removing Engine Control Unit from engine

1. Note or mark assignment of cables and connectors.
2. Remove all screws (2).
3. Undo latches (3) of the connectors.
4. Remove all connectors.
5. Remove screws (1).
6. Take off Engine Control Unit.



### Installing Engine Control Unit on engine

1. Install in reverse order. In doing so, ensure correct assignment of connectors and sockets.
2. Check rubber mounts before installation.

Result: Replace rubber mounts if they are found porous or defective.

# 8 Appendix A

## 8.1 Abbreviations

| Abbreviation | Meaning   | Explanation  |
|--------------|---|--|
| A/D          | Analog/Digital                                      | Transformer: transforms sensor voltages into numeric values  |
| ADEC         | Advanced Diesel Engine Controller                   | Engine management system   |
| AFRS         | Air Filter Restriction Sensor                       |  |
| ANSI         | American National Standards Institute               | Association of American standardization organizations  |
| ATL          | Abgasturbolader                                     | Exhaust turbocharger (ETC)   |
| ATS          | Air Temperature Sensor                              |  |
| BR           | Baureihe  | Series   |
| BV           | Betriebsstoffvorschrift                             | MTU Fluids and Lubricants Specifications, publication No. A01061/..                                  |
| CAN          | Controller Area Network                             | Data bus system, bus standard  |
| CDC          | Calibration Drift Compensation                      | Setting of drift compensation in engine governor with DiaSys   |
| CEL          | Stop engine light                                   | 1st function: Warning lamp (rectify fault as soon as possible)<br>2nd function: Read out fault codes |
| CKT          | Circuit   |  |
| CLS          | Coolant level sensor                                |  |
| CPS          | Coolant pressure sensor                             |  |
| CTS          | Coolant temperature sensor                          |  |
| DDEC         | Detroit Diesel Electronic Controls                  | Engine control system made by Detroit Diesel   |
| DDL          | Diagnostic Data Link                                |  |
| DDR          | Diagnostic Data Reader                              |  |
| DIN          | Deutsches Institut für Normung e. V.                | At the same time identifier of German standards (DIN = "Deutsche Industrie-Norm")                    |
| DL           | Default Lost  | Alarm: Default CAN bus failure   |
| DOC          | Diesel Oxidation Catalyst                           | Oxidation catalyst upstream of the diesel particulate filter   |
| DPF          | Diesel particulate filter                           |  |
| DT           | Diagnostic Tool                                     |  |
| ECM          | Electronic Control Module                           | Electronic control unit of the DDEC system   |
| ECU          | Engine Control Unit                                 | Engine governor  |
| EDM          | Engine Data Module                                  | Memory module for engine data  |
| EE-PROM      | Electrically Erasable Programmable Read Only Memory |  |
| EFPA         | Electronic Foot Pedal Assembly                      |  |
| EGR          | Exhaust Gas Recirculation                           |  |

| Abbreviation | Meaning  | Explanation   |
|--------------|--|---|
| EMU          | Engine Monitoring Unit                         |   |
| ETK          | Ersatzteilkatalog                              | Spare Parts Catalog (SPC)   |
| EUI          | Electronic Unit Injector                       |   |
| FPS          | Fuel Pressure Sensor                           |   |
| FRS          | Fuel Differential Pressure Sensor              |   |
| FTS          | Fuel Temperature Sensor                        |   |
| FWCP         | Fire Water Control Panel                       |   |
| GND          | Ground   |   |
| HP           | High pressure                                  |   |
| HI           | High   | Alarm: Measured value exceeds 1st maximum limit                                 |
| HIHI         | High High                                      | Alarm: Measured value exceeds 2nd maximum limit value                           |
| HT           | High Temperature                               |   |
| IDM          | Interface Data Module                          | Memory module for interface data  |
| INJ          | Injector                                       |   |
| ISO          | International Organization for Standardization | International umbrella organization for all national standardization institutes |
| KGS          | Kraftgegenseite                                | Engine free end in accordance with DIN ISO 1204                                 |
| KS           | Kraftseite                                     | Engine driving end in accordance with DIN ISO 1204                              |
| LED          | Light Emitting Diode                           |   |
| LO           | Low  | Alarm: Measured value lower than 1st minimum limit value                        |
| LOLO         | Low Low  | Alarm: Measured value lower than 2nd minimum limit value                        |
| LSG          | Limiting Speed Governor                        |   |
| N/A          | Not Applicable                                 |   |
| LP           | Low pressure                                   |   |
| OEM          | Original Equipment Manufacturer                |   |
| OI           | Optimized Idle                                 |   |
| OLS          | Oil Level Sensor                               |   |
| OPS          | Oil pressure sensor                            |   |
| OTS          | Oil Temperature Sensor                         |   |
| OT           | Oberer Totpunkt                                | Top dead center (TDC)   |
| PAN          | Panel  | Control panel   |
| PIM          | Peripheral Interface Module                    |   |
| PWM          | Modulated signal                               |   |
| P-xyz        | Pressure-xyz                                   | Pressure measuring point, xyz specifies the measuring point designation         |
| RL           | Redundancy Lost                                | Alarm: Redundant CAN bus failure  |
| SAE          | Society of Automotive Engineers                | U.S. standardization organization   |
| SD           | Sensor Defect                                  | Alarm: Sensor failure   |

| Abbreviation | Meaning                      | Explanation  |
|--------------|------------------------------|--|
| SEL          | Stop engine light            | 1st function: Warning lamp (stop engine and rectify fault)<br>2nd function: Read out fault codes |
| SID          | System Identifier            |  |
| SRS          | Synchronous Reference Sensor | TDC cylinder 1   |
| SS           | Safety System                | Safety system alarm  |
| TBS          | Turbocharger Boost Sensor    | Monitors charge-air pressure   |
| TCI          | Turbo Compressor Inlet       |  |
| TCO          | Turbo Compressor Outlet      |  |
| TD           | Transmitter Deviation        | Alarm: Deviation in transmitter values   |
| TPS          | Throttle Position Sensor     |  |
| TRS          | Timing Reference Sensor      |  |
| T-xyz        | Temperature-xyz              | Temperature measuring point, xyz specifies the measuring point designation                       |
| UT           | Unterer Totpunkt             | Bottom dead center (BDC)   |
| VNT          | Variable nozzle turbine      |  |
| VSG          | Variable-speed governor      |  |
| VSS          | Vehicle Speed Sensor         |  |
| WZK          | Werkzeugkatalog              | Tool Catalog   |

## 8.2 MTU contact persons/service partners

Our worldwide sales network with its subsidiaries, sales offices, representatives and customer service centers ensures fast and direct support on site and the high availability of our products.

### **Local support**

Experienced and qualified specialists place their knowledge and expertise at your disposal.

For locally available support, go to the MTU Internet site: <http://www.mtu-online.com>

### **24h hotline**

With our 24h hotline and the outstanding flexibility of our service staff, we are always ready to assist you – either during operation, for preventive maintenance, corrective work in case of malfunction or changed operating conditions, or for spare parts supply.

Your contact at Headquarters: [Service-support@mtu-online.com](mailto:Service-support@mtu-online.com)

### **Spare parts service**

Fast, simple and correct identification of spare parts for your drive system or vehicle fleet. The right spare part at the right time at the right place.

With this aim in mind, we can call on a globally networked spares logistics system, a central warehouse at headquarters and on-site stores at our subsidiary companies, agencies and service workshops.

Your contact at Headquarters:

E-mail: [spare.parts@mtu-online.com](mailto:spare.parts@mtu-online.com)


Phone: +49 7541 908555

Fax: +49 7541 908121

# 9 Appendix B


## 9.1 Special Tools

### Barring device




|           |  |
|-----------|--|
| Part No.: | F6555766                                     |
| Qty.:     | 1  |
| Used in:  | 7.1.1 Engine – Barring manually (→ Page 131) |

### Feeler gauge




|           |   |
|-----------|---|
| Part No.: | Y20010128   |
| Qty.:     | 1   |
| Used in:  | 7.4.2 Valve clearance – Check and adjustment (→ Page 141) |

### Filter wrench



|           |   |
|-----------|---|
| Part No.: | F30379104   |
| Qty.:     | 1   |
| Used in:  | 7.8.1 Fuel filter – Replacement (→ Page 153)        |
| Qty.:     |   |
| Used in:  | 7.14.1 Engine oil filter – Replacement (→ Page 171) |

### Installation/removal tool




Part No.: F6789889

Qty.: 1

Used in: 7.6.2 Injector – Removal and installation (→ Page 147)

### Milling cutter




Part No.: F30452739

Qty.: 1

Used in: 7.6.2 Injector – Removal and installation (→ Page 147)

### MTU test kit



Part No.: 5605892099/00


Qty.: 1

Used in: 7.13.3 Engine oil – Sample extraction and analysis (→ Page 170)

Qty.: 1

Used in: 7.15.6 Engine coolant – Sample extraction and analysis (→ Page 183)

### Ratchet adapter




Part No.: F30027340

Qty.: 1

Used in: 7.3.1 Crankcase breather – Oil separator element replacement, diaphragm check and replacement (→ Page 138)

### Ratchet adapter




Part No.: F30027341

Qty.: 1

Used in: 7.13.1 Engine oil – Change (→ Page 167)

### Ratchet with extension



Part No.: F30006212

Qty.: 1

Used in: 7.1.1 Engine – Barring manually (→ Page 131)

### Rigid endoscope




Part No.: Y20097353

Qty.: 1

Used in: 7.2.1 Cylinder liner – Endoscopic examination (→ Page 134)

### Ring socket, 24 mm



Part No.: F30039526

Qty.: 1

Used in: 7.4.2 Valve clearance – Check and adjustment (→ Page 141)

### Steam jet cleaner

|           |                                 |
|-----------|---------------------------------|
| Part No.: | -                               |
| Qty.:     | 1                               |
| Used in:  | 4.11 Plant cleaning (→ Page 77) |

### Torque wrench, 0.5-5 Nm

|           |  |
|-----------|--|
| Part No.: | 0015384230   |
| Qty.:     | 1  |
| Used in:  | 7.6.2 Injector – Removal and installation (→ Page 147) |



### Torque wrench, 10-60 Nm

|           |  |
|-----------|--|
| Part No.: | F30510423  |
| Qty.:     | 1  |
| Used in:  | 1.4 Crankshaft transport locking device (→ Page 8) |




### Torque wrench, 10-60 Nm

|           |  |
|-----------|--|
| Part No.: | F30452769  |
| Qty.:     | 1  |
| Used in:  | 7.6.2 Injector – Removal and installation (→ Page 147) |




### Torque wrench, 40-200 Nm

|           |   |
|-----------|---|
| Part No.: | F30027337                               |
| Qty.:     | 1                                       |
| Used in:  | 7.13.1 Engine oil – Change (→ Page 167) |



### Torque wrench, 6-50 Nm

|           |  |
|-----------|--|
| Part No.: | F30027336  |
| Qty.:     | 1  |
| Used in:  | 7.3.1 Crankcase breather – Oil separator element replacement, diaphragm check and replacement (→ Page 138) |
| Qty.:     | 1  |
| Used in:  | 7.14.3 Centrifugal oil filter – Cleaning and filter sleeve replacement (→ Page 174)                        |



### Torque wrench, 60-320 Nm

|           |   |
|-----------|---|
| Part No.: | F30047446   |
| Qty.:     | 1   |
| Used in:  | 7.4.2 Valve clearance – Check and adjustment (→ Page 141) |



### Torque wrench, 60-320 Nm

|           |  |
|-----------|--|
| Part No.: | F30047446  |
| Qty.:     | 1  |
| Used in:  | 1.4 Crankshaft transport locking device (→ Page 8) |



Torque wrench, 60-320 Nm

Part No.: F30452768

Qty.: 1

Used in: 7.6.2 Injector – Removal and installation (→ Page 147)



## 9.2 Index

- 12 V 4000 engine data
  - Continuous operation 3B, optimized exhaust emissions (EPA stage 2) [40](#)
- 12 V 4000 Gx3 engine data
  - Continuous operation, variable 3B, optimized exhaust emissions (TA-Luft) [32](#)
  - Continuous operation, variable 3B, optimized fuel consumption [28](#)
  - Standby operation 3D, optimized exhaust emissions (EPA stage 2) [52](#)
- 12V 4000 Gx3 engine data
  - Standby operation 3D, optimized fuel consumption [44](#)
- 16 V 4000 engine data
  - Continuous operation 3B, optimized exhaust emissions (EPA stage 2) [40](#)
- 16 V 4000 G83L engine data
  - Standby operation 3D, optimized exhaust emissions (EPA stage 2) [60](#)
  - Standby operation 3D, optimized fuel consumption [56](#)
- 16 V 4000 Gx3 engine data
  - Continuous operation 3A, optimized fuel consumption [25](#)
  - Continuous operation, variable 3B, optimized fuel consumption [36](#)
  - Standby operation 3D, optimized exhaust emissions (EPA stage 2) [52](#)
  - Standby operation 3D, optimized fuel consumption [48](#)
- A**
- Abbreviations [199](#)
- Actuators
  - Overview [21](#)
- After stopping the engine – Engine remains ready for operation [75](#)
- After stopping the engine – putting the engine out of service [76](#)
- Air filter
  - Removal and installation [164](#)
  - Replacement [162](#)
- Air filter – Check [163](#)
- Air starter
  - Manual operation [166](#)
- Auxiliary materials [16](#)
- B**
- Battery-charging generator
  - Drive belt replacement [193](#)
  - Drive belt tension adjustment [192](#)
- C**
- Centrifugal oil filter
  - Cleaning and filter sleeve replacement [174](#)
- Charge-air coolant
  - Change [185](#)
  - Draining [186](#)
  - Filling [187](#)
  - Level check [184](#)
- Charge-air coolant level
  - Check [184](#)
- Charge-air coolant pump
  - Relief bore check [190](#)
- Connectors
  - Cleaning [196](#)
- Contact persons [202](#)
- Coolant
  - Change [185](#)
- Coolant - charge air
  - Level check [184](#)
- Crankcase breather
  - Diaphragm check [138](#)
  - Oil separator element replacement [138](#)
- Crankshaft transport locking device
  - Removal/installation [8](#)
- Cylinder
  - Designation [19](#)
- Cylinder head cover
  - Removal and installation [144](#)
- Cylinder liner
  - Endoscopic examination [134](#)
  - Instructions and comments on endoscopic and visual examination [136](#)
- D**
- Drive belt
  - Condition check [191](#)
- E**
- ECU 7 engine governor
  - Removal and installation [198](#)
- Emergency stop [74](#)
- Engine
  - Barring manually [131](#)
  - Barring with starting system [132](#)
  - Main dimensions [66](#)
  - Test run [133](#)
  - Wiring check [195](#)
- Engine coolant
  - Change [177](#)
  - Draining [178](#)
  - Filling [179](#)
  - Level check [176](#)
  - Sample extraction and analysis [183](#)
- Engine coolant pump
  - Relief bore check [182](#)
- Engine governor
  - Checking plug-in connections [197](#)
  - Cleaning [196](#)

Engine governor ADEC (ECU 7) for Series 4000 genset engines – Fault messages 82

Engine layout 20

Engine mounting

– Check 194

Engine oil

– Centrifugal oil filter – Cleaning and filter sleeve replacement 174

– Change 167

– Sample extraction and analysis 170

Engine oil filter

– Replacement 171

Engine oil level

– Check 169

Engine side

– Designation 19

Engine wiring

– Check 195

Environmental protection 16

## F

Final compression pressure 64

Fire prevention 16

Firing order 65

Fluids and lubricants 16

Fuel

– prefilter

– Flushing 157

Fuel filter

– Replacement 153

Fuel prefilter

– Differential pressure gauge

– Check and adjustment 155

– Draining 156

– Filter element

– Replacement 159

– Flushing 157

Fuel prefilter cleaning 154

Fuel system

– Venting 152

## G

General conditions 5

## H

Hotline 202

HP pump

– Filling with engine oil 145

## I

Injector

– Removal and installation 147

– Replacement 146

Injectors

– Overview 21

Inspection port cover

– Explosion hazard 12

Intercooler

– Checking condensate drain for coolant discharge 161

– Checking condensate drain for obstructions 161

## M

Main dimensions 66

Maintenance task reference table [QL1] 78

Maintenance work

– Safety regulations 13

MTU contact persons 202

## O

Oil indicator filter

– Check 172

Operation

– Safety regulations 11

Operational checks 72

Organizational requirements 6

## P

Personnel requirements 6

Plant

– Cleaning 77

Putting the engine into operation after extended out-of-service periods (>3 months) 67

Putting the engine into operation after scheduled out-of-service-period 68

## R

Repair work

– Safety regulations 13

## S

Safety instructions

– Conventions 18

Safety regulations 11, 13

Safety system

– Override 70

Sensors

– Overview 21

Service indicator

– Signal ring position check 165

Service partners 202

Spare parts service 202

Start engine in manual mode (testing mode) 69

Starting the engine in emergency situations (override mode) 71

Startup

– Safety regulations 11

Stop engine in manual mode (testing mode) 73

## T

Transport 7

Troubleshooting 79

## V

Valve clearance

– Adjustment 141

– Check 141

Valve gear

– Lubrication 140

## W

Wiring - engine

– Check 195